

Increasing The Fan Speed - Sanyo ECO R410A Installation Instructions Manual

Eco-i system air conditioner

1

2

3

Table Of Contents

4

5

6

7

8

9

10

11

12

13


14

15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48




•

Table of Contents

- - Troubleshooting

•

Bookmarks



CAUTION

- (4) When the check of drainage is complete, open the check pin (CHK) and remount the insulator and drain cap onto the drain inspection port. **Be careful since the fan will start when you short the pin on the indoor control board.**



Be careful since the fan will


CAUTION

start when you short the pin

on the indoor control board.

3-15. Increasing the Fan Speed

- (4) When the check of drainage is complete, open the check pin (CHK) and remount the insulator and drain cap onto the drain inspection port.



3-15. Increasing the Fan Speed

For Short Circuit Connection

■ For Short Circuit Connection

- The standard (before shipment) external static pressure is shown in the table below
- When using with a higher static pressure, it is necessary to change to the high static

● External static pressure

When using with a higher static pressure, it is necessary to change to the high static pressure mode

TYPE	7	12	15	18
Standard (in.WG)	0.04	0.06	0.06	0.06
External high static pressure (in.WG)	0.12	0.12	0.16	0.16



When using with high static pressure mode, set the indoor unit control board

TYPE

Standard (in.WG)

**CAUTION**

When using with high static pressure mode, set the indoor unit control board on the indoor control board.

as shown at right. Follow the below procedure while the unit is turned off.

(4) When the check of drainage is complete, open the check pin (CHK) and remount the insulator and drain cap onto the drain inspection port.



(2) Connect the short circuit connector to the short circuit pin TP3 (2P: Yellow) of the indoor unit control board.

- The standard (before shipment) external static pressure is shown in the table below
- When using with a higher static pressure, it is necessary to change to the high static pressure mode.

In case of wired remote control setting, do not use the short circuit connector.

External static pressure

TYPE	7	9	12	15	18
For Wired Remote Control	0.04	0.06	0.06	0.06	0.06
Press "High static pressure (in.WG)"	0.12	0.12	0.16	0.16	0.16

longer When using with high static pressure mode, set the indoor unit control board as shown at right. Follow the below procedure while the unit is turned off.

(1) Open the cover of the electrical box and confirm that it is the indoor unit control board.

(2) Connect the short circuit connector to the short circuit pin TP3 (2P: Yellow) of the indoor unit control board.

At this time, the indoor unit fan (or all indoor unit fans in the case of group control) begins operating.

- In case of wired remote control setting, do not use the short circuit connector.

For Wired Remote Control

① Press and hold the , and buttons simultaneously for 4 seconds or longer.

* For item codes and setting data, refer to the right table.

Press and settings data " **00XX** " are displayed blinking on the remote controller LCD button display.

(The display stops blinking and remains lit, and setting is completed.) (At this time, the indoor unit fan (or all indoor units in the case of group control) begins operating.)




② Press the temperature setting / buttons to select the item code " **5d** ".

③ Press the timer time / buttons to select the desired setting data.

* For item codes and setting data, refer to the right table.

④ Press the .

(The display stops blinking and remains lit, and setting is completed.)



0.04
L
0
177
353
Airflow (CFM)



CAUTION

Be careful since the fan will start when you short the pin on the indoor control board.

Be careful since the fan will start when the check of drainage is complete, open the check pin (CHK) and remount the insulator and drain cap onto the drain inspection port.



3-15. Increasing the Fan Speed

■ For Short Circuit Connection

- The standard (before shipment) external static pressure is shown in the table below
- When using with a higher static pressure, it is necessary to change to the high static

External static pressure

TYPE	7	9	12	15	18
Standard (in.WG)	0.04	0.06	0.06	0.06	0.06
High static pressure (in.WG) button(s) simultaneously for 4 seconds or	0.12	0.12	0.16	0.16	0.16

"(or)" When using with high static pressure mode, set the indoor unit control board "in the case of group control" item code " as shown at right. Follow the below procedure while the unit is turned off. are displayed blinking on the remote controller LCD.



(1) Open the cover of the electrical box and confirm that it is the indoor unit control board.

(2) Connect the short circuit connector to the short circuit pin TP3 (2P: Yellow) of the indoor unit control board.

In case of wired remote control setting, do not use the short circuit connector.

■ For Wired Remote Control

- Press and hold the , and buttons simultaneously for 4 seconds or longer.
- " **SETTING** , " unit No. " **L** " (or " **ALL** " in the case of group control), item code " **10** " and settings data " **00XX** " are displayed blinking on the remote controller LCD display.

At this time, the indoor unit fan (or all indoor unit fans in the case of group control) begins operating.




③ Press the temperature setting / buttons to select the item code " **5d** ".

④ Press the timer time / buttons to select the desired setting data.

* For item codes and setting data, refer to the right table.

⑤ Press the button.

(The display stops blinking and remains lit, and setting is completed.)



0.06
0.06
0.06
0.16
0.16



CAUTION

Be careful since the fan will start when you short the pin on the indoor control board.

- (4) When the check of drainage is complete, open the check pin (CHK) and remount the insulator and drain cap onto the drain inspection port.

External static pressure's upper limit in high static pressure mode

Standard external static

pressure's upper limit

Lower limit airflow

UMHX1862

When using with a higher static pressure, it is necessary to change to the high static

External static pressure

TYPE	7	9	12	15	18
Standard (in.WG)	0.04	0.06	0.06	0.06	0.06
High static pressure (in.WG)	0.12	0.12	0.16	0.16	0.16

When using with high static pressure mode, set the indoor unit control board as shown at right. Follow the below procedure while the unit is turned off.

(1) Open the cover of the electrical box and confirm that it is the indoor unit control board.

(2) Connect the short circuit connector to the short circuit pin TP3 (2P: Yellow) of the indoor unit control board.

In case of wired remote control setting, do not use the short circuit connector.

For Wired Remote Control

Water inlet

Eyelet cap

Indoor control board

② "SETTING," unit No. "1-1" (or "ALL" in the case of group control), item code "10," and settings data "00XX" are displayed blinking on the remote controller LCD display.

At this time, the indoor unit fan (or all indoor unit fans in the case of group control) begins operating.

③ Press the temperature setting Δ / ∇ buttons to select the item code "5d".

④ Press the timer time Δ / ∇ buttons to select the desired setting data.

* For item codes and setting data, refer to the right table.

⑤ Press the SET button.

(The display stops blinking and remains lit, and setting is completed.)

Airflow (CFM)

0.197

0

530

Wiring port

Fig. 3-34

White Yellow Red

TP6

TP3 TP1

2

3


4

Description

Rated external static


pressure in high static

UMHX0762



UMHX1262

UMHX0962



UMHX1562

External static pressure's upper limit in high static pressure mode

Standard external static pressure's upper limit

External Static Pressure (in.WG)

UMHX1862

0.24

UMHX1862

pressure mode

Lower static pressure


in high static pressure

mode

Rated external static

pressure at shipment

Upper limit airflow



CAUTION

Be careful since the fan will start when you short the pin on the indoor control board.

~~When the check of drainage is complete, open the check pin (CHK).~~



[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

[1](#)

[...](#)

[16](#)

[17](#)

[18](#)

[19](#)

[20](#)

[21](#)

[22](#)

[23](#)

Quick Links:

[Indoor Unit](#)
[Installing the Drain Piping](#)
[Name of Parts](#)
[Care and Cleaning](#)
[Troubleshooting](#)

Related Manuals for Sanyo ECO R410A

[Air Conditioner Sanyo ECO-i AHX0752 Technical Data Manual](#)

(265 pages)

[Air Conditioner Sanyo MINI ECO-i XHX1252 Service Manual & Test Run Service Manual](#)

(190 pages)

[Air Conditioner Sanyo ECO-i CHDZR07263 Series Service Manual](#)

(146 pages)

[Air Conditioner Sanyo CHDXR09663* Service Manual](#)

2-way eco-i multi system (142 pages)

[Air Conditioner Sanyo CHDZ07263 Service Manual](#)

(128 pages)

[Air Conditioner Sanyo AHX0752 Service Manual](#)

W-2way eco-i multi system (114 pages)

[Air Conditioner Sanyo W-3WAY ECO-i 85464369098000 Installation](#)

[Instructions Manual](#)

W-3way eco-i system air conditioner (106 pages)

[Air Conditioner Sanyo 85464359982001 Installation Instructions](#)

[Manual](#)

W-2way system air conditioner (96 pages)

[Air Conditioner Sanyo Mini ECO-i CHXR03652 Service Manual](#)

(93 pages)

[Air Conditioner Sanyo Mini ECO-i 85464359981002 Installation Instructions Manual](#)

Sanyo air conditioner installation instructions (90 pages)

[Air Conditioner Sanyo R410A Installation Instructions Manual](#)

W-3way eco-i system air conditioner (54 pages)

[Air Conditioner Sanyo XM18AAB Installation Instructions Manual](#)

W-2way system air conditioner (50 pages)

[Air Conditioner Sanyo XHX1252 Instruction Manual](#)

Split system air conditioner (20 pages)

[Air Conditioner Sanyo THX2452 User Manual](#)

(4 pages)

[Air Conditioner Sanyo DHX4852 Manual](#)

Indoor unit (4 pages)

[Air Conditioner Sanyo THX1852 Manual](#)

Indoor unit (4 pages)

Related Content for Sanyo ECO R410A

[CH2442 Increasing The Fan Speed](#)

Sanyo CH2442

[W-3WAY ECO-i 85464369098000 Increasing The Fan Speed](#)

Sanyo W-3WAY ECO-i 85464369098000

[Mini ECO-i 85464359981002 Increasing The Fan Speed](#)

Sanyo Mini ECO-i 85464359981002

[C4272R Increasing The Fan Speed](#)

Sanyo C4272R

[C4272R S/C Increasing The Fan Speed](#)

Sanyo C4272R S/C

[SPW-C0705DZH8 Increasing The Fan Speed](#)

Sanyo SPW-C0705DZH8

[SPW-CR365GXH56 Increasing The Fan Speed](#)

Sanyo SPW-CR365GXH56

[C4272R Increasing The Fan Speed](#)

Sanyo C4272R

This manual is also suitable for:

Xhx1252Xhx1852Xhx2452Xhx365Xmhx1252Xmhx1852 ... [Show all](#)