

Scrolling With The Touchpad; Control Buttons; Disabling Or Enabling The Touchpad - Toshiba L20/L25 User Manual

Toshiba user's guide notebook computer l20/l25

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27

Table Of Contents


28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256



•

[Table of Contents](#)

•

Bookmarks



Scrolling with the TouchPad

There are two active regions on the TouchPad that allow you to scroll as you would with any wheel device on a mouse or trackball.

To scroll vertically, run your finger up or down along the right edge of the TouchPad. To scroll horizontally, run your

finger

along the bottom edge of the TouchPad. This feature can be disabled or changed in the Mouse Properties dialog box.

Control buttons

When a step instructs you to click or choose an item, move the cursor to the item, then press and release the primary (left-hand) button. To double-click, press the primary button

twice in rapid succession. The primary button usually corresponds to the left mouse button.

The function of the secondary (right-hand) button depends on

the program you are using. It usually corresponds to the right

mouse button. Check your program's documentation to find

whether it uses the right mouse button.

Disabling or enabling the TouchPad

The TouchPad is enabled by default. To change the enable/disable TouchPad setting:

1

Click Start, and then Control Panel.

The Control Panel window appears.

2

Click Printers and Other Hardware.

3

Click the Mouse icon.

4

Click the TouchPAD ON/OFF tab.

The TouchPAD ON/OFF tab view window appears.

Getting Started

Using the TouchPad™

™

63

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
60
61
62
63
64
65
66
67

Related Manuals for Toshiba L20/L25

[Laptop Toshiba Satellite L20 Series Maintenance Manual](#)

Personal computer (264 pages)

[Laptop Toshiba Satellite L20 Series User Manual](#)

(190 pages)

[Laptop Toshiba Satellite L20-SP119 User Manual](#)

Portable personal computer (178 pages)

[Laptop Toshiba Satellite L25-S119 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S1192 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S1193 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S1194 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S1195 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S1196 Specifications](#)

Satellite l25 series (10 pages)

[Laptop Toshiba Satellite L25-S121 Specifications](#)

Toshiba satellite l25-s121: specifications (10 pages)

[Laptop Toshiba Satellite L25-S1215 Specifications](#)

Toshiba satellite l25-s1215: specifications (10 pages)

[Laptop Toshiba Satellite L25-S1216 Specifications](#)

Toshiba satellite l25-s1216: specifications (10 pages)

[Laptop Toshiba Satellite L25-S1217 Specifications](#)

Toshiba satellite l25-s1217: specifications (10 pages)

[Laptop Toshiba Satellite L20-S310TD Specifications](#)

Toshiba satellite l20-s310td: specifications (7 pages)

[Laptop Toshiba L2-S022 User Manual](#)

L2-s022 user's guide (260 pages)

[Laptop Toshiba Tecra L2-S022 Specifications](#)

Toshiba tecra l2-s022: specifications (7 pages)

Related Content for Toshiba L20/L25

[X305-Q705 - Qosmio - Core 2 Duo GHz Scrolling With The Touchpad](#)

Toshiba X305-Q705 - Qosmio - Core 2 Duo GHz

[U205-S5002 - Satellite - Core Duo 1.66 GHz Scrolling With The Touchpad](#)

Toshiba U205-S5002 - Satellite - Core Duo 1.66 GHz

[P105 S6197 - Satellite - Core 2 Duo 1.6 GHz Scrolling With The Touchpad](#)

Toshiba P105 S6197 - Satellite - Core 2 Duo 1.6 GHz

[P505 S8970 - Satellite - Core 2 Duo 2.2 GHz Scrolling With The Touchpad](#)

Toshiba P505 S8970 - Satellite - Core 2 Duo 2.2 GHz

[S300 EZ1514 - Satellite Pro - Core 2 Duo 2.1 GHz Scrolling With The Touchpad](#)

Toshiba S300 EZ1514 - Satellite Pro - Core 2 Duo 2.1 GHz

[R10 S4401 - Tecra - Core 2 Duo 2.26 GHz Scrolling With The Touchpad](#)

Toshiba R10 S4401 - Tecra - Core 2 Duo 2.26 GHz

[M45-S165 - Satellite - Celeron M 1.5 GHz Scrolling With The Touchpad](#)

Toshiba M45-S165 - Satellite - Celeron M 1.5 GHz

[M45 S169 - Satellite - Celeron M 1.6 GHz Scrolling With The Touchpad](#)

Toshiba M45 S169 - Satellite - Celeron M 1.6 GHz

This manual is also suitable for:

[L20-s310tdL25-s119L25-s1192L25-s1193L25-s1194L25-s1195](#) ... [Show all](#)