



# Inserting A Compact Disc - Toshiba P100-ST7211 User Manual

P100-st7211 user's guide



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
Table Of Contents  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117


118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167

168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217



218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242  
243  
244  
245  
246  
247  
248  
249  
250  
251  
252  
253  
254  
255  
256  
257  
258  
259  
260  
261  
262  
263  
264  
265  
266  
267

268  
269  
270  
271  
272  
273  
274  
275



•

•

## Bookmarks





# 94

## **Learning the Basics**

*Using the Optical Drive*

---

**Manual eject hole—Use if you need to release the disc tray**

when the power is off. Use a straightened paper clip or other

narrow object to press the manual eject button located inside the hole.

## Inserting a compact disc

To insert a compact disc into the drive:

**1**

Make sure the computer is turned on.

**2**

Make sure the in-use indicator light is off.

**3** **CAUTION**

Press the drive's eject button.

The disc tray slides partially out of the drive (about 1 inch).

**4**

Grasp the tray and pull it fully open.

*(Sample Illustration) Drive tray fully extended*

**5**

Hold the disc by its edges and check that it is free of dust.

Never use a pencil to press the manual eject button. Pencil lead can break off inside the computer and damage it.

HINT: The drive will not open if the computer's power is off.

[Previous Page](#)  
[Next Page](#)



1  
...  
91  
92  
93  
94  
95  
96  
97  
98

## Related Manuals for Toshiba P100-ST7211

[Laptop Toshiba Satellite P100 Series User Manual](#)

(196 pages)

[Laptop Toshiba Satellite P100-ST7211 Series Specifications](#)

Toshiba satellite p100-st7211: specifications (8 pages)

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

Pc (314 pages)

[Laptop Toshiba Satellite P100 Series Maintenance Manual](#)

(311 pages)

[Laptop Toshiba P100/P105 User Manual](#)

Toshiba satellite p100/p105 series user's guide (280 pages)

[Laptop Toshiba P105-S9337 User Manual](#)

P105-s9337 user's guide (278 pages)

[Laptop Toshiba P100-ST1072 User Manual](#)

P100-st1072 user's guide (237 pages)

[Laptop Toshiba PSPA3C-SD402E User Manual](#)

User manual (172 pages)

[Camcorder Toshiba PA3943U-1CAM Camileo P100 User Manual](#)

Pa3943u-1cam camileo p100 user's guide (146 pages)

[Laptop Toshiba Satellite P100/P105Series Resource Manual](#)

Toshiba laptop pc user's guide (72 pages)

[Laptop Toshiba Satellite P105-S6014 Specifications](#)

Toshiba satellite p105-s6014: specifications (11 pages)

[Laptop Toshiba Satellite P105-S6024 Specifications](#)

Toshiba satellite p105-s6024: specifications (11 pages)

[Laptop Toshiba Satellite P105-S6084 Specifications](#)

Toshiba satellite p105-s6084: specifications (11 pages)

[Laptop Toshiba Satellite P105-S6104 Specifications](#)

Toshiba satellite p105-s6104: specifications (11 pages)

[Laptop Toshiba Satellite P105-S6134 Specifications](#)

Toshiba satellite p105-s6134: specifications (11 pages)

[Laptop Toshiba Satellite P100 Specifications](#)

Toshiba satellite p100: specifications (2 pages)

## Related Content for Toshiba P100-ST7211

[M45-S165 - Satellite - Celeron M 1.5 GHz Inserting A Compact Disc](#)

Toshiba M45-S165 - Satellite - Celeron M 1.5 GHz

[M45 S169 - Satellite - Celeron M 1.6 GHz Inserting A Compact Disc](#)

Toshiba M45 S169 - Satellite - Celeron M 1.6 GHz

[M115 S1061 - Satellite - Celeron M 1.6 GHz Inserting A Compact Disc](#)

Toshiba M115 S1061 - Satellite - Celeron M 1.6 GHz

[M105-S1021 - Satellite - Celeron M 1.46 GHz Inserting A Compact Disc](#)

Toshiba M105-S1021 - Satellite - Celeron M 1.46 GHz

[M400 - Portege - Core 2 Duo 1.83 GHz Inserting A Compact Disc](#)

Toshiba M400 - Portege - Core 2 Duo 1.83 GHz

[A8 S8514 - Tecra - Core 2 Duo GHz Inserting A Compact Disc](#)

Toshiba A8 S8514 - Tecra - Core 2 Duo GHz

[A105-S4004 - Satellite - Core Duo 1.66 GHz Inserting A Compact Disc](#)

Toshiba A105-S4004 - Satellite - Core Duo 1.66 GHz

[Satellite R20-ST2081 Inserting A Compact Disc](#)

Toshiba Satellite R20-ST2081

This manual is also suitable for:

[P100-st7111P100-st9012P100-st9212P100-st9412P100-st9612P105-s6002](#) ... [Show all](#)