



# Asus AAEON SRG-ACAN User Manual

lot gateway system



1

2

3

4

5

6

7

8

9

10

Table Of Contents

11

12

13

14

15

16

17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51

---

•


[Table of Contents](#)

•

## Bookmarks

[Download this manual](#)

## Quick Links



# SRG-ACAN

## IoT Gateway System

User's Manual

Ed

st

Last Updated: August 13, 2021



## Table of Contents

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Asus AAEON SRG-ACAN

### [Gateway Asus AAM6KBDBX User Manual](#)

Zhone bonded channel (42 pages)

### [Gateway Asus AAEON SRG-ADIO User Manual](#)

lot gateway system (53 pages)

### [Gateway Asus Aaeon AIOT-QM User Manual](#)

(39 pages)

### [Gateway Asus Aaeon AIOT-IGWS01 User Manual](#)

Industrial automation iot gateway (44 pages)

### [Gateway Asus Aaeon SRG-4858P User Manual](#)

lot gateway system (40 pages)

### [Gateway Asus AAEON SRG-IMX8PL User Manual](#)

lot gateway system (76 pages)

### [Gateway Asus iPBX30 User Manual](#)

(160 pages)

### [Gateway Asus WL-500g User Manual](#)

Spacelink home gateway (26 pages)

### [Gateway Asus WL-600g User Manual](#)

(57 pages)

### [Gateway Asus Aaeon UP-GWS01 User Manual](#)

(21 pages)

### [Gateway Asus HG100 User Manual](#)

(160 pages)

### [Gateway Asus WL-500b User Manual](#)

Spacelink home gateway (26 pages)

### [Gateway Asus Aaeon UPC-GWS01 User Manual](#)

(21 pages)

### [Gateway Asus SpaceLink WL-500 User Manual](#)

Home gateway (74 pages)

### [Gateway Asus DSL-N10 User Manual](#)

Wireless adsl gateway (2 pages)

## Summary of Contents for Asus AAEON SRG-ACAN

[Page 1](#) SRG-ACAN IoT Gateway System User's Manual 1 Last Updated: August 13, 2021...

[Page 2](#) Copyright Notice This document is copyrighted, 2021. All rights are reserved. The original manufacturer reserves the right to make improvements to the products described in this manual at any time without notice. No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission of the original manufacturer.

[Page 3](#) Acknowledgements All other products' name or trademarks are properties of their respective owners. Microsoft Windows is a registered trademark of Microsoft Corp. • Intel® is a registered trademark of Intel Corporation • ARM, Cortex, and Cortex-A8 are registered trademarks of Arm Limited (or its •...



## [Page 17: Chapter 2 - Hardware Information](#)

Chapter 2 Chapter 2 – Hardware Information...

## [Page 18: Dimensions](#)

Dimensions Chapter 2 – Hardware Information...

## [Page 19: I/O Location](#)

I/O Location Reference Function Antenna Connector Antenna connector for 2.4G or LTE Reset Button Reboots the system Debug Port User can log into the gateway's operating system via SSH with debug port (Micro USB connector) RS-485 Terminal Resistor Used with long distance connection between gateway and RS-485 device Micro SIM Slot Insert a Micro SIM card here when using an LTE Mini Card Module...

[Page 20](#) Reference Function Gigabit LAN Port Standard RJ-45 LAN jack to connect with Local Area Network Function Status Yellow Active status ON: LAN link is established. OFF: LAN link is not established. Blink: Data received and transmitted. Orange Link Speed Green on: 10/100Mbps. /Green status Orange on: 1000Mbps.

## [Page 21: Wireless Hardware Setup](#)

Wireless Hardware Setup The SRG-ACAN features both a SIM Card and Mini Card slot for connecting to wireless networks such as 4G. This section details how to install a SIM Card and 4G/LTE module on the mini card slot. 2.3.1 Mini Card Installation Step 1: Remove the six screws securing the top cover.

[Page 22](#) Step 4: Remove the bottom access panel. Install the 4G/LTE module by inserting at an angle into the Mini Card slot, pressing down gently and securing with a screw. Step 5: Connect the antenna cable to the module. Step 6: Replace the bottom panel, then the top cover. Chapter 2 –...

## [Page 23: Sim Card Installation](#)

2.3.2 SIM Card Installation To install a SIM Card (Micro SIM) simply insert the SIM Card into the slot on the side of the system as shown. Take care to make sure the card is oriented correctly. Chapter 2 – Hardware Information...

## [Page 24: Chapter 3 - Gateway Setup And Configuration](#)

Chapter 3 Chapter 3 – Gateway Setup and Configuration...

## [Page 25: Connecting To System](#)

Connecting to System When connecting a PC or laptop to the SRG-ACAN system, it is recommended to use PuTTY with Windows 10. Users can download the software from the PuTTY website. <https://www.putty.org/> For Windows 7 or older, users must first set up their PC to recognize the system. The following instructions detail how to set up your PC to connect to the SRG-ACAN system by installing the CDC Serial Driver.

[Page 26](#) Step 4: Open PuTTY and use the following settings to connect to the system. Serial Port Settings Baud Rate 115200 bps Parity None Data bits Stop bits Flow Control None Click "Open" to connect with the gateway system. Chapter 3 – Gateway Setup and Configuration...

[Page 27](#) Step 5: You will see the login prompt once the host PC successfully connects to the gateway. Default login information is: Username: aaeon Password: aaeon Chapter 3 – Gateway Setup and Configuration...

## [Page 28: User Account Management](#)

User Account Management This section details how to manage user accounts on the system. Add User Account Command Line: ✓ \$ sudo useradd -m -G sudo -s /bin/bash USERACCOUNT USERACCOUNT -> Account name you want to add Return (test3 is the account name in this example): ✓ ...

## [Page 29: Network Settings](#)

Network Settings This section details how to check and setup the network settings. 3.3.1 Check IP Settings: Check the IP setting by entering the following command into Terminal/Command Line: `$ nmcli con show NETWORKPROFILE` NETWORKPROFILE refers to one of the system's network connections as follows: NETWORKPROFILE Port/Hardware Ethernet0...

## [Page 30: Set Static Ip](#)

3.3.2 Set Static IP Step 1: Enter edit mode with the following command: `$ nmcli con edit NETWORKPROFILE` See table in 3.3.1 for NETWORKPROFILE values Command should return the following (Ethernet0 used in this example): Step 2: Edit the IP Address with the following commands: `$ nmcli>...`

## [Page 31: Set Dynamic Ip](#)

3.3.3 Set Dynamic IP Step 1: Enter edit mode with the following command: `$ nmcli con edit NETWORKPROFILE` See table in 3.3.1 for NETWORKPROFILE values Command should return the following (Ethernet0 used in this example): Step 2: Edit the IP address with the following commands: `$ nmcli>...`

## [Page 32: Cellular Network Settings](#)

Cellular Network Settings This section details how to check and manage the cellular network settings. 3.4.1 Check Cellular Module Status Step 1: To check the status of the cellular module, enter the following command: `$ mmcli -m 0` The system should output the following: Chapter 3 -...

## [Page 33: Dial Up Cellular Module](#)

3.4.2 Dial Up Cellular Module Step 1: Follow the steps in the previous section to check the cellular module status. The system should return a state of "registered" under Status if the module is ready to use. If there is an issue, the state will show "failed" along with a failed reason such as "sim missing".

## [Page 34: Wi-Fi And Bluetooth Network Settings](#)

Wi-Fi and Bluetooth Network Settings This section details how to check and setup Wi-Fi and Bluetooth wireless networks. 3.5.1 Scan for Wi-Fi Access Points To scan for Wi-Fi access points, enter the following command: `$ nmcli dev wifi` The system will return a list of Wi-Fi networks with their name, signal strength and security type.

## [Page 35: Disconnect From Wi-Fi Access Point](#)

3.5.3 Disconnect from Wi-Fi Access Point To disconnect from a Wi-Fi network, enter the following command: `$ sudo nmcli con down id 'SSID'` SSID is the name of the network you want to disconnect from The system will return the following if successful: 3.5.4 Check Wi-Fi Connection Status To check the status of a Wi-Fi connection, enter the following command:...

## [Page 36: Enter Bluetooth Control Panel](#)

3.5.5 Enter Bluetooth Control Panel Before managing Bluetooth settings, you must first enter the Bluetooth Control Panel with the following command: `$ sudo bluetoothctl` The system will return the following: 3.5.6 Scan for Bluetooth Device To scan for a Bluetooth Device, enter the following commands: `$ power on` This command turns on the Bluetooth module `$ scan on...`

## [Page 37: Pair Bluetooth Device](#)

3.5.7 Pair Bluetooth Device To pair a Bluetooth Device, enter the following command while in the control panel: `$ pair MAC_ID MAC_ID` is the MAC address of the device you wish to connect to. This example is connecting to device E8:6F:38:83:CF:10 3.5.8 Check Paired Bluetooth Devices To check which Bluetooth devices are paired with the system, use the command:...

## [Page 38: System Management](#)

System Management This section details how to check the OS version, storage device status, shutdown the system and set the date and time. 3.6.1 Check OS Version To check which OS version the system is running, enter the command: `$ cat /etc/os-release` The system will return the OS information: Chapter 3 -...

## [Page 39: Check Storage Status](#)

3.6.2 Check Storage Status To check the status of the system storage, enter the following command: `$ df -h` The system will return a list of storage devices, capacity and usage  
3.6.3 Shut Down the System To force the system to shut down, use following command. Note, you may need to enter the user password.

## [Page 40: Set Date And Time](#)

3.6.4 Set Date and Time Step 1: Check current date and time by issuing the following command: `$ timedatectl` The system will return the current system clock settings Step 2: Change the date and time by issuing the following command: `$ date MMDDhhmmYYYY`  
Command uses the following formatting: MM -...

## [Page 41: I/O Management](#)

I/O Management This section details how to operate the programmable I/O functions; GPIO and RS-485 2-wire connectors.  
3.7.1 Control GPIO (LEDs) To control the GPIO manually, issue the following commands, this example uses led1: GPIO On: `$ echo 1 > /sys/class/leds/srt3352:led1/brightness` GPIO Off: `$ echo 0 >...`

## [Page 42: Rs-485 2-Wire Pin Definition](#)

3.7.2 RS-485 2-wire Pin Definition Label System Reference COM1 /dev/ttyS4 COM2 /dev/ttyS5  
Signal DATA+ DATA- Chapter 3 – Gateway Setup and Configuration...

## [Page 43: Rs-232/422/485, Can Bus Pin Definitions](#)

3.7.3 RS-232/422/485, CAN Bus Pin Definitions Label System Reference COM1 /dev/ttyMU0  
COM2 /dev/ttyMU1 COM1 Signal COM2 Signal CAN Signal AI\_2 AI\_4 CAN1\_H CAN0\_H AI\_1 AI\_3  
CAN1\_L CAN0\_L Chapter 3 – Gateway Setup and Configuration...

## [Page 44: Manage Rs-232/422/485 Mode](#)

3.7.3.1 Manage RS-232/422/485 Mode Check Current Mode by entering the following command:  
`$ sudo uartmode -p PORTNO` PORTNO is the label of each port: PORTNO System Name Port  
Label /dev/ttyMU0 COM1 /dev/ttyMU1 COM2 Example: will return mode for COM1 `$ sudo uartmode -p`  
The command will output a single number.

## [Page 45: Can Bus Read/Write](#)

3.7.3.2 CAN Bus Read/Write To command the CAN Bus to Read or Write, use the following commands: Initialize CAN Bus: `$ sudo srg52-initcan CANN0 BAUDRATE`  
CAN Bus Read: `$ sudo can_read CANN0` CAN Bus Write: `$ sudo can_write CANN0 CANN0` variable is either can0 or can1  
CANN0 System Name...

## [Page 46: Adc, Digital I/O Pin Definitions](#)

3.7.4 ADC, Digital I/O Pin Definitions COM1 Signal COM2 Signal VCC+ DI\_Common (VCC+) VCC-  
DI\_1 DO\_2 DI\_2 DO\_3 DI\_3 DO\_4 DI\_4 DO\_1 AI\_1 AI\_2 AI\_3 AI\_GND AI\_4 Chapter 3 – Gateway Setup and Configuration...

## [Page 47: Wiring Diagram](#)

3.7.4.1 Wiring Diagram Analog Input: Digital Input: Chapter 3 – Gateway Setup and Configuration...

## [Page 48](#) Digital Output Chapter 3 – Gateway Setup and Configuration...

## [Page 49: Manage Digital I/O](#)

3.7.4.2 Manage Digital I/O Set Digital Output State Use the following command to set digital output state to ON or OFF `$ setdo CHANNEL STATE` CHANNEL 0, 1, 2, or 3 STATE set to 1 for ON or 0 for OFF  
Example: Get Digital Input Status Use the following command to check the status of digital input:...

## [Page 50: Manage Analog Input \(4Ch Signal End\)](#)

3.7.4.3 Manage Analog Input (4CH Signal End) Enter the following command to view status for all channels: `$ rd_exadc -a`  
Config-CH0 Config-CH1 Config-CH2 Config-CH3 Config-CH# for each

channel use the following numerical inputs: Voltage Current Disable (no value will be returned)  
For example: The following command will return voltage values for all four channels: \$ rd\_exadc  
-a...

### [Page 51: Manage Analog Input \(2Ch Differential\)](#)

3.7.4.4 Manage Analog Input (2CH Differential) To check Group status, use the following  
command: \$ rd\_exadc -g GROUP -m 0 GROUP enter 0 for group 0 (ch0 and ch1); enter 1 for  
group 1 (ch2 and ch3) The system will return the following: Chapter 3 -...