

TOSHIBA

Toshiba PDP002Z Function Manual

Profibus-dp option

1
Table Of Contents
2
3
4
5
6
7
8
20
21
22
23
24
25
26
27
28



•

[Table of Contents](#)

•

Bookmarks

[Download this manual](#)

Quick Links



E658134B 

TOSVERT VF-AS1/PS1

PROFIBUS-DP Option Function Manual

PDP002Z

* The data given in this manual are subject to change without notice.

© Toshiba Schneider Inverter Corporation 2006

All rights reserved.

Table of Contents

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba PDP002Z

[Inverter Toshiba TOSVERT VF-AS1 Instruction Manual](#)

High-performance inverter (328 pages)

[Inverter Toshiba TOSVERT VF-PS1 Instruction Manual](#)

Variable torque inverter (317 pages)

[Inverter TOSHIBA TOSVERT VF-AS1 Instruction Manual](#)

The new high-performance inverter tosvert (313 pages)

[Inverter Toshiba VF-PS1 Instruction Manual](#)

Variable torque inverter (307 pages)

[Inverter Toshiba VF-PS1 Instruction Manual](#)

Totally enclosed box type inverter (52 pages)

[Inverter Toshiba TOSVERT VF-AS1 Series Function Manual](#)

Ethernet/ip option unit (49 pages)

[Inverter Toshiba TOSVERT VF-AS1 Function Manual](#)

(33 pages)

[Inverter Toshiba TOSVERT VF-AS1 Instruction Manual](#)

Pg feedback board (27 pages)

[Inverter Toshiba TOSVERT VF-AS1 Instruction Manual](#)

Cc-link ccl001z1 (22 pages)

[Inverter Toshiba DEV002Z Instruction Manual](#)

Devicenet option (20 pages)

[Inverter Toshiba BACnet BCN001Z Function Manual](#)

(19 pages)

[Inverter Toshiba TOSVERT VF-AS1 Instruction Manual](#)

Heatsink outside mounting kit (14 pages)

[Controller Toshiba TOSVERT VF-AS1 Instruction Manual](#)

Torque control (13 pages)

[Power Supply Toshiba TOSVERT VF-AS1 Installation Manual](#)

Conduit box kit option (13 pages)

[Inverter Toshiba TOSVERT VF-AS1 Instruction Manual](#)

Light-load high-speed operation (11 pages)

[Inverter Toshiba TOSVERT VF-AS1 Manual](#)

Current and speed control gain adjustment method (7 pages)

Summary of Contents for Toshiba PDP002Z

[Page 1](#) E6581343 © TOSVERT VF-AS1/PS1 PROFIBUS-DP Option Function Manual PDP002Z *
The data given in this manual are subject to change without notice. © Toshiba Schneider
Inverter Corporation 2006 All rights reserved.

[Page 2: Table Of Contents](#)

Contents 1. Introduction...2 2. Connection Information ...3 2.1. Exterior features...3 2.2.
PDP002Z Device Data...4 2.3. Setting a station address ...5 2.4. Status indicator ...7 2.5.
Communications-related parameters...7 3. "PROFIdrive" Profile ...8 3.1. PPO TYPE ...8 3.2. STW
Control Word Data ...9 3.3.

with two's complement of the forward frequency reference.

[Page 14: The Access To The Profibus Parameter](#)

(Parameter ID/value) Octet 1 Octet 2 Octet 3 Octet 4 Octet 5 Octet 6 Octet 7 Octet 8 PKE
(Parameter ID) (Task ID/Response ID) AK (Request from Master to PDP002Z) Request ID AK
(Response from PDP002Z to Master) Response ID SPM: always 0.

[Page 15](#) 5 = 187.5 kbit/s 6 = 93.75 kbit/s 7 = 45.45 kbit/s 19.2 kbit/s 9.6 kbit/s 255 = Invalid
baud rate Identification number of the PDP002Z (0x093C) Profile number of the PDP002Z
(0x0302) Control word Status word - 14 -...

[Page 16: Examples Of Reading Or Changing The Profdrive Parameter](#)

3.5.1. Examples of reading or changing the PROFdrive parameter 3.5.1.1. Example 1. Reading
the PNU 964 (ID number) AK = 1 (Request parameter value) SPM = 0 PNU = 964 (0x03C4)
Requirement Response (Value: 0x093C) 3.5.1.2. Example 2. Reading the PNU 947, IND (Fault
history) AK = 6 (Request parameter value (array)) SPM = 0 PNU = 947 (0x03B3)

[Page 17](#) 3.5.1.3. Example 2. Changing the PNU 933 (Control word, bit 11) AK = 2 (Change
parameter value (word)) SPM = 0 PNU = 933 (0x03A5) PWE = 10 (0x000A) Requirement (PNU
933 = 10 (f111 = 10)) Response (Value: 0x000D = Inverter over load) Example of the error
occurrence Requirement (PNU 933 = 136 (out of the value range)) Response (Value: 0x0002 =
Lower or upper limit violated)

[Page 18: Access To The Vf-As1/Ps1 Parameter](#)

3.6. Access to the VF-AS1/PS1 parameter When access to the VF-AS1/PS1 parameter, set "1" to
the PNU. The communication number of the inverter parameter is set to the subindex IND. Refer
to the inverter instruction manual about the communication number and unit. 3.6.1.

[Page 19](#) 3.6.1.3. Example 3. Reading the status monitor parameter (fe02 (The operation
frequency)) AK = 6 (Request parameter value (array)) SPM = 0 PNU = 1 IND = 0xFE02(fe02
communication number) Requirement Response (Value: 0x03E8 (= 1000 -> 10.00Hz)) * The
status monitor parameter can not be changed. 3.6.1.4.

[Page 20: User Defind" Profile](#)

4. "USER DEFIND" Profile Cyclic command transmission (the value of the parameter f831 - f836)
and monitoring (the value of the parameter f841 - f846) are possible for PDP002Z by the
original profile Select the "USER DEFIND" as the profile on the configuration.

[Page 21: How To Use](#)

The value of the parameter fd03 specified as 0 and 1 byte of the PZD1 with the parameter f841
is inputted. VF-AS1/PS1 Parameter Value f841 3 (FD03) f842 f843 The value of a parameter fd03
is outputted. PDP002Z PZD1 PDP002Z PZD1 - 20 - PROFIBUS Master PZD2 PZD3 PROFIBUS
Master PZD2...

[Page 22: The Overview Of The Vf-As1/Ps1 Parameter](#)

4.2. The overview of the VF-AS1/PS1 parameter Refer to a communication functional description
(VF-AS1: E6581315/VF-PS1: E6581413) for details. 4.2.1. FA06 (Command word 1 from internal
option PCB) Function Preset Speed1 Preset Speed2 Preset Speed3 Preset Speed4 THR/2 PI off
ACC1/ACC2 DC braking Forward/Reverse Run/stop...

[Page 23: Fa07 \(Frequency Reference From Internal Option Pcb\)](#)

4.2.3. FA07 (Frequency reference from internal option PCB) Frequency reference is set up by
0.01Hz unit and the hexadecimal number. For example, when "Frequency reference" is set up
to 80Hz, since the minimum unit is 0.01Hz, 80 / 0.01 = 8000 = 0x1F40 (Hex.) 4.2.4.

[Page 24: Fd01 \(Inverter Status \(Real Time\)\)](#)

4.2.8. FD01 (Inverter status (real time)) Function ALARM (Reserved) tHr2(VF2+tH2) ACC1/ACC2
DC braking Forward /Reverse Run/stop Free run (ST) Emergency stop READY with ST/ RUN
READY without ST/RUN 15** Local/Remote * Ready for operation: Initialization completed, not a
stop due to a failure, no alarm issued, not moff, not a forced stop due to II, not a forced stop due

to a momentary power failure.

[Page 25: Fe36 \(Analog Input Value Vi/Ii\)](#)

4.2.11. FE36 (Analog input value VI/II) The value inputted into the VI/II terminal is read. The value range is 0 - 10000 (0 - 100.00 %). Also the same as the parameter FE35 (RR Input).

4.2.12. FE37 (RX Input) The value inputted into the RX terminal is read. The value range is -10000 - 10000 (-100.00 - +100.00 %).

[Page 26: Fc91 \(Alarm Code\)](#)

4.2.16. FC91 (Alarm code) Function Over current alarm Inverter over load alarm Motor over load alarm Over heat alarm Over voltage alarm Under voltage of main power (Reserved) Under current alarm Over torque alarm OLr alarm Cumulative run-time alarm (Reserved) (Reserved) (Reserved) Stop after instantaneous power off...

[Page 27: Fc90, Fe10 - Fe13 \(Inverter Fault\)](#)

4.2.19. FC90, FE10 - FE13 (Inverter fault) Data Data (hexa- (decimal) decimal) Code No error nerr Over-current during acceleration Over-current during deceleration Over-current during constant speed operation Over-current in load at startup U-phase arm over-current oca1 V-phase arm over-current oca2 W-phase arm over-current oca3 Input phase failure...

[Page 28: About Gsd File](#)

E6581343 © 4.3. About GSD file As for acquisition of an GSD file, it is possible to download from homepage of our company. Please use what was in agreement with the software version of usage's VF-AS1/PS1. VF-AS1: <http://www.inverter.co.jp/product/inv/vfas1/pdp/> VF-PS1: <http://www.inverter.co.jp/product/inv/vfps1/pdp/> - 27E - - 27 -...

This manual is also suitable for:

[Tosvert vf-as1](#) [Tosvert vf-ps1](#)