




Asus 7265NG E-Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110



•

[Table of Contents](#)

•

Bookmarks

Quick Links

[1 Table of Contents](#)

[2 Chapter 1: Hardware Setup](#)

[3 Getting to Know Your Notebook Pc](#)

[4 Top View](#)

[5 Hardware Faqs](#)

[Download this manual](#)



E9958

Revised Edition V2

November 2014

Notebook PC



E-Manual

Table of Contents

[Next Page](#)

1
2
3
4
5

Related Manuals for Asus 7265NG

[Tablet Asus 7265NGW E-Manual](#)

(108 pages)

[Laptop Asus UX305F E-Manual](#)

Notebook pc (112 pages)

[Laptop Asus Eee PC 701SD XP Quick Use Manual](#)

(8 pages)

[Laptop Asus Eee PC 4G Service Overview](#)

Asus eee pc 4g service overview (103 pages)

[Laptop Asus Chromebook 7265D2 User Manual](#)

(17 pages)

[Laptop Asus Vivobook S410UN-NS74 E-Manual](#)

(98 pages)

[Laptop Asus Q502L E-Manual](#)

(116 pages)

[Laptop Asus N591LN E-Manual](#)

(126 pages)

[Laptop Asus L403S E-Manual](#)

(104 pages)

[Laptop Asus ASUS ZENBOOK UX31A Manual](#)

(98 pages)

[Laptop Asus ASUS Transformer Pad TF300T Bruksanvisning](#)

Tf300t (90 pages)

[Laptop Asus ASUS TAICHI 21 E-Manual](#)

Notebook pc (110 pages)

[Laptop Asus ASUS ZENBOOK UX32VD User Manual](#)

Notebook pc (100 pages)

[Laptop Asus ASUS VivoBook S550CA E-Manual](#)

(122 pages)

[Laptop Asus TUF Gaming F15 Series Service Manual](#)

(31 pages)

[Laptop Asus X75A User Manual](#)

(116 pages)

Summary of Contents for Asus 7265NG

[Page 1](#) E9958 Revised Edition V2 November 2014 Notebook PC E-Manual...

[Page 2](#) Warranty Statement, up to the listed contract price of each product. ASUS will only be responsible for or indemnify you for loss, damages or claims based in contract, tort or infringement under this Warranty Statement.

[Page 3: Table Of Contents](#)

Table of Contents About this manual7 Conventions used in this manual
.....8 Icons 8 Typography8 Safety precautions
.....9 Using your Notebook PC9 Caring for your Notebook PC

.....10 Proper disposal 11 Chapter 1: Hardware Setup Getting to know your Notebook PC14 Top View

[Page 4](#) Chapter 3: Working with Windows® 8.1 Starting for the first time34 ® Windows UI35 Start screen35 Hotspots36 Start button39 Customizing your Start screen 41 ® Working with Windows apps42 Launching apps 42 Customizing apps

[Page 5](#) Tips and FAQs Useful tips for your Notebook PC78 Hardware FAQs79 Software FAQs82 Appendices DVD-ROM Drive Information (on selected models) 86 Blu-ray ROM Drive Information (on selected models).....88 Internal Modem Compliancy88 Overview89 Network Compatibility Declaration

[Page 6](#) ENERGY STAR complied product104 European Union Eco-label 104 Global Environmental Regulation Compliance and Declaration105 ASUS Recycling/Takeback Services105 Rechargeable Battery Recycling Service in North America.....105 Regional notice for Singapore 106 Regional notice for India106 Regional notice for California

[Page 7: About This Manual](#)

About this manual This manual provides information about the hardware and software features of your Notebook PC, organized through the following chapters: Chapter 1: Hardware Setup This chapter details the hardware components of your Notebook Chapter 2: Using your Notebook PC This chapter shows you how to use the different parts of your Notebook PC.

[Page 8: Conventions Used In This Manual](#)

Conventions used in this manual To highlight key information in this manual, some text are presented as follows: IMPORTANT! This message contains vital information that must be followed to complete a task. NOTE: This message contains additional information and tips that can help complete tasks.

[Page 9: Safety Precautions](#)

Safety precautions Using your Notebook PC This Notebook PC should only be used in environments with ambient temperatures between 5°C (41°F) and 35°C (95°F). Refer to the rating label on the bottom of your Notebook PC and ensure that your power adapter complies with this rating.

[Page 10: Caring For Your Notebook Pc](#)

Caring for your Notebook PC Disconnect the AC power and remove the battery pack (if applicable) before cleaning your Notebook PC. Use a clean cellulose sponge or chamois cloth dampened with a solution of nonabrasive detergent and a few drops of warm water. Remove any extra moisture from your Notebook PC using a dry cloth.

[Page 11: Proper Disposal](#)

Proper disposal Do not throw your Notebook PC in municipal waste. This product has been designed to enable proper reuse of parts and recycling. The symbol of the crossed out wheeled bin indicates that the product (electrical, electronic equipment and mercury- containing button cell battery) should not be placed in municipal waste.

[Page 12](#) Notebook PC E-Manual...

[Page 13: Chapter 1: Hardware Setup](#)

Chapter 1: Hardware Setup Notebook PC E-Manual...

[Page 14: Getting To Know Your Notebook Pc](#)

Getting to know your Notebook PC Top View NOTE: The keyboard's layout may vary per region or country. The Notebook view may also vary in appearance depending on the Notebook PC model. Notebook PC E-Manual...

[Page 15](#) Ambient light sensor The ambient light sensor detects the amount of ambient light

in your environment. It allows the system to automatically adjust the brightness of the display depending on the ambient light condition. Camera The built-in camera allows you to take pictures or record videos using your Notebook PC.

[Page 16](#) Capital lock indicator This indicator lights up when the capital lock function is activated. Using capital lock allows you to type capitalized letters (such as A, B, C) using your Notebook PC's keyboard. Touchpad The touchpad allows the use of multi-gestures to navigate onscreen, providing an intuitive user experience.

[Page 17: Bottom](#)

Bottom NOTE: The bottom side may vary in appearance depending on model. WARNING! The bottom of the Notebook PC can get warm to hot while in use or while charging the battery pack. When working on your Notebook PC, do not place it on surfaces that can block the vents. IMPORTANT! Battery time varies by usage and by the specifications for this Notebook PC.

[Page 18: Right Side](#)

Right Side Power indicator The power indicator lights up when the Notebook PC is turned on and blinks slowly when the Notebook PC is in sleep mode. Two-color battery charge indicator The two-color LED provides a visual indication of the battery's charge status.

[Page 19](#) Headphone output jack port This port allows you to connect your Notebook PC to amplified speakers or headphones. Micro HDMI port This port is for a micro High-Definition Multimedia Interface (HDMI) connector and is HDCP compliant for HD DVD, Blu-ray, and other protected content playback.

[Page 20: Left Side](#)

Left Side USB 3.0 ports These Universal Serial Bus 3.0 (USB 3.0) ports provide a transfer rate of up to 5 Gbit/s and are backward compatible to USB 2.0. Memory card reader This built-in memory card reader supports SD and SDXC card formats.

[Page 21: Chapter 2: Using Your Notebook PC](#)

Chapter 2: Using your Notebook PC Notebook PC E-Manual...

[Page 22: Getting Started](#)

Getting started Charge your Notebook PC. Plug the AC power cord into a 100V~240V power source. Connect the DC power connector into your Notebook PC's power (DC) input port. Charge the Notebook PC for 3 hours before using it in battery mode for the first time.

[Page 23](#) • The socket outlet must be easily accessible and near your Notebook • To disconnect your Notebook PC from its main power supply, unplug your Notebook PC from the power socket. WARNING! Read the following precautions for your Notebook PC's battery. • Only ASUS-authorized technicians should remove the battery inside the device. • The battery used in this device may present a risk of fire or chemical burn if removed or disassembled. • Follow the warning labels for your personal safety. • Risk of explosion if battery is replaced by an incorrect type. •...

[Page 24: Lift To Open The Display Panel](#)

Lift to open the display panel. Press the power button. Notebook PC E-Manual...

[Page 25: Gestures For The Touchpad](#)

Gestures for the touchpad Gestures allow you to launch programs and access the settings of your Notebook PC. Refer to the following illustrations when using hand gestures on your touchpad. Moving the pointer using the touchpad You can tap or click anywhere on the touchpad to activate its pointer, then slide your finger on the touchpad to move the pointer onscreen.

[Page 26](#) One-finger gestures Tap/click, Double tap/click • In the Start screen, tap/click an app to launch it. • In Desktop mode, double tap/click an application to launch it. Drag and drop Double-tap/click an item, then slide the same finger without lifting it off the touchpad. To drop the item to its new location, lift your finger from the touchpad. Notebook PC E-Manual...

[Page 27](#) Left-click Right-click • In the Start screen, click an app to launch it. • In the Start screen, click an app to select it and launch the settings bar. You can also double-press this button to launch an application to the All Apps bar. • In Desktop mode, use this button to open the right-click menu.

[Page 28](#) Top edge swipe • In the Start screen, swipe from the top edge to launch the All Apps bar. • In a running app, swipe from the top edge to view its menu. Left edge swipe Right edge swipe Swipe from the left edge to shuffle Swipe the right edge to launch the Charms bar. your running apps. Notebook PC E-Manual...

[Page 29](#) Two-finger gestures Tap/click Rotate Tap/click two fingers on the touchpad to rotate an image, place two fingers on the touchpad then click function. turn one finger clockwise or counterclockwise while the other stays still. Two-finger scroll (up/down) Two-finger scroll (left/right) Slide two fingers to scroll up or Slide two fingers to scroll left or...

[Page 30](#) Zoom out Zoom in Bring together your two fingers on the touchpad. Spread apart your two fingers on the touchpad. Drag and drop Select an item then press and hold the left button. Using your other finger, slide down the touchpad to drag and drop the item to a new location.

[Page 31: Using The Keyboard](#)

Using the keyboard Function keys The function keys on your Notebook PC's keyboard can trigger the following commands: Puts the Notebook PC into Sleep mode Turns Airplane mode on or off NOTE: When enabled, the Airplane mode disables all wireless connectivity. Decreases display brightness Increases display brightness Turns the display panel off...

[Page 32: Windows® 8.1 Keys](#)

Enables or disables the touchpad Turns the speaker on or off Turns the speaker volume down Turns the speaker volume up Windows® 8.1 keys There are two special Windows® keys on your Notebook PC's keyboard used as below: Press this key to go back to the Start screen. If you are already in the Start screen, press this key to go back to the last app you opened.

[Page 33: Chapter 3: Working With Windows](#)

Chapter 3: Working with Windows® 8.1 Notebook PC E-Manual...

[Page 34: Starting For The First Time](#)

Starting for the first time When you start your computer for the first time, a series of screens appear to guide you in configuring your Windows® 8.1 operating system. To start your Notebook PC for the first time: Press the power button on your Notebook PC. Wait for a few minutes until the setup screen appears.

[Page 35: Windows ® Ui](#)

® Windows Windows® 8.1 comes with a tile-based user interface (UI) which allows you to organize and easily access Windows® apps from the Start screen. It also includes the following features that you can use while working on your Notebook PC. Start screen The Start screen appears after successfully signing in to your user account.

[Page 36: Hotspots](#)

Hotspots Onscreen hotspots allow you to launch programs and access the settings of your Notebook PC. The functions in these hotspots can be activated using the touchpad. Hotspots on a running app Hotspots on the Start screen Notebook PC E-Manual...

[Page 37](#) Hotspot Action upper left corner Hover your mouse pointer on the upper left corner then tap/click on the recent app's thumbnail to revert back to that running app. If you launched more than one app, slide down to show all running apps. lower left corner From a running app screen: Hover your mouse pointer on the lower left...

[Page 38](#) Hotspot Action top side Hover your mouse pointer on the top side until it changes to a hand icon. Drag then drop the app to a new location. NOTE: This hotspot function only works on a running app or when you want to use the Snap feature.

[Page 39: Start Button](#)

Start button Windows® 8.1 features the Start button which allows you to switch between the two most recent apps that you opened. The Start button may be accessed from the Start screen, while on Desktop mode, and on any app that is currently open onscreen. Start button on the Start screen NOTE: The actual color of your Start button varies depending on the display settings you chose for your Start screen.

[Page 40](#) Start button on Desktop mode Context menu The context menu appears as a box filled with quick access to some of the programs inside Windows® 8.1 when you right-click on the Start button. The context menu also includes the following shut down options for your Notebook PC: sign out, sleep, shut down, restart.

[Page 41: Customizing Your Start Screen](#)

Customizing your Start screen Windows® 8.1 also enables you to customize your Start screen, allowing you to boot directly to the Desktop mode and customize the arrangement of your apps onscreen. To customize the settings of your Start screen: Launch the Desktop. Right-click anywhere on the taskbar, except on the Start button, to launch the pop-up window.

[Page 42: Working With Windows ® Apps](#)

® Working with Windows apps Use your Notebook PC's touchpad, or keyboard to launch, customize, and close apps. Launching apps Position your mouse pointer over the app then left-click or tap once to launch it. Press twice then use the arrow keys to browse through the apps.

[Page 43](#) Unpinning apps Right-click on the app to activate the Customize bar then tap/click Closing apps Move your mouse pointer on the top side of the launched app then wait for the pointer to change to a hand icon. Drag then drop the app to the bottom of the screen to close it.

[Page 44: Accessing The Apps Screen](#)

Accessing the Apps screen Aside from the apps already pinned on your Start screen, you can also open other applications through the Apps screen. NOTE: Actual apps shown onscreen may vary per model. The following screenshot is for reference only. Launching the Apps screen Launch the Apps screen using your Notebook PC's touchpad or keyboard.

[Page 45](#) Pinning more apps on the Start screen You can pin more apps on the Start screen using your touchpad. Launch the All Apps screen Right-click on the apps that you want to add on the Start screen. Tap/click on the icon to pin the selected apps on the Start screen.

[Page 46: Charms Bar](#)

Charms bar The Charms bar is a toolbar that can be triggered on the right side of your screen. It consists of several tools that allow you to share applications and provide quick access for customizing the settings of your Notebook PC. Charms bar Notebook PC E-Manual...

[Page 47](#) Launching the Charms bar NOTE: When called out, the Charms bar initially appears as a set of white icons. The image above shows how the Charms bar looks like once activated. Use your Notebook PC's touchpad or keyboard to launch the Charms bar.

[Page 48](#) Inside the Charms bar Search This charm allows you to look for files, applications, or programs in your Notebook PC. Share This charm allows you to share applications via social networking sites or email. Start This charm reverts the display back to the Start screen. From the Start screen, you can also use this to revert back to a recently opened app.

[Page 49: Snap Feature](#)

Snap feature The Snap feature displays two apps side-by-side, allowing you to work or switch between apps. IMPORTANT! Ensure that your Notebook PC's screen resolution is set to 1366 x 768 pixels or higher before using the Snap feature. Snap bar Notebook PC E-Manual...

[Page 50](#) Using Snap Use your Notebook PC's touchpad or keyboard to activate and use Snap. Launch the app you wish to snap. Hover the mouse point on the top side of your screen. Once the pointer changes to a hand icon, drag then drop the app to the left or right side of the display panel.

[Page 51: Other Keyboard Shortcuts](#)

Other keyboard shortcuts Using the keyboard, you can also use the following shortcuts to help you launch applications and navigate Windows® 8.1. Switches between the Start screen and the last running app Launches the desktop Launches the This PC window on Desktop mode Opens the File option from the Search charm Opens the Share charm Opens the Settings charm...

[Page 52](#) Launches the Project pane Opens the Everywhere option from the Search charm Opens the Run window Opens Ease of Access Center Opens the Settings option under the Search charm Opens the context menu of the Start button Launches the magnifier icon and zooms in your screen Zooms out your screen Opens the Narrator Settings...

[Page 53: Connecting To Wireless Networks](#)

Connecting to wireless networks Wi-Fi Access emails, surf the Internet, and share applications via social networking sites using your Notebook PC's Wi-Fi connection. IMPORTANT! The Airplane mode disables this feature. Ensure that Airplane mode is turned off before enabling the Wi-Fi connection of your Notebook PC.

[Page 54: Bluetooth](#)

Bluetooth Use Bluetooth to facilitate wireless data transfers with other Bluetooth-enabled devices. IMPORTANT! The Airplane mode disables this feature. Ensure that Airplane mode is turned off before enabling the Bluetooth connection of your Notebook PC. Pairing with other Bluetooth-enabled devices You need to pair your Notebook PC with other Bluetooth-enabled devices to enable data transfers.

[Page 55: Airplane Mode](#)

Airplane mode The Airplane mode disables wireless communication, allowing you to use your Notebook PC safely while in-flight. Turning Airplane mode on Launch the Charms bar. Tap/click and tap/click Move the slider to the right to turn the Airplane mode on. Press Turning Airplane mode off Launch the Charms bar.

[Page 56: Turning Your Notebook Pc Off](#)

Turning your Notebook PC off You can turn off your Notebook PC by doing either of the following procedures: from the Charms bar then • Tap/click > Shut down to do a normal tap/click shutdown. > Shut • From the log-in screen, tap/click down. •...

[Page 57: Windows ® 8.1 Lock Screen](#)

® Windows 8.1 lock screen The Windows® 8.1 lock screen appears when you wake your Notebook PC from sleep or hibernate mode. It also appears when you lock or unlock Windows® 8.1. The lock screen can be customized to regulate access to your operating system.

[Page 58: Customizing Your Lock Screen](#)

Customizing your lock screen You can customize your lock screen to show your preferred photo, a photo slideshow, app updates, and quickly access your Notebook PC's camera. To change the settings of your lock screen, you may refer to the following information: Selecting a photo Launch the Charms bar >...

[Page 59](#) Adding app updates Launch the Charms bar > Settings. Select Change PC Settings > Lock screen. Scroll down until you see the Lock screen apps option. Use the following options to add the apps whose updates you would like to see from your lock screen: Activating your Notebook PC camera from the lock screen From the lock screen, you can swipe down to activate and use your...

[Page 60](#) Notebook PC E-Manual...

[Page 61: Chapter 4: Power-On Self-Test \(Post\)](#)

Chapter 4: Power-On Self-Test (POST) Notebook PC E-Manual...

[Page 62: The Power-On Self-Test \(Post\)](#)

The Power-On Self-Test (POST) The Power-On Self-Test (POST) is a series of software-controlled

diagnostic tests that run when you turn on or restart your Notebook PC. The software that controls the POST is installed as a permanent part of the Notebook PC's architecture. Using POST to access BIOS and Troubleshoot During POST, you can access the BIOS settings or run troubleshooting options using the function keys of your Notebook PC.

[Page 63: Bios Settings](#)

BIOS Settings NOTE: The BIOS screens in this section are for reference only. The actual screens may differ by model and territory. Boot This menu allows you to set your boot option priorities. You may refer to the following procedures when setting your boot priority. On the Boot screen, select Boot Option #1.

[Page 64](#) and select a device as the Boot Option #1. Press Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc. Main Advanced Boot Security Save & Exit Boot Configuration Sets the system boot order Fast Boot [Enabled] Launch CSM [Disabled] Driver Option Priorities Boot Option #1 Boot Option Priorities...

[Page 65](#) Security This menu allows you to set up the administrator and user password of your Notebook PC. It also allows you to control the access to your Notebook PC's hard disk drive, input/output (I/O) interface, and USB interface. NOTE: If you install a User Password, you will be prompted to input this •...

[Page 66](#) To set the password: On the Security screen, select Administrator Password or User Password. Type in a password then press Re-type to confirm the password then press To clear the password: On the Security screen, select Administrator Password or User Password.

[Page 67](#) I/O Interface Security In the Security menu, you can access I/O Interface Security to lock or unlock some interface functions of your Notebook PC. Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc. Security If Locked, LAN I/O Interface Security controller will be disabled.

[Page 68](#) USB Interface Security Through the I/O Interface Security menu, you can also access USB Interface Security to lock or unlock ports and devices. Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc. Security If Locked, all USB Interface Security USB device will be disabled USB Interface...

[Page 69](#) Set Master Password In the Security menu, you can use Set Master Password to set up a password-enabled access to your hard disk drive. Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc. Main Advanced Boot Security Save & Exit Aptio Setup Utility - Copyright (C) 2011 American Megatrends, Inc.

[Page 70](#) Save & Exit To keep your configuration settings, select Save Changes and Exit before exiting the BIOS. Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc. Main Advanced Boot Security Save & Exit Exit system setup Save Changes and Exit after saving the Discard Changes and Exit changes.

[Page 71](#) To update the BIOS: Verify the Notebook PC's exact model then download the latest BIOS file for your model from the ASUS website. Save a copy of the downloaded BIOS file to a flash disk drive. Connect your flash disk drive to your Notebook PC.

[Page 72](#) Locate your downloaded BIOS file in the flash disk drive then press ASUSTek Easy Flash Utility FLASH TYPE: MXIC 25L Series Current BIOS New BIOS Platform: Unknown Platform: UX305 Version: Unknown Version: 101 Build Date: Unknown Build Date: Oct 26 2012 Build Time: Unknown Build Time: 11:51:05 0 EFI...

[Page 73: Recovering Your System](#)

Recovering your system Using recovery options on your Notebook PC allows you to restore the system to its original state or simply refresh its settings to help improve performance. IMPORTANT! • Back up all your data files before doing any recovery option on your Notebook PC.

[Page 74](#) • Advanced startup - Using this option allows you to perform other advanced recovery options on your Notebook PC such as: Using a USB drive, network connection or Windows recovery DVD to startup your Notebook PC. Using Troubleshoot to enable any of these advanced recovery options: System Restore, System Image Recovery, Startup Repair,

Command Prompt, UEFI Firmware Settings, Startup Settings.

[Page 75: Enabling A Recovery Option](#)

Enabling a recovery option Refer to the following steps if you want to access and use any of the available recovery options for your Notebook PC. Launch the charms bar and select Settings. Select Change PC Settings. Notebook PC E-Manual...

[Page 76](#) Under the PC Settings options, select Update and recovery. Under the Update and recovery options, select Recovery then select the recovery option you would like to do. Notebook PC E-Manual...

[Page 77: Tips And Faqs](#)

Tips and FAQs Notebook PC E-Manual...

[Page 78: Useful Tips For Your Notebook Pc](#)

- Update Windows® periodically to ensure that your applications have the latest security settings.
- Use ASUS Live Update to update ASUS-exclusive applications, drivers and utilities in your Notebook PC. Refer to the ASUS Tutor installed in your Notebook PC for more details.
- Use an anti-virus software to protect your data and keep this updated too.
- ...

[Page 79: Hardware Faqs](#)

I turn on the Notebook PC. What should I do? Although these dots normally appear onscreen, they will not affect your system. If the incident continues and subsequently affects system performance, consult an authorized ASUS service center. My display panel has an uneven color and brightness. How...

[Page 80](#) • Check if your speakers were set to mute. • Check if a headphone jack is connected to your Notebook PC and remove it. What should I do if my Notebook PC's power adapter gets lost or my battery stops working? Contact your local ASUS service center for assistance. Notebook PC E-Manual...

[Page 81](#) My Notebook PC's touchpad is not working. What should I You can try doing any of the following suggestions: • Check if ASUS Smart Gesture is set to disable touchpad by connecting an external pointing device to your Notebook PC. If yes, disable this function. • ...

[Page 82: Software Faqs](#)

Remove all connected USB devices then restart your Notebook PC. • If the problem still exists, your Notebook PC might have a memory storage problem. Contact your local ASUS service center for assistance. My Notebook PC boots slower than usual and my operating system lags. How can I fix this? Delete the applications you recently installed or were not included with your operating system package then restart your system.

[Page 83](#) My Notebook PC does not boot up. How can I fix this? You can try doing any of the following suggestions: • Remove all connected devices to your Notebook PC then restart your system. • If the problem still exists, contact your local ASUS service center for assistance. Why can't my Notebook PC wake up from sleep mode? • You need to press the power button to resume your last working state.

[Page 84](#) Notebook PC E-Manual...

[Page 85: Appendices](#)

Appendices Notebook PC E-Manual...

[Page 86: Dvd-Rom Drive Information \(On Selected Models\)](#)

DVD-ROM Drive Information (on selected models) The DVD-ROM drive allows you to view and create your own CDs and DVDs. You can purchase an optional DVD viewer software to view DVD titles. Regional Playback Information Playback of DVD movie titles involves decoding MPEG2 video, digital AC3 audio and decryption of CSS protected content.

[Page 87](#) Region Definitions Region 1 Canada, US, US Territories Region 2 Czech, Egypt, Finland, France, Germany, Gulf States, Hungary, Iceland, Iran, Iraq, Ireland, Italy, Japan,

Netherlands, Norway, Poland, Portugal, Saudi Arabia, Scotland, South Africa, Spain, Sweden, Switzerland, Syria, Turkey, UK, Greece, Former Yugoslav Republics, Slovakia Region 3 Burma, Indonesia, South Korea, Malaysia, Philippines, Singapore, Taiwan, Thailand,...

[Page 88: Blu-Ray Rom Drive Information \(On Selected Models\)](#)

Blu-ray ROM Drive Information (on selected models) The Blu-ray ROM Drive allows you to view high definition (HD) videos and other disc file formats such as DVDs and CDs. Region Definitions Region A North, Central and South American countries, and their territories; Taiwan, Hong Kong, Macao, Japan, Korea (South and North), South East Asian countries and their territories.

[Page 89: Overview](#)

Overview On 4th August 1998 the European Council Decision regarding the CTR 21 has been published in the Official Journal of the EC. The CTR 21 applies to all non voice terminal equipment with DTMF-dialling which is intended to be connected to the analogue PSTN (Public Switched Telephone Network).

[Page 90](#) This table shows the countries currently under the CTR21 standard. Country Applied More Testing Austria Belgium Czech Republic Not Applicable Denmark Finland France Germany Greece Hungary Not Applicable Iceland Ireland Italy Still Pending Still Pending Israel Lichtenstein Luxemburg The Netherlands Norway Poland Not Applicable...

[Page 91: Federal Communications Commission Interference Statement](#)

This information was copied from CETECOM and is supplied without liability. For updates to this table, you may visit http://www.cetecom.de/technologies/ctr_21.html 1 National requirements will apply only if the equipment may use pulse dialling (manufacturers may state in the user guide that the equipment is only intended to support DTMF signalling, which would make any additional testing superfluous).

[Page 92](#) • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. WARNING! The use of a shielded-type power cord is required in order to meet FCC emission limits and to prevent interference to the nearby radio and television reception. It is essential that only the supplied power cord be used. Use only shielded cables to connect I/O devices to this equipment.

[Page 93: Fcc Radio Frequency \(Rf\) Exposure Caution Statement](#)

FCC Radio Frequency (RF) Exposure Caution Statement WARNING! Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. "The manufacture declares that this device is limited to Channels 1 through 11 in the 2.4GHz frequency by specified firmware controlled in the USA.

[Page 94: Ce Marking](#)

CE Marking CE marking for devices without wireless LAN/Bluetooth The shipped version of this device complies with the requirements of the EEC directives 2004/108/EC "Electromagnetic compatibility" and 2006/95/EC "Low voltage directive". CE marking for devices with wireless LAN/ Bluetooth This equipment complies with the requirements of Directive 1999/5/EC of the European Parliament and Commission from 9 March, 1999 governing Radio and Telecommunications Equipment and mutual recognition of conformity.

[Page 95: Ic Radiation Exposure Statement For Canada](#)

IC Radiation Exposure Statement for Canada This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with IC RF exposure compliance requirements, please avoid direct contact to the transmitting antenna during transmitting. End users must follow the specific operating instructions for satisfying RF exposure compliance.

[Page 96: Déclaration D'industrie Canada Relative À L'exposition Aux Ondes Radio](#)

Déclaration d'Industrie Canada relative à l' exposition aux ondes radio Cet appareil est conforme aux limites d'exposition aux radiations d'Industrie Canada définies pour un environnement non-contrôlé. Pour maintenir la conformité avec les exigences d'exposition RF

d'IC, veuillez éviter tout contact direct avec l'antenne pendant l'émission.

[Page 97](#) Radio Frequency (RF) Exposure Information The radiated output power of the Wireless Device is below the Industry Canada (IC) radio frequency exposure limits. The Wireless Device should be used in such a manner such that the potential for human contact during normal operation is minimized.

[Page 98: Wireless Operation Channel For Different Domains](#)

Wireless Operation Channel for Different Domains N. America 2.412-2.462 GHz Ch01 through CH11 Japan 2.412-2.484 GHz Ch01 through Ch14 Europe ETSI 2.412-2.472 GHz Ch01 through Ch13 France Restricted Wireless Frequency Bands Some areas of France have a restricted frequency band. The worst case maximum authorized power indoors are: •...

[Page 99](#) Departments in which the use of the 2400–2483.5 MHz band is permitted with an EIRP of less than 100mW indoors and less than 10mW outdoors: 01 Ain 02 Aisne 03 Allier 05 Hautes Alpes 08 Ardennes 09 Ariège 11 Aude 12 Aveyron 16 Charente 24 Dordogne 25 Doubs 26 Drôme 32 Gers 36 Indre 37 Indre et Loire 41 Loir et Cher 45 Loiret...

[Page 100: UI Safety Notices](#)

UL Safety Notices Required for UL 1459 covering telecommunications (telephone) equipment intended to be electrically connected to a telecommunication network that has an operating voltage to ground that does not exceed 200V peak, 300V peak-to-peak, and 105V rms, and installed or used in accordance with the National Electrical Code (NFPA 70).

[Page 101: Power Safety Requirement](#)

REACH Complying with the REACH (Registration, Evaluation, Authorization, and Restriction of Chemicals) regulatory framework, we publish the chemical substances in our products at ASUS REACH website at <http://csr.asus.com/english/REACH.htm>. Macrovision Corporation Product Notice This product incorporates copyright protection technology that is protected by method claims of certain U.S.A.

[Page 102: Nordic Lithium Cautions \(For Lithium-Ion Batteries\)](#)

Nordic Lithium Cautions (for lithium-ion batteries) CAUTION! Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions. (English) ATTENZIONE! Rischio di esplosione della batteria se sostituita in modo errato. Sostituire la batteria con un una di tipo uguale o equivalente consigliata dalla fabbrica.

[Page 103: Optical Drive Safety Information](#)

Optical Drive Safety Information Laser Safety Information CD-ROM Drive Safety Warning CLASS 1 LASER PRODUCT WARNING! To prevent exposure to the optical drive's laser, do not attempt to disassemble or repair the optical drive by yourself. For your safety, contact a professional technician for assistance.

[Page 104: Ctr 21 Approval \(For Notebook Pc With Built-In Modem\)](#)

CTR 21 Approval (for Notebook PC with built-in Modem) Danish Dutch English Finnish French Notebook PC E-Manual...

[Page 105](#) German Greek Italian Portuguese Spanish Swedish Notebook PC E-Manual...

[Page 106](#) All ASUS products with the ENERGY STAR logo comply with the ENERGY STAR standard, and the power management feature is enabled by default. The monitor and computer are automatically set to sleep after 10 and 30 minutes of user inactivity.

[Page 107](#) Declaration ASUS follows the green design concept to design and manufacture our products, and makes sure that each stage of the product life cycle of ASUS product is in line with global environmental regulations. In addition, ASUS disclose the relevant information based on regulation requirements.

[Page 108](#) Regional notice for Singapore This ASUS product complies with IDA Standards. Complies with IDA Standards DB103778 Regional notice for India This product complies with the "India E-waste (Management and Handling)Rule 2011" and prohibits use of lead, mercury,

hexavalent chromium, polybrominated biphenyls(PBBs) and polybrominated diphenyl ethers (PBDEs) in concentrations exceeding 0.1 % by weight in homogenous materials and 0.01 % by weight...

[Page 109](#) EC Declaration of Conformity We, the undersigned, Manufacturer: ASUSTeK COMPUTER INC. Address: 4F, No. 150, LI-TE Rd., PEITOU, TAIPEI 112, TAIWAN Authorized representative in Europe: ASUS COMPUTER GmbH Address, City: HARKORT STR. 21-23, 40880 RATINGEN Country: GERMANY declare the following apparatus: Notebook PC...

This manual is also suitable for:

[Ux305f7265ngw](#)