

TOSHIBA


Toshiba W-704C Service Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138



•

[Table of Contents](#)

•

Bookmarks

[Download this manual](#)

Quick Links



FILE NO. 110-200004

SERVICE **TOSHIBA** MANUAL

NC MECHANICAL DECK

VIDEO CASSETTE RECORDER

W-704 TOSHIBA

General Descriptions

[General Descriptions](#)

Adjustment Procedures

[Adjustment Procedures](#)

Servicing Diagrams

[Servicing diagrams](#)

Parts List

[Part List](#)

Feb., 2000 Y

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Chapters

Table of Contents 10

Section 3 Servicing Diagrams 90

Related Manuals for Toshiba W-704C

[VCR Toshiba W-704C Owner's Manual](#)

Toshiba america consumer products, inc. video cassetterecorder owner's manual w-704c (48 pages)

[VCR Toshiba W-705 Owner's Manual](#)

Hi-fi vhs video cassette recorder (42 pages)

[VCR Toshiba W-701 Owner's Manual](#)

Hi-fi vhs sqpb video cassette recorder (42 pages)

[VCR Toshiba W-704 Service Manual](#)

Nc mechanical deck (139 pages)

[VCR Toshiba W-704 Owner's Manual](#)

Toshiba video cassette recorder w-704 owner's manual (49 pages)

[VCR Toshiba W-706 Owner's Manual](#)

Hi-fi vhs sqpb video cassette recorder (49 pages)

[VCR Toshiba W-707 Owner's Manual](#)

Toshiba video cassette recorder w-707 owner's manual (49 pages)

[VCR Toshiba W-707 Service Manual](#)

(138 pages)

[VCR Toshiba W-717 Owner's Manual](#)

Hi-fi vhs sqpb video cassette recorder (47 pages)

[VCR Toshiba W-727 Owner's Manual](#)

Hi-fi vhs sqpb video cassette recorder (46 pages)

[VCR Toshiba W-727 Service Manual](#)

(83 pages)

[VCR Toshiba W-714 Owner's Manual](#)

Hi-fi vhs (34 pages)

[VCR Toshiba W-415 Owner's Manual](#)

Video cassette recorder w-415 owner's manual (32 pages)

[VCR Toshiba W-622 Owner's Manual](#)

Toshiba video cassette recorder owner's manual w-622 (33 pages)

[VCR Toshiba W-603 Service Manual](#)

(84 pages)

[VCR Toshiba w425 Service Manual](#)

(50 pages)

Summary of Contents for Toshiba W-704C

[Page 2](#) SAFETY NOTICE SAFETY PRECAUTIONS LEAKAGE CURRENT CHECK Plug the AC line cord directly into a 120V AC outlet (do not measure the AC voltage across the 1500 W resistor. Do not use an isolation transformer for this check). The test must be conducted with the AC switch on and AC Voltmeter, having 5000 W per volt or more sensitivity - then repeated with the AC switch off.

[Page 3](#) Adjustment Procedures Servicing Diagrams Adjustment Procedures Servicing Diagrams Parts List Parts List SECTION 1 GENERAL DESCRIPTIONS 1. OWNER'S MANUAL...

[Page 4](#) Video Cassette Recorder W-704C OWNER'S MANUAL PLAY POWER EJECT PROG.TV STOP PAUSE/STILL This publication is printed on recycled paper 70971857...

[Page 5: Safety Precautions](#)

Address: 1420 Toshiba Drive, Lebanon, TN37087 Telephone: 615-449-2360 User Installer Caution: Changes or modification made to this equipment not expressly approved by Toshiba Corporation or parties authorized by Toshiba Corporation could void the user's authority to operate the equipment. Note to CATV system installer: This reminder is provided to call the CATV system installer's attention to Article 820-40 of the...

[Page 6: Important Precautions](#)

It is permissible to record television programs, film, video tapes and other material only in the event that third party copyrights and other rights are not violated. ® As an E Partner, TOSHIBA has determined that this product or NERGY ® product model meets the E guidelines for energy efficiency.

[Page 7: Important Safety Instructions](#)

IMPORTANT SAFETY INSTRUCTIONS CAUTION: PLEASE READ AND OBSERVE ALL WARNINGS AND INSTRUCTIONS GIVEN IN THIS OWNER'S MANUAL AND THOSE MARKED ON THE UNIT. RETAIN THIS BOOKLET FOR FUTURE REFERENCE. This set has been designed and manufactured to assure personal safety. Improper use can result in electric shock or fire hazard.

[Page 8](#) 6. Water and Moisture Do not use this product near water - for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool and the like. 7. Cleaning Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners.

[Page 9](#) IMPORTANT SAFETY INSTRUCTIONS 12. Lightning For added protection for this product during storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power-line surges.

[Page 10: Table Of Contents](#)

Contents INTRODUCTION Variable Speed Playback21 • Picture Search Provides important notes and general explanation of the VCR, including names of the • Still Picture buttons, jacks, etc. • Slow-motion Picture • Frame Advance SAFETY PRECAUTIONS2 • Double Speed Playback IMPORTANT PRECAUTIONS

[Page 11: Identification Of Controls](#)

INTRODUCTION Identification of Controls See the page in for details. This manual shows the names of buttons in italics. Front Panel CHANNEL EJECT PLAY Cassette compartment POWER STOP PLAY SHUTTLE POWER c EJECT CHANNEL STOP LINE IN 2 PAUSE/STILL LINE IN 2 VIDEO L-MONO-AUDIO-R VIDEO jack...

[Page 12: Vcr Display](#)

VCR Display VCR indicator Timer recording indicator Cassette indicator REMAIN indicator OFF indicator POWER indicator AM PM POWER REMAIN Hi-Fi (L/R) indicators L: Left channel R:Right channel TIMER off: Normal track Multifunctional indicator REC (Recording) DT (Digital Auto Tracking) indicator Channel indicator Tape speed indicator...

[Page 13: Preparation](#)

PREPARATION How to Use the Remote Control This section explains how to get ready for remote

control operation. Setting up the Remote Control Open the battery compartment lid on the rear panel. Install 2 batteries ("AAA" size) following the polarity diagrams. Close the battery compartment lid.

[Page 14: Connections](#)

PREPARATION Connections Before you use this VCR, it is necessary to connect it to your TV. Several ways of connecting are available depending on your use of TV or cable box. Select one which is applicable to your equipment. Antenna/VCR/TV Connection Disconnect the antenna cable from your TV and connect it to the RF IN terminal on the VCR.

[Page 15](#) Connections (continued) Cable Connection Choose one of the below according to your usage of the cable box. This set-up will enable you to: - record an unscrambled channel. - watch an unscrambled channel while recording - record an unscrambled channel while watching another (only when you connect a cable-compatible TV).

[Page 16](#) This set-up will enable you to: - watch an unscrambled or scrambled channel while recording it. - record any channels through the cable box. Cable Box You will need to: • set TV channel 3 or 4 to receive video signals. (See page 11.) •...

[Page 17: Auto Set Up](#)

PREPARATION Auto Set Up The Auto Set Up function automatically sets the tuner channels and clock when power is first connected to the VCR. Preparation • Turn on the TV, and select the video channel (3 or 4), or the video input mode if you made the Audio/Video connection (page 11).

[Page 18: Initial Settings Using On-Screen Display](#)

PREPARATION Initial Settings Using On-screen Display Language selection must be set first when the VCR is first plugged in, or after it encounters a power failure. You can also easily make necessary settings using the on-screen displays. Preparation • Turn on the TV, and select the video channel (3 or 4), or the video input mode if you made the Audio/Video connection (page 11).

[Page 19: Setting The Clock](#)

Initial Settings Using On-Screen Display (continued) Setting the Clock Press ENTER to start the "AUTO" clock set feature. Example: To set the clock to 2:30 p.m. on After a while, the VCR automatically updates August 25 (summer time) 2000. the clock using the data broadcast by the local TV stations.

[Page 20: Storing Channels On The Vcr](#)

PREPARATION Storing Channels on the VCR This section is required if you receive only normal TV or unscrambled cable channels, or use a cable box between your TV and the VCR. Incoming Antenna/Cable (CATV) Signals The VCR scans through all receivable TV and CATV channels and stores only the active ones in your area into the memory.

[Page 21](#) Storing Channels on the VCR (continued) Adding or erasing channels 3) Enter a channel number of 1 to 125 using number buttons . Adding channels For more than 100 number, first press 100 . If a desired channel cannot be scanned For CATV channels, refer to the chart below.

[Page 22: Video Cassette Use](#)

PREPARATION Video Cassette Use Video Cassette Use Loading a cassette Push the cassette into the cassette compartment with the window side facing up and the label side towards the front. The VCR is automatically turned on. The indicator will appear in the VCR display. Ejecting a cassette Press EJECT .

[Page 23: Playback](#)

PLAYBACK Playback This section explains the basic playback operation. Preparation • Select the video channel (3 or 4) or video input mode on the TV. • Press VCR to set the remote control operating the VCR. Basic Playback CH/TRK Load a recorded cassette. POWER Power is turned on.

[Page 24: Variable Speed Playback](#)

PLAYBACK Variable Speed Playback You can play back a tape at various tape speeds. Picture Search A tape runs at 5 times or 7 times the normal playback speed so that you can quickly locate a particular scene. Press FF or REW during playback. The tape runs at 5 times the normal playback speed.

[Page 25: Frame Advance](#)

Variable Speed Playback (continued) Frame Advance Double Speed Playback A picture advances frame by frame. A tape runs at twice the normal speed. Press PLAY/x2 during still playback. Press PLAY/x2 during playback. Each time you press PLAY/x2, the picture The picture runs at twice the normal playback advances one frame.

[Page 26: Operation](#)

PLAYBACK Useful Functions in Tape Operation These functions will help your playback. S-VHS Quasi Playback (SQPB) • This VCR can also play back a tape which is recorded in S-VHS format. But the playback picture does not have the same quality and resolution as the original S-VHS playback picture.

[Page 27: Index Search Function](#)

Useful Functions in Tape Operation (continued) Press PROG. to exit. Press REMAIN/COUNTER. The remaining time ("RT - : -") appears in the VCR display. Notes • The displayed remaining time is an approximation. • The remaining time is calculated according to the tape speed (SP or SLP) and the cassette type.

[Page 28: Recording](#)

RECORDING Recording a TV Program This section explains the basic recording operation. Preparation • Select the video channel (3 or 4) or video input mode on the TV. • If you record cable channels via the cable box, finish the cable box set-up (pages 33-36), and turn on the cable box.

[Page 29: Timer Program Recording](#)

RECORDING Timer Program Recording The programmable timer allows you to record up to 6 different programs over one month. Preparation • Select the video channel (3 or 4) or video input mode on the TV. • Make sure that the clock is set correctly (page 16). •...

Page 30 Move to the next using FF, and set SET UP PRESET PROGRAM the recording date using PLAY/x2 or CH DATE 25 8 / 30 - : - - - : - - STOP . - - - / - - - : - - -...

Page 31 Timer Program Recording (continued) Confirming the timer programs If a power failure occurs during the (in the timer standby mode) timer program recording (including VCR Plus+ C 3 ® system recording Press PROG. . (page 31)) The screen for confirming will appear. •...

[Page 32: Vcr Plus+ C System Set-Up](#)

RECORDING 3 ® VCR Plus+ C system Set-up 3 ® VCR Plus+ C system is a timer recording system for an easier programming that requires you only to ® enter a PlusCode programming number assigned to a desired program. This section explains the necessary set-up to make VCR Plus+ C 3 ®...

Page 33 VCR Plus+ C system Set-up (continued) ® Preparation • Select the video channel (3 or 4) or video input mode on the TV. • If you record cable channels, finish the cable box set-up (pages 33 - 36). • Prepare the list like below. Example Your home channel number (on the channel line-up Guide channel number...

[Page 34: Vcr Plus+ C System Recording](#)

RECORDING 3 ® VCR Plus+ C system Recording 3 ® After performing the VCR Plus+ C system set-up, you can easily program a recording simply by ® entering the PlusCode programming number. The numbers are published in the TV listings of newspapers, TV guide magazine, etc.

Page 35 VCR Plus+ C system Recording (continued) ® Press ENTER. SET UP PRESET PROGRAM The program setting is now memorized. CH DATE 25 8 / 30 9 : 30 10 : 00 • If your

cable box is not remote- --...

[Page 36: Cable Box Set-Up](#)

RECORDING Cable Box Set-up The VCR can directly control channel selecting of the connected cable box. Cable Box Control Connection Type This VCR needs to be connected to a cable Type A box equipped with an infrared wireless remote control. You can select cable channels from the cable box by operating this VCR.

[Page 37](#) Cable Box Set-up (continued) Preparation • Select the video channel (3 or 4) or video input mode on the TV. • Set "TV/CATV" on the CH MEMORY screen to "CATV" (page 17). Cable Box Set-up Press PROG. to display the MENU screen. Number Select "PRESET"...

[Page 38](#) Select "BRAND TYPE" using STOP , and enter a brand code of your cable box using number buttons . Refer to the table on the next page. Example: For a TOSHIBA cable box, identified by number 36. Cable box display PROGRAM...

[Page 39](#) Table of cable box brand codes Brand name of your Brand name of your Brand code
Brand code cable box cable box Telecaption Toshiba Teleview 4, 6, 32, 42, 78 Anvision 13, 20,
21, 22, 23, 24, 25, Texscan 18, 19 26, 58, 62, 84...

[Page 40: Dss ® Satellite Receiver Set-Up](#)

RECORDING ® Satellite Receiver Set-up ® The VCR can directly control channel selecting of the connected DSS satellite receiver. ® Satellite Receiver Control Connection Type ® This VCR needs to be connected to a DSS Type A satellite receiver equipped with an infrared Satellite wireless remote control.

[Page 41](#) ® Satellite Receiver Set-up (continued) Preparation Select the video channel (3 or 4) or video input mode on the TV. ® Satellite Receiver Set-up Press PROG. to display the MENU screen. Number Select "PRESET" using FF or REW , buttons and press ENTER .

[Page 42](#) Select "BRAND TYPE" using STOP , and enter a brand code ® satellite receiver using number buttons . Refer of your DSS to the table on the next page. ® Example: For a TOSHIBA DSS satellite receiver, identified by number 99. SET UP PROGRAM PRESET VCR display C .

[Page 43](#) Brand name of your Brand code ® satellite receiver satellite receiver can be controlled by the following buttons on the remote control of the TOSHIBA VCR. • POWER (CABLE BOX) SONY To turn the DSS ® satellite receiver on or off.

[Page 44: Mts Broadcast Compatibility](#)

RECORDING MTS Broadcast Compatibility This VCR can receive or record MTS (Multichannel TV Sound) broadcasts. By connecting the VCR to your stereo system or stereo TV, you will experience the SAP or stereo sound. Preparation Connect a stereo TV or stereo system to the AUDIO OUT jacks of the VCR. Recording the SAP/Stereo Broadcast On the SET UP screen (page 15), PROGRAM...

[Page 45: Simulcast Recording](#)

RECORDING Simulcast Recording When TV program such as MTV, HBO or MAX is being simulcast in FM stereo in your area, the VCR can also record the simulcast sound from an FM stereo tuner or receiver onto the Hi-Fi track and normal track.

[Page 46: Additional Information](#)

Multi Brand Remote Control The remote control can be compatible with various brands of TV by setting their control codes. The TOSHIBA code has initially been set to control TOSHIBA TVs. Setting Control Codes Press TV to set the remote control operating your TV.

[Page 47](#) Multi Brand Remote Control (continued) Table of Brand Codes Brand name of your TV Brand name of your TV Brand Code Brand Code Toshiba Proton Bell & Howell Pulser Carver Quasar 07, 15 Celebrity Radio Shack Citizen Curtis Mathes 09, 12...

[Page 48: Before Calling Service Personnel](#)

ADDITIONAL INFORMATION Before Calling Service Personnel Check the following symptoms

before requesting servicing. No power. The desired sound is not heard, such as SAP, stereo, or regular sound. • The power cord is not plugged in. • Setting of sounds is not correct. -...

[Page 49](#) Before Calling Service Personnel (continued) The remote control does not work properly. • The batteries are exhausted. - Replace all batteries. (page 10) • The remote control is operated beyond the operating range. - Make sure the remote control is within 30° of the remote sensor on the VCR.

[Page 50: Specifications](#)

Specifications Power supply: 120 V AC, 60 Hz Power consumption: 19 W 430 × 96.5 × 281 mm (W.H.D.) External dimensions: Mass: 3.8 kg Channels received: VHF: Channels 2-13 UHF: Channels 14-69 CATV: Channels 1-125 UHF/VHF: 75 Ω F type connector Antenna input/output terminals: Signal system: Standard NTSC...

[Page 51: Canadian Warranty](#)

This warranty applies only to the original purchaser and is not transferable. The video head warranty is also covered, during which TOSHIBA will provide a replacement head warranted for the unexpired portion of the warranty. This warranty does not apply to sets subjected to misuse, neglect, accident, act of God or improper installation.

[Page 52](#) General Descriptions Servicing Diagrams Parts List General Descriptions Servicing Diagrams Part List SECTION 2 ADJUSTMENT PROCEDURES 1. MECHANICAL ADJUSTMENT 1-1. Mechanical Parts Location 1-2. Servicing Jig List 1-3. Main Parts Servicing Time 1-4. Mechanism Check Method 1-5. Mechanical Deck Removing and Mounting Method 1-6.

[Page 53](#) 1. MECHANICAL ADJUSTMENT 1-1. Mechanical Parts Location Head cleaner ACE head Slip ring assembly No.8 guide cap Pinch roller Impedance roller Cylinder assembly FE head Loading motor T slider S slider No.9 guide lever Tension lever FL cam gear S brake T brake Band brake T reel table...

[Page 54](#) Capstan motor Worm gear T loading lever holder assembly Worm wheel T loading lever assembly Reel belt Loading drive gear Joint gear 1 Tension drive Joint gear 2 lever Cam slider Up/down lever S-VHS switch Holder clutch assembly Pinch drive lever Fig.

[Page 55](#) 1-3. Main Parts Servicing Time 1. Part replacement time differs from servicing life time of each part. 2. Following table is prepared based on a standard condition (room temperature, room humidity). The replacement time will be varied depending upon operation environment, using methods, operation duty. 3.

[Page 56](#) 1-4. Mechanism Check Method Does the loading motor and the If the abnormal condition is caused by the mechanism Loading motor is worm wheel rotate without abnormal. a cassette after turning itself, analyze the cause according to the following the power ON? procedures.

[Page 57](#) 1-4-4. Check by Defective Analyzing Table Note: If the abnormality causes the mechanism abnormal • After replacing the defective parts according to the condition, presume, confirm and treat the defective procedure of the treatment method for the damage according to the defective analyzing table. and phase mismatch of mechanical part, check the operation of the mechanism again, since the same (or (1) Manual Mechanism Operation (Mode Shift) Method...

[Page 58](#) Table 1-4-2 Defective analyzing table Case Defective phenomenon (Main items) Presumed cause (Main cause) Check method Power does not turn on. Loading <General> (1) Check the mode shift "Cas- operation is defective. sette out « FF/REW position" (1) Mechanism stops due to mechanical phase can be performed when turning Mode shift operation is defective.

[Page 59](#) 1-4-5. Unloading Method of Cassette in Manual 1-4-6. Check Method of Each Operation Mode without Loading the Cassette The mechanical deck can not be removed at the condition the cassette is loaded, since one of screws for 1. Put some tapes on both left and right sides of the mounting the mechanism deck with the chassis is cassette holder so that the start/end sensors are not located under the cassette.

[Page 60](#) 1-5. Mechanical Deck Removing and Mounting Method 1-5-1. Cabinet Removal 1-5-2.

Mechanical Deck Removal 1. Unplug the power supply plug (1) from the outlet. 1. Remove the cabinet. (Refer to section 1-5-1, Cabinet 2. Remove the three screws (3) securing the Top cover Removal.) (2).

[Page 61](#) 6. Remove the power supply cord holder (4) from the chassis. 7. Remove the two screws (5) to detach the rear panel(6). 8. Remove the screw (7) to detach the main PC board (8). Power supply Screw (7) cord holder (4) Main PC board (8) Screw (5) Screw (5)

[Page 62](#) 1-6. Main Parts Replacement Lock lever (1) Guide groove 1-6-1. Door Open Lever Replacement Cassette holder 1. Release the claw (1) of the door open lever (2) assembly (2) inserted to the hole at the left lower of the right side mechanical deck with the door open lever (2) turned to the arrow direction.

[Page 63](#) 1-6-4. FL Arm Lever Replacement 1. Remove the door open lever. (Refer to item 1-6-1.) Worm wheel (10) 2. Remove the FL cassette guide assembly. (Refer to Boss (3) of mechanical deck item 1-6-2.) FL cam gear (7) 3. Remove the cassette holder assembly. (Refer to item 1-6-3.) 4.

[Page 64](#) 13. When mounting the FL cam gear (7), align the mark of the FL cam gear (7) with the center of the worm wheel (9). FL cam gear (7) Apply grease to the Mark shaded portion Worm wheel (9) Fig. 1-6-7 FL drive slider Fig.

[Page 65](#) 1-6-6. Worm Gear, Worm Gear Holder, Loading Motor Apply grease to the shaded portion and Worm Wheel Replacement 1. Release the claw (1) of the worm gear holder (2) from the cutout portion of the mechanical deck by bending it to the arrow direction, and remove the worm gear holder (2) by pulling downward.

[Page 66](#) 7. Remove the S, T loading lever assemblies (4) and (5). 8. When removing the pinch drive lever (6), first, remove the cassette door guide, pinch assembly, and the joint lever (Refer to item 1-6-13.), and then remove the T reel table (Refer to item 1-6-11.). Next, pull out the pinch drive lever (6) after turning Apply grease to the it counterclockwise from the bottom side of the...

[Page 67](#) 1-6-8. Tension Lever, Band Brake and Tension Sleeve Replacement 1. Remove the S brake. (Refer to item 1-6-9.) 2. Remove the tension spring (1). 3. Lift up slightly the hole side of the tension sleeve (2) mounted to the mechanical deck, and turn it to the left or right direction, and then remove the tension Tension...

[Page 68](#) 4. Replace each part to new ones. Holder clutch Stop ring (3) assembly (4) 5. Mount it in the reverse order of removal. Notes: • Check that the pad for T brake lever assembly and compression spring (7) are attached. Apply a drop of oil When mounting the T brake lever assembly, do not Spring...

[Page 69](#) 1-6-12. S, T Slider Assemblies Replacement Note: 1. Remove the S, T loading lever assemblies. (Refer to • Check the spring of the holder clutch assembly is set item 1-6-7.) correctly. 2. Remove the S brake. (Refer to item 1-6-9.) 3.

[Page 70](#) No. 9 guide post (10) Pinch assembly (3) Brim of the Capstan motor Cassette door base. shaft guide (2) No. 9 guide spring Flange of the No.9 Pinch drive guide lever. lever (6) Claw (1) (Without spring) Fig. 1-6-33 Type a Pinch drive spring (7) Small hole Brim of the...

[Page 71](#) 1-6-14. FE Head Replacement 1. Remove screw (1) on the FE head (2), and remove the ACE head Boss (6) of FE head (2). assembly (3) mechanical deck 2. Replace the part with new one. Slit (B) 3. Mount it in the reverse order of removal. 4.

[Page 72](#) 1-6-17. Slip Ring Assembly Replacement Notes: 1. Remove two connectors (1) and (2) (cylinder side and • Take care not to stick the grease, oil and etc. on the PC board side) of the slip ring assembly (3). roller (4). •...

[Page 73](#) 1-6-18. Cylinder Holding Plates Replacement Notes: 1. Remove the head cleaner assembly. (Refer to item 1- • Tightening order of the securing screws (1), (2) and 6-16.) (3) is 294 to 392 mN•m (3 to 4kg•cm). 2. Remove three securing screws (1), (2) and (3) on the •...

[Page 74](#) Notes: <Replacement> 1. Remove the slip ring assembly. (Refer to item 1-6-17.) •

When remounting the cylinder holding plate (4), 2. Remove the head cleaner assembly. (Refer to item 1- after confirming that the FPC (1) is hooked at the 6-16.) groove on the lower head assembly properly, insert 3.

[Page 75](#) 1-6-21. No. 8 Guide Cap Replacement 1. Press the No. 8 guide cap for replacement forcibly after pulling out the No. 8 guide cap (1) from the No. Screws (2) 8 guide (2). 2. Mount the No. 8 guide cap (1) by facing the slant surface to cassette side.

[Page 76](#) 1-7. Check and Adjustment 1-7-2. Reel Torque Check (1) Reel Torque 1-7-1. Check of Tension Post Position 1. REV.....supply side Poor torque may not wind the tape. On the other 1. Turn the worm wheel clockwise after removing the cassette holder assembly on the front loading hand, excessive torque will cause damage to the tape mechanism, and set the cam gear at playback mode.

[Page 77](#) <Precautions for Use of Torque Cassette (KT-300NR)> 1. Before loading a torque cassette in a VCR, always remove tape slack. The tape slack can be removed by rotating the reel in the cassette to its take-up direction. (The tape tends to slack since there is no reel brake on the torque cassette.) 2.

[Page 78](#) 1-7-3. Tape Transport System Adjustment (1) Location of Tape Transport Adjustment The tape transport system has been precisely adjusted in <Adjustment Reference> the factory, so only when some defective phenomenon Lower flange height of No.8 guide is used as the basic occurs such as noise observed on the screen and tape reference for the transport adjustment.

[Page 79](#) (2) Tape Transport System Adjustment Flowchart Head assembly (cylinder) assembly replacement S, T slider assembly replacement ACE head assembly replacement Impedance roller replacement Capstan motor assembly Tension lever assembly replacement Clutch gear assembly replacement replacement Pinch lever assembly replacement FE head replacement Reel table replacement Checks for Hi-Fi models only.

[Page 80](#) (3) Tape Transport System Adjustment c. Audio Head Azimuth Adjustment <Rough Adjustment> 1. Play back the 7 kHz audio signal on the alignment When the part(s) listed in Table 1-7-1 is replaced, tape in the SP mode. perform required adjustments by referring to procedures 2.

[Page 81](#) 3) Linearity Adjustment 7. If the envelope varies like NG figures as shown in 1. Play back the SLP mode white video signal on the Fig. 1-7-9, perform the adjustment again since it is alignment tape. abnormal. Smooth secondary curves are allowable level. Note: •...

[Page 82](#) c. Audio Head Height Check 5) No. 9 Guide Lever Check Play back the audio signal as described in the step 4) a., 1. Set the VCR to Cue mode with T-160 tape (at and check if the audio envelope is flat. If not, repeat the beginning portion) loaded.

[Page 83](#) 7) Envelope Check b. Review mode 1. Make recordings and playback the tapes T-120 and Tape damage at No. 8 guide T-160 in SP and SLP modes and make sure the (a) ACE head assembly rough adjustment playback output envelope meets the specifications (Pinch assembly, No.

[Page 84](#) 1-8. Self-Check Function Table 1-8-2 Abnormal system control modes 1-8-1. Outline Standby Stop When a tape running stops or the VCR enters the power Rewind OFF mode, etc. due to some abnormality, the abnormal- Review ity is stored in the EEPROM and displayed on the display tube.

[Page 85](#) 2. ELECTRICAL ADJUSTMENT < Specified input output levels, and impedance > Video input: Negative sync, standard composite < Test equipment required > video signal 1 V(p-p), 75 Ω Adjustment will be performed with the following test Video output: Same as the video input, equipment.

[Page 86](#) Alignment tape specifications (1) ST-N1 Item Record Contents Video signal Audio signal Mode Time *Check and adjustment of Servo circuit. Color bar 1 kHz *Check and adjustment of Video circuit. 10 min *Check and adjustment of Audio circuit. Mono Scope 3 kHz *Check and adjustment of Servo circuit.

[Page 87](#) (3) ST-N5 Item Record Video signal Audio signal Contents Mode Time *Check and adjustment of Servo circuit. Color bar 1 kHz *Check and adjustment of Video circuit. 10 min *Check and adjustment of Audio circuit. Mono Scope 3 kHz *Check and adjustment of Servo circuit. 10 min Notes : 1.

[Page 88](#) P990 P801 P506 Tuner Power Supply R008 ZX01 Main Board 2-1. PIF Circuit 2-1-1. In Case of IC01 is Replaced When IC01 (μ PC1852) is replaced, the EEPROM data in the VCR is required to memorize a new set of default values as initial alignment.

[Page 89](#) 2-2. Servo Circuit 2-2-2. Pseudo-V 2-2-1. Playback Phase (PG) Adjustment Test point : Tracking UP-DOWN key Test equipment : TV monitor Test point : P506, P990 (Video Out) Test equipment : Oscilloscope 1. Self-recorded tape in SP mode is played and enter STILL mode.

[Page 90](#) General Descriptions Adjustment Procedures General Descriptions Parts List Adjustment Procedures Parts List SECTION 3 SERVICING DIAGRAMS 1. INSPECTION PROCEDURES 2. REMOVAL OF THE CABINET 3. LOCATION OF ELECTRICAL UNITS 4. PC BOARD SERVICING PROCEDURE 5. PART CONFIGURATION AND THEIR SYMBOLS 5-1.

[Page 91: Inspection Procedures](#)

1. INSPECTION PROCEDURES Fig No. Operation steps Items to be confirmed Inspection block Block Circuit Diagram Diagram 1.AC Plug-in Clock setting Clock display Power (AC system) 7-1-1 8-2-1 Clock setting operation 7-3-1 8-2-1 2.Power SW ON Timer/counter, SP/SLP, TV/ Mode display lamp Power 7-1-1 8-2-1...

[Page 92: Removal Of The Cabinet](#)

2. REMOVAL OF THE CABINET 4. PC BOARD SERVICING PRO- CEDURE (1) Unplug the power supply plug (1) from the outlet. (2) Remove the three screws (3) securing the Top cover When performing service, connect each connection part (2). of the mechanical deck with the main PC board (two (3) Pull the Top cover (2) backwards for removing.

[Page 93: Part Configuration And Their Symbols](#)

5. PART CONFIGURATION AND THEIR SYMBOLS 5-1. Precautions For Part Replacement * In the schematic diagram, parts marked (ex. F801) are critical part to meet the safety regulations, so always use the parts bearing specified part codes (SN) when replacing them. * Using the parts other than those specified shall violate the regulations, and may cause troubles such as operation failures, fire, etc.

[Page 94: Inductor Indication](#)

5-4. Inductor Indication Unit None • • • H μ • • • μ H • • • mH Tolerance None • • • \pm 5 % • • • \pm 0.1 % 10 μ • • • \pm 0.25 % • • • \pm 0.5 % • • •

[Page 95: Printed Wiring Board And Schematic Diagram](#)

6. PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM UZ01 MAIN UV01 SP-A W501A P102 COMP EVER +5.6V SP-B F(-) F(+) EP-A EVER +5V SCLK P101 70165319 MAIN TO DIS EP-B HIFI / CTL(+) HIFI / CTL(+) DIS TO MAIN HIFI / CTL(-) HIFI / CTL(-) REMOTE IN HiFi SA...

[Page 96: Block Diagrams](#)

7. BLOCK DIAGRAMS 7-1. Power Supply Block Diagram T802 C832 RECTIFIER D820 MB 24V SMOOTHING C826 C805 RECTIFIER D826 D802 D804 C806 R803 VKK-26V D803 D805 SMOOTHING L801 D806 ,C813 C827 RECTIFIER D827 RECTIFIER EVER 37V SNUBBER SMOOTHING SMOOTHING C825 D825 F1 (+) RECTIFIER...

[Page 97: Pif Block Diagram](#)

7-2. PIF Block Diagram S001 CH SW 3 IN 1 TUNER ANT IN ANT OUT VIDEO SIGNAL H001 TMDH2-032A AUDIO SIGNAL ANT IN RF OUT AUDIO IN 4.5MHz OSC CH SW RF MODULATOR MB(5V) SPLITER HA11560FP RF SW CONTROL RF VIDEO IN RESONATOR VIDEO IN TO VIDEO...

[Page 98: Kdb Display Block Diagram](#)

7-3. KDB Display Block Diagram ZX01 25U39149SAN F(-) 6G 5G 4G 3G 2G 1G S16S15S14S13S12 S11S10 S9 S8 S7 S6 S5 S4 S3 S2 S1 F(+) 9 10 17 18 19 20 21 22 23 24 25

26 27 28 29 30 31 32 34 35 F(+) F(-)

[Page 99](#) ECO / ECO LED POWER LED Seg 1 Seg 2 Seg 3 Seg 4 Seg 5 IC501 Seg 6 Seg 7 TMP93CU76 Seg 8 Seg 9 Seg 10 MAIN Seg 11 Seg 12 MICROCOMPUTER Seg 13 Seg 14 KEY INPUT 2 KEY INPUT 1 B3 / B4 (Shuttle) B1 / B2 (Shuttle)

[Page 100](#) - - - - - 2b,2c - - - - - 3b,3c Fig. 7-3-3...

[Page 101: Eds Block Diagram](#)

7-4. EDS Block Diagram CSYNC VIDEO IN IC301 Z86131 Buffer HSYNC M.SYNC Dual Logic Clamp Lines 1 Drive COMP SYNC & MUX O / S Buffer SYNC Slicer Control Data Loop Slicer Filter V Lock Vss(A) Digital Data CLK II Logic Recovery Line &...

[Page 102](#) 7-5. Servo/Logic Block Diagram IC501 TMP93CU76 EVER +5V MAIN MICROPROCESSOR BU 5.0V EVER +5V D.Vcc AD REF IC505 DRIVE EVER +5V EVER +5V PST7025MT DX32 DX31 RESET IC BU 5.0V QX30, QX31 RMT OUT REC INHIBIT SW S602 REC INH START SENSOR INPUT...

[Page 103](#) 7-5-1. IC501 Main Microcomputer Terminal Function TEST PIN TEST3(ALE) C.SYNC COMPOSITE SYNC INPUT(V SYNC DETECT) NO CONNECTION C.FGA IN CAPSTAN AMPLIFIED FG.A INPUT TV / VCR SWITCH TV / VCR C.FGB IN CAPSTAN AMPLIFIED FG.B INPUT NO CONNECTION POWER GOOD POWER A.C CLOCK INPUT CLOCK OUTPUT SIGNAL TO OSD IC OSD SIO CLK...

[Page 104](#) 7-5-2. IC501 Main Microcomputer Output Polarity IC501 MAIN MICROCOMPUTER OUTPUT POLARITY MODE Un- REMOTE MAIN Pin. SLOT SLOT Load STAND PLAY STILL SLOW Act. Load STOP PAUSE POWER POWER -ing -BY SP SLP SP SLP SP SLP SP SLP SP SLP SP SLP -ing...

[Page 105](#) 7-5-3. Logic Mode Shift Table PAUSE / COUNTER REMOCON MAIN COUNTER TAPE TAPE STOP PLAY SLOW EJECT INDEX Current STILL / TIMER POWER POWER RESET START Mode POWER POWER SHORT SHORT STOP - EJECT SEARCH POWER POWER - EJECT STOP POWER POWER REVIEW...

[Page 106](#) 7-6. Video and Conventional Audio Block Diagram PLAYBACK Y SIGNAL PLAY AUDIO Q206 REC AUDIO PLAY VIDEO REC VIDEO MAIN DE-EMPH SYNC W / C O / C C TRAP MAIN EMPH CLAMP VIDEO IN NL-EMPH DE-EMPH DELAY PV / PH REC FM FM-MOD CLAMP...

[Page 107](#) 7-7. Hi-Fi Audio Block Diagram TUNER AUDIO (L) TO PIF TUNER AUDIO (R) I / O I C BUS DECODER MEMORY DECODER MOD AUDIO INPUT SELECTOR SDA1 LINE IN2 (L) BPF ADJ SCL1 LINE IN2 (R) HIFI ENV SERVO / LOGIC HIFI HIFI DET OUT OUTPUT...

[Page 108](#) 7-7-1. Audio Level Chart HIFI AUDIO LEVEL CHART [mV(rms)] [dB] (-8) -10 77.5 -20 (REC / PLAY) 24.5 -30 7.75 -40 2.45 -50 INPUT INPUT PLAY LINE LINE 400Hz SELECTOR OUTPUT SYSTEM INPUT SYSTEM SYSTEM OUTPUT mV(rms) Fig. 7-7-2 CONVENTIONAL AUDIO LEVEL CHART [mV(rms)] [dB] (-8)

[Page 109](#) 8. CIRCUIT DIAGRAMS 8-1. Waveform Power Selvo/Logic Video/Audio Q801, COLLECTOR H001, Pin 1 A-15 ICD01, Pin 16 C-18 IC501, Pin 6 IC501, Pin 50 IC506, Pin 3 IC201, Pin 15 IC201, Pin 59 IC920, Pin 19 K-10 I-12 H-15 CTL. AMP SCAN1 AUDIO IN SCL1...

[Page 110](#) 8-2. Circuit Diagram Divided Circuit Diagram (For Printing) Note PLAY AUDIO [V] : EE SERVO MODE AUDIO MODE meaning "KETSU" AUDIO (V) : PLAY JP212 LOCATION PLAY LOCATION PLAY (20) JP211 JP253 "Not used". PLAY VIDEO : REC (15) (10) VIDEO V001 JP225...

[Page 111](#) 8-2. Circuit Diagram JP212 (20) [3.25] (3.27) R210 Q219 [2.33] 3.27 KETSU (2.33) Q211 2.33 C246 2SC2712Y R238 KETSU BUFFER KETSU R212 L207 68μ JP201 (10) R248 [1.67] R211 100R (1.67) 1.5k L206 47μ C276 1.67 JP203 (12.5) C210 C244 R213 R227 2μ...

[Page 112](#) JP212 JP211 JP253 (20) (15) (10) JP225 D202 L205 (7.5) (10) R243 KETSU 10μ Q214 KETSU KETSU Q215 KETSU KETSU JP238 JP277 (15) (7.5) C203 C202 D201 47μ F0.01μ KETSU R203 JP219 JP234 (7.5) C246 KETSU KETSU JP233 (10) R204 L207 68μ...

[Page 113](#) Note meaning "KETSU" "Not used". V001 EARTH PLATE P102 R104 3 IN 1 TUNER

CH SW R105 H001 TMDH2 C202 D201 (3CH) F0.01μ S001 KETSU RF VIDEO IN JP287 SSSF12 (4CH) ANT IN RF OUT R203 AUDIO IN 23344082 (10) 4.5M OSC CH SW R204...

[Page 114](#) [V] : EE PLAY AUDIO SERVO MODE AUDIO MODE meaning "KETSU" (V) : PLAY AUDIO LOCATION PLAY LOCATION PLAY : REC used". PLAY VIDEO VIDEO - - - IC502 14.1 14.1 JP305 (20) 14.1 14.1 IC503 14.1 14.1 JP306 (20) IC920 JP010 (20)

[Page 115](#) JP202 JP246 (12.5) (7.5) ON / OFF5V ON / OFF5V ICL01 TC90A25F-410 Csync IN CL12 F0.01μ KETSU VIDEO IN D GND SERVO A.Vcc LOCATION CL13 BLANK CL11 KETSU KETSU VIDEO OUT D.Vcc Q510 RL11 A GND 1.8k RL13 S.CLK P1 OUT S.DATA IN Q511 1S5131...

[Page 116](#) LA7116 P246 SERVO MODE 7.5) C545 LOCATION PLAY 47μ16V C-Ref VCC2 32 33 ON / OFF5V R531 4.7k Q515 CR- C547 12.9 11.7 11.7 Q516 C548 R568 R510 C520 RN1402 R532 R511 22μ35V 1.8k 1μ50V Q515 2.2k 1 / 6w SWITCH 4.7k DH11...

[Page 117](#) AUDIO HIFI C534 PROCESSOR 10μ25V MODE C532 PLAY B0.1μ R522 C533 12.9 11.7 11.7 B0.1μ C531 HW300B(F)-15 R593 B0.1μ Z662 4.7k IC503 TB6515AP DRUM MOTOR DRIVER Z662A C940 HOLD HALLSEN HALL SENSOR 10μ16V EVER 5V END SENSOR JP904 REC FM R572 (7.5) ON / OFF5V...

[Page 118](#) C971 22μ16V R926 C922 R924 1μ50V R927 IC501 R925 C923 1μ50V (maxi) RF92 CF90 1μ50V RF90 - - - - - CF91 1μ50V RF93 RF91 (maxi) C929 ON / OFF+9V 10μ16V VIDEO MODE - - - LOCATION PLAY C942 C964 100μ16V F0.1μ...

[Page 119](#) 9. PC BOARDS 9-1. Main PC Board P990 (UK01) S001 R801 C801 P801 Q870 D203 P506 D801 D204 C844 D870 C223 CL11 L202 R870 W101 C270 L206 D803 RL21 T801 X401 C803 L207 C248 C113 C804 L209 L101 CF03 C103 LF01 C002 D804...

[Page 120](#) 9-2. FCB PC Board (UK03) CK99 SK21 WK11 SK22 Fig. 9-2-1 9-3. JSB PC Board (UK03) Fig. 9-3-1...

[Page 121](#) General Descriptions Adjustment Procedures Servicing Diagrams Servicing Diagrams General Descriptions Adjustment Procedures SECTION 4 PARTS LIST 1. SAFETY PRECAUTION 2. NOTICE 3. ABBREVIATIONS 3-1. Integrated Circuit (IC) 3-2. Capacitor (Cap) 3-3. Resistor (Res) 4. EXPLODED VIEWS 4-1. Packing Assembly 4-2. Cabinet Assembly 4-3.

[Page 122](#) 1. SAFETY PRECAUTION The parts identified by ! () mark are critical for safety. Replace only with part number specified. The mounting position of replacement is to be identical with originals. The substitute replacement parts which do not have the same safety characteristics as specified in the parts list may create shock, fire or other hazards.

[Page 123](#) 4. EXPLODED VIEWS A703 4-1. Packing Assembly A702 P801 Y101 Y102 Y103 Y107 Y111 Y112 Y113 A701 Fig. 4-1-1 4-2. Cabinet Assembly A104 A104J UK02 A101D A101H A106A A102C UK03 A101 A106 Fig. 4-2-1...

[Page 124](#) 4-3. Chassis Assembly B001A A105 UZ01 B603B B603C B603 Fig. 4-3-1...

[Page 125](#) 4-4. Mechanism Assembly (1) G051 G050 G001 G101A G101 U190 U190A G104 G102 G053 G661 G534 G536 G663 G532 G530 G540 G052 B256 G666 G538 B254 G428 G510 G555 G458 G480 B239 G420 G450 B474 K546 G527 G520 B478 B473 B488 B500 B458...

[Page 126](#) 4-5. Mechanism Assembly (2) K544 K490 K544 K502 K542 K350 K330 B248 K340 K250 K140 K110 K248 B570 B410 K240 K544 K180 B444 B446 K530 B448 B440 B238 B452 K470 B560 KC02 K224 K221 K200 K219 G546 G542 Fig. 4-5-1...

[Page 127](#) LOCATION PART NUMBER NUMBER DESCRIPTION - MECHANICAL PARTS - ! A101 70884696 Front Panel A101D 70896138 Cassette Door A101H 70356358 Spring A102C 70868910 Door ! A104 70814541 Top Cover A104J 70391703 Screw 3x6mm A105 70896091 Bracket A106 70885253 Knob A106A 70391356 Screw 3x10mm...

[Page 128](#) LOCATION PART NUMBER NUMBER DESCRIPTION ! Y101 70971857 Owner's Manual English/French Y112 70148430 Remote Control Unit Y113 70168298 RF Cable...

[Page 129](#) LOCATION PART NUMBER NUMBER DESCRIPTION - ELECTRICAL PARTS - UK02
70185130 PC Board Assy - RESISTORS - RF02 24872750 Res,Chip 75ohm J 1/16W RJK91
24000824 Chip Jumper - MISCELLANEOUS - P998 70163114 Phono Jack P999 70163100 Phono
Jack PK99 70163113 Phono Jack SK21 70145487...

[Page 130](#) LOCATION PART NUMBER NUMBER DESCRIPTION QL11 A6014040 Transistor,Chip
RN2404 QL12 A6004040 Transistor,Chip RN1404 QX30 A6004010 Transistor,Chip RN1401 QX31
A6325549 Transistor 2SC2236-Y QX32 A6004010 Transistor,Chip RN1401 - DIODES - D001
23316753 Diode,Zener MTZJ33A D501 A7152750 Diode,Chip 1SS226 D503 23115537 Diode
1SS131 D506 23118486 Diode...

[Page 131](#) LOCATION PART NUMBER NUMBER DESCRIPTION C104 24781180 Cap,Chip 18pF J
50V C106 24630025 Cap,Electrolytic 10MF M 50V C107 24815103 Cap,Chip 0.01MF K 50V C108
24092178 Cap,Chip 0.1MF K 25V C109 24630034 Cap,Electrolytic M 50V C110 24814103
Cap,Chip 0.01MF Z 50V C111 24287104 Cap,Chip...

[Page 132](#) LOCATION PART NUMBER NUMBER DESCRIPTION C518 24630034 Cap,Electrolytic
M 50V C519 24781101 Cap,Chip 100pF J 50V C520 24630034 Cap,Electrolytic M 50V C521
24781101 Cap,Chip 100pF J 50V C522 24794470 Cap,Electrolytic 47MF M 16V C523 24815102
Cap,Chip 1000pF K 50V C524 24815102 Cap,Chip 1000pF...

[Page 133](#) LOCATION PART NUMBER NUMBER DESCRIPTION C844 24793220 Cap,Electrolytic
22MF M 10V C920 24797478 Cap,Electrolytic 0.47MF M 50V C921 24797478 Cap,Electrolytic
0.47MF M 50V C922 24797010 Cap,Electrolytic M 10V C923 24797010 Cap,Electrolytic M 10V
C926 24797478 Cap,Electrolytic 0.47MF M 50V C928 24794100 Cap,Electrolytic 10MF...

[Page 134](#) LOCATION PART NUMBER NUMBER DESCRIPTION R202 24872750 Res,Chip 75ohm J
1/16W R203 24366681 Res,Carbon 680ohm J 1/6W R204 24366681 Res,Carbon 680ohm J 1/6W
R205 24872101 Res,Chip 100ohm J 1/16W R210 24872102 Res,Chip 1kohm J 1/16W R211
24872152 Res,Chip 1.5kohm J 1/16W R212 24872101 Res,Chip...

[Page 135](#) LOCATION PART NUMBER NUMBER DESCRIPTION R537 24872103 Res,Chip 10kohm
J 1/16W R538 24366103 Res,Carbon 10kohm J 1/6W R539 24872103 Res,Chip 10kohm J 1/16W
R540 24872103 Res,Chip 10kohm J 1/16W R546 24366102 Res,Carbon 1kohm J 1/6W R547
24366102 Res,Carbon 1kohm J 1/6W R548 24872472 Res,Chip...

[Page 136](#) LOCATION PART NUMBER NUMBER DESCRIPTION R922 24872272 Res,Chip
2.7kohm J 1/16W R923 24872272 Res,Chip 2.7kohm J 1/16W R924 24872332 Res,Chip 3.3kohm
J 1/16W R925 24872332 Res,Chip 3.3kohm J 1/16W R926 24872272 Res,Chip 2.7kohm J 1/16W
R927 24872272 Res,Chip 2.7kohm J 1/16W R928 24872273 Res,Chip...

[Page 137](#) LOCATION PART NUMBER NUMBER DESCRIPTION S602 70145505 Leaf Switch 1C1P
S610 70145494 Switch,Cam SX01 70145487 Push Switch SX02 70145487 Push Switch SX04
70145487 Push Switch SX08 70145487 Push Switch SX10 70145487 Push Switch SX11
70145487 Push Switch ! T801 23211691 Line Filter TRF3213 ! T802...

[Page 138](#) 438B ALEXANDRA ROAD BLOCK B#06-01 ALEXANDRA TECHNOPARK SINGAPORE
119968...