



# Toshiba ML-EM34P Instruction Manual



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55

--

•

[Table of Contents](#)

•

Troubleshooting

•

Bookmarks

--



## Quick Links

[1 Setting up Your Oven](#)

[Download this manual](#)



User Manual of Product 1:

TOSHIBA ML-EM34P(SS) Smart Countertop Microwave,  
Sensor Reheat, Works With Alexa & Remote Control,  
Kitchen

Essentials, Mute Function&ECO; Mode, 1100W, 1.3 Cu  
Ft,

With 12.4" Turntable, Stainless Steel

User Manual of Product 2:

# TOSHIBA AC25CEW-BS Large 6-Slice Convection Toaster Oven Countertop, 10-In-One with Toast, Pizza and Rotisserie, 1500W, Black Stainless Steel, Includes 6 Accessories

[Table of Contents](#)

[Next Page](#)

- 1
- 2
- 3
- 4
- 5

## Chapters

Microwave Oven Instruction Manual 3

Toaster Oven Instruction Manual Ac25Cew-Bs 43

## Related Manuals for Toshiba ML-EM34P

[Microwave Oven Toshiba ML-EM34PSS Instruction Manual](#)

(68 pages)

[Microwave Oven Toshiba ML-EM34P Instruction Manual](#)

(40 pages)

[Microwave Oven Toshiba ML-EM34P Instruction](#)

(21 pages)

[Oven Toshiba AC25CEW-BS Instruction Manual](#)

(55 pages)

[Microwave Oven Toshiba ML-EM45P Instruction](#)

(21 pages)

[Microwave Oven Toshiba ML-EM45P Instruction Manual](#)

(40 pages)

[Microwave Oven Toshiba ML-EM23PSS Instruction Manual](#)

(29 pages)

[Microwave Oven Toshiba ML-EM23P Instruction Manual](#)

(40 pages)

[Microwave Oven Toshiba ML-EM45PIT Instruction Manual](#)

Microwave solo oven (40 pages)

[Microwave Oven Toshiba ML-EM45PITBS Instruction Manual](#)

Microwave solo oven (26 pages)

[Microwave Oven Toshiba ML-EM62P Instruction Manual](#)

(56 pages)

[Microwave Oven Toshiba ML-EM62P Instruction Manual](#)

(84 pages)

[Microwave Oven Toshiba ML-EM31P\(SS\)/CA Instruction Manual](#)

Microwave solo oven (28 pages)

[Microwave Oven Toshiba MM-EM25P\(WH\) Instruction Manual](#)

(24 pages)

[Microwave Oven Toshiba ML-EM42P Instruction Manual](#)

(28 pages)

[Microwave Oven Toshiba ML-EM34PF Instruction Manual](#)

34l microwave oven (40 pages)

## Summary of Contents for Toshiba ML-EM34P

[Page 1](#) User Manual of Product 1: TOSHIBA ML-EM34P(SS) Smart Countertop Microwave, Sensor Reheat, Works With Alexa & Remote Control, Kitchen Essentials, Mute Function&ECO; Mode, 1100W, 1.3 Cu Ft, With 12.4" Turntable, Stainless Steel User Manual of Product 2: TOSHIBA AC25CEW-BS Large 6-Slice Convection Toaster...

[Page 2](#) MICROWAVE OVEN INSTRUCTION MANUAL ML-EM34P(SS) Please review this instruction manual before operating.

## [Page 3: Table Of Contents](#)

CONTENTS PRODUCT SAFETY Precautions to avoid possible exposure to excessive microwave energy .....EN-01 Important safety instructions .....EN-03 Grounding instructions .....EN-07 Radio interference .....EN-09 Utensils .....EN-10 Materials you can use in microwave oven .....EN-11 Materials can not be used in microwave oven .....EN-13 PRODUCT SETTING Setting up your oven .....

[Page 4](#) 9. Reheat .....EN-27 10. Multi-section cooking .....EN-27 11. Inquiring function .....EN-28 12. Lock function for children .....EN-28 13. Eco function .....EN-29 14. Mute function .....EN-29 Cleaning .....EN-31 MAINTENANCE Trouble shooting .....EN-33 One year limited warranty .....EN-34 BEFORE OPERATING THIS PRODUCT, READ, UNDERSTAND, AND FOLLOW THESE INSTRUCTIONS.

## [Page 5: Product Safety](#)

PRODUCT SAFETY PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY (a). Do not attempt to operate this oven with the door open since open door operation can result in harmful exposure to microwave energy. It is important not to defeat or tamper with the safety interlocks.

[Page 6](#) SPECIFICATIONS MODEL ML-EM34P(SS) RATED VOLTAGE 120V~ 60Hz RATED INPUT POWER(MICROWAVE) 15 0W RATED OUTPUT POWER(MICROWAVE) 1100W OVEN CAPACITY 1.3 cu.ft. TURNTABLE DIAMETER 12.4 inch EXTERNAL DIMENSIONS 20.4x16.6 x12.4inch NET WEIGHT Approx. 35.05lbs All pictures in this manual are for illustrative purposes only; these may be...

## [Page 7: Important Safety Instructions](#)

IMPORTANT SAFETY INSTRUCTIONS To reduce the risk of burns, electric shock, fire, injury to persons or exposure to excessive microwave oven energy when using your appliance, follow basic WARNING safety precautions, including the following: Read all instructions before To reduce the risk of fire in using the appliance.

[Page 8](#) IMPORTANT SAFETY INSTRUCTIONS nonabrasive soaps, or Do not leave paper detergent applied with a products, cooking sponge or soft cloth. utensils, or food in the cavity when not in use. As with any appliance, close supervision is necessary when used by children.

[Page 9](#) IMPORTANT SAFETY INSTRUCTIONS To reduce the risk of injury to persons: 1. Do not overheat the liquid. 2. Stir the liquid both Use this appliance only before and halfway for its intended use as through heating it. described in the manual. 3.

[Page 10](#) IMPORTANT SAFETY INSTRUCTIONS use this oven near water, Do not immerse cord or for example, near a kitchen plug in water or any other sink, in a wet basement, liquid. near a swimming pool, or similar location. Do not let cord hang over edge of table or counter.

## [Page 11: Grounding Instructions](#)

GROUNDING INSTRUCTIONS This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance is equipped with a cord having a grounding wire with a grounding plug.

[Page 12](#) GROUNDING INSTRUCTIONS Electric Shock Hazard: Improper use of the grounding can result in electric shock. Do not plug into an outlet until appliance is properly installed and grounded. 1. A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.

## [Page 13: Radio Interference](#)

RADIO INTERFERENCE 1. Operation of the microwave oven may cause interference to your radio, TV or similar equipment. 2. When there is interference, it may be reduced or eliminated

by taking the following measures: (1). Clean door and sealing surface of the oven. (2).

### [Page 14: Utensils](#)

UTENSILS Personal Injury Hazard: Tightly-closed utensils could explode. Closed containers should be opened and plastic pouches should be pierced before cooking. See the instructions on "Materials you can use in microwave oven " or "Materials can not be used in CAUTION microwave oven."...

### [Page 15: Materials You Can Use In Microwave Oven](#)

MATERIALS YOU CAN USE IN MICROWAVE OVEN UTENSILS REMARKS Follow manufacturer's instructions. The bottom of browning dish must be at least 3/16 inch (5mm) above the turntable. Incorrect usage may cause Browning dish the turntable to break. Microwave-safe only. Follow manufacturer's instructions.

[Page 16](#) MATERIALS YOU CAN USE IN MICROWAVE OVEN UTENSILS REMARKS Microwave-safe only. Follow the manufacturer's instructions. Should be labeled "Microwave Safe". Some plastic containers soften, as the food inside gets hot. "Boiling bags" and tightly closed plastic bags should be Plastic slit, pierced or vented as directed by package.

### [Page 17: Materials Can Not Be Used In Microwave Oven](#)

MATERIALS CAN NOT BE USED IN MICROWAVE OVEN UTENSILS REMARKS May cause arcing. Transfer food into microwave-safe dish. Aluminum tray May cause arcing. Transfer food into microwave-safe dish. Food carton with metal handle Metal shields the food from microwave energy. Metal trim may cause arcing.

### [Page 18: Product Setting](#)

PRODUCT SETTING SETTING UP YOUR OVEN NAMES OF OVEN PARTS AND ACCESSORIES Remove the oven and all materials from the carton and oven cavity. Your oven comes with the following accessories: Glass Tray (Can be used under all functions) Instruction Manual A.

### [Page 19: Setting Up Your Oven](#)

SETTING UP YOUR OVEN TURNTABLE INSTALLATION Cleaning the cooking compartment and putting the turntable in place. For new installations, make sure all packaging and shipping tape has been removed from the turntable shaft. Before using the appliance to prepare food for the first time, you will need to put the turntable in place correctly.

[Page 20](#) COUNTERTOP INSTALLATION Remove all packing material and accessories. Examine the oven for any damage such as dents or broken door. Do not install if oven is damaged. Cabinet: Remove any protective film found on the microwave oven cabinet surface. Do not remove the light brown Mica cover that is attached to the oven cavity to protect the magnetron.

[Page 21](#) 4. Set up Echo with Alexa app (Refer to Alexa App Instruction) Link MSmartLife account to Alexa a. Tap "Toshiba iMicrowave" in the Skills & Games, then search. Select and tap [ENABLE] to enable the Toshiba iMicrowave. b. You will be redirected to the account link page. Type in your MSmartLife account and password, then tap [Login] to link your MSmartLife account.

### [Page 22: Instruction For Use](#)

INSTRUCTION FOR USE BEFORE USING FOR THE FIRST TIME The appliance may produce unpleasant odors when it is used for the first time. This section tells you what you need to do before using your microwave to prepare food for the first time.

### [Page 23: Operation](#)

OPERATION CONTROL PANEL AND FEATURES EN-19...

### [Page 24: Clock Setting](#)

You can use your microwave oven without setting it up for Alexa control. However, we highly recommend using your microwave oven with Alexa control to unlock its full potential. 1. CLOCK SETTING When the microwave oven is plugged into a outlet, the oven will display " 0:00 " Press "...



## [Page 25: Microwave Cook](#)

When the kitchen time arrives, clock indicator will go out. The buzzer will ring one time. At the end of cooking, the bee rings and returns to standby status. • Kitchen Timer is a timer. That is to say it possesses the function of alarming clock. NOTE 3.

[Page 26](#) LEVEL POWER DISPLAY Example: to cook the food with 50% microwave power for 15 minutes. • Press "Cook Time/Clock" twice. "00:00" displays. • Press "1", "5", "0", "0" in order. • Press "POWER LEVEL" once, then press "5" to select 50% microwave power.

## [Page 27: Speedy Cooking](#)

"Alexa, add X to the microwave." • When your microwave is in use, you can ask it to cook for additional time by saying, "Alexa, add X to the microwave," where X is the amount of time you'd like to add. For example, to add 2 minutes to the cooking time while the microwave is already running, say "Alexa, add 2 minutes to the microwave."

## [Page 28: Weight Defrost Function](#)

At the end of cooking, the bee rings and returns to standby status. • Under microwave and time defrost states, press "START/30SEC." button to increase cooking time by 30 seconds. • Under sensor menu cooking and weight defrost state, time cannot be added NOTE by pressing "..."

## [Page 29: Time Defrost Function](#)

6. TIME DEFROST FUNCTION Press "TIME DEFROST", LED will display "dEF2". Press numerical buttons to input defrost time to be defrosted. Input the time ranged is between 0:01~99:99. Press "START/30SEC." to start defrosting. The default microwave power is PL3. The power cannot be adjusted. At the end of cooking, the bee rings and returns to standby status.

## [Page 30: Potato](#)

TIMES( PRESS "POPCORN") WEIGHT DISPLAY Once 2.75 Oz 2.75 Twice 3.2 Oz Popcorn "Alexa, microwave 1.5 ounces of popcorn." • To microwave popcorn, say "Alexa, microwave X ounces of popcorn". Your microwave oven will determine the time to cook your popcorn appropriately. For example, to microwave oven 2.2 ounces of popcorn, say "Alexa, microwave 2.2 ounces of popcorn".

## [Page 31: Reheat](#)

9. REHEAT Press "REHEAT", LED will display "SC-1", " " are light. Press "START/30SEC." to cook, LED flashing display "SC01", humidity sensing menu logo " " flashing display, waiting for sensing, countdown display remaining cooking time. At the end of cooking, the bee rings and returns to standby status.

## [Page 32: Inquiring Function](#)

• Press "POWER LEVEL" once. • Then press number button "6" to set 60% microwave power. • Press "START/30SEC." start cooking. • Auto menu and reheat menu cannot be set as one of the multi-section. • When microwave cooking is the second part of multiple cooking, you must NOTE press the cooking clock.

## [Page 33: Eco Function](#)

13. ECO FUNCTION Dump screen: In standby state, press Stop/Cancel key, buzzer, screen extinguished, enter ECO mode. Awakening: In ECO mode, opening the furnace door or pressing any key can awaken the display and enter the standby state; In ECO mode, the first button pressing is to wake up the display.

[Page 34](#) meat (SC- 7) Alexa, reheat meat. Fresh Vegetable (SC- 8) Alexa, reheat the fresh vegetable. Frozen Vegetable (SC- 9) Alexa, reheat frozen vegetable. Frozen Entree (SC-A) Alexa, reheat frozen entree. Pasta(no cover) (SC- b) Alexa, reheat pasta. EN-30...

## [Page 35: Cleaning](#)

CLEANING With good care and cleaning, your appliance will retain its appearance and remain fully functioning for a long time to come. We will explain here how you should correctly care for and clean your appliance. • Scratched glass in the appliance door may develop into a crack. Do not use a glass scraper, sharp or abrasive cleaning aids or detergents.

**Page 36** APPLIANCE FRONT PLATE Hot soapy water: Clean using a dish cloth and then dry with a soft cloth. Remove splashes and patches of limescale, grease, starch and albumin immediately. Corrosion can form under these patches or splashes. Do not use glass cleaners or metal or glass scrapers for cleaning.

Page 37: Maintenance

**MAINTENANCE TROUBLE SHOOTING** Check your problem by using the chart below and try the solutions for each problem. If the microwave oven still does not work properly, contact the nearest authorized service center.

TROUBLE	POSSIBLE CAUSE	POSSIBLE REMEDY
a. Electrical cord for oven is not a.		

Page 38: One Year Limited Warranty

If service is required during the warranty period, properly pack your unit. We recommend using the original carton and packing materials. If additional assistance is needed, please contact customer assistance at: [customer care@us.toshiba-lifestyle.com](mailto:customer care@us.toshiba-lifestyle.com) 855-204-5313 Midea America Corp. expressly disclaims all responsibility for consequential damages or incidental losses caused by use of the appliance.

[Page 41](#) Details Matter Customercare@us.toshiba-lifestyle.com 855-204-5313...

Page 42 TOASTER OVEN INSTRUCTION MANUAL AC25CEW-BS...

**Page 43** CONTENTS IMPORTANT SAFEGUARDS BASIC SAFETY PRECAUTIONS.....EN-3  
BEFORE FIRST USE..... EN-6 PRODUCT INSTRUCTION NAMES OF  
PARTS.....EN-7 OPERATION HOW TO USE.....? ? ? ? ? ? ? ? .....? ? ? ? ? . ? ? ? ?  
? ..EN-8 FUNCTION INSTRUCTION.....? ? ? ? ? .

[Page 44: Important Safeguards](#)

**IMPORTANT SAFEGUARDS BASIC SAFETY PRECAUTIONS SAFETY WARNING** When using electrical appliance, basic safety precautions should always be followed, including the following: 1. Read all instructions. 2. Do not touch hot surfaces. Use handles or knobs. 3. To protect against electrical shock do not immerse cord, plugs, or (state specific part or parts in question) in water or other liquid.

**Page 45** BASIC SAFETY PRECAUTIONS SAFETY WARNING 13. Do not use appliance for other than intended use. 14. Use extreme caution when removing tray or disposing of hot grease. 15. Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, creating parts, creating a risk of electric shock.

**Page 46** IMPORTANT SAFEGUARDS BASIC SAFETY PRECAUTIONS SAFETY WARNING 22.  
Caution-To ensure continued protection against risk of electric shock, connect to properly grounded outlets only. 23. Remove plug from outlet when the appliance is not in use, before putting on or taking off parts, and before cleaning. Allow to cool before handling.

## Page 47: Before First Use

**BEFORE FIRST USE** 1. Remove all accessories and shipping materials packed inside the Oven. 2. Wash the Rack and Pan in warm soapy water. Wipe the inside of the Oven with a damp cloth or sponge. Blot dry with paper towels to be sure the unit is dry before using.

[Page 48: Product Instruction](#)

PRODUCT INSTRUCTION NAMES OF PARTS When using electrical appliance, basic safety precautions should always be followed, including the following: Housing Door handle Function knob Stop/Start button Temperature knob Timer knob Baking Pan Baking Rack Crumb Tray Rack clamp Helper Handle Rotisserie Kit EN-7...

[Page 49: How To Use](#)

HOW TO USE CAUTION THE OVEN SURFACES ARE HOT DURING AND AFTER USE. GENERAL INSTRUCTIONS 1. Place the Baking Rack in position that will accommodate the height of the food to be cooked. 2. The food must be put into the baking pan to avoid the fire danger that caused by the accumulation of food chipping on the heating pipes.

## [Page 50: Function Instruction](#)

OPERATION FUNCTION INSTRUCTION OVEN FUNCTION COOKING PRESET TEMP RANGE PRESET TIME TIME RANGE TEMP FUNCTION Toast Fixed Temp Fixed Time 450 °F Bake 0.01~2Hour 30min Broil 350 °F Pizza 6 inch 7min 150 °F~450 °F Pizza 9 inch 450 °F 8.5min 1min~30min Pizza 12 inch...

[Page 51](#) FUNCTION INSTRUCTION BROIL PIZZA Preset temperature : 350 °F Preset temperature : 450 °F BROIL PIZZA Temp range : 150 °F- 450 °F Temp range : 150 °F- 450 °F Preset time : 30min Preset time : 30min Time range : 0.01~2 Hour Time range : 0.01~2 Hour NOTE Do not preheat when using this function NOTE Do not preheat when using this function...

## [Page 52: Rotisserie Function](#)

OPERATION FUNCTION INSTRUCTION ROTISSERIE FUNCTION 1. Remove the Baking Rack from the oven and set aside. 2. Place the Baking Pan in the lowest level of the oven. This will catch all the drippings from the food that is on the Rotisserie Forks as it cooks.

[Page 53](#) FUNCTION INSTRUCTION 10. Gently remove the right pointed side of the Rotisserie Forks from the Rotisserie Socket and remove the food on the forks out of the oven. 11. Place the food on a heat safe plate or dish when you have removed from the oven.

## [Page 54: Care And Cleaning](#)

OPERATION CARE AND CLEANING 1. Before cleaning, unplug the toaster oven and allow it to cool completely. 2. Wash all the attachments with mild, soaped water including the Baking rack and the Baking pan. 3. Do not use abrasive cleansers, scrubbing brushes and chemical cleaner as this will cause damage to the non-stick coating of baking pan.

## [Page 55: One Year Limited Warranty](#)

If service is required during the warranty period, properly pack your unit. We recommend using the original carton and packing materials. If additional assistance is needed, please contact customer assistance at: [customer care@us.toshiba-lifestyle.com](mailto:customer care@us.toshiba-lifestyle.com) 855-204-5313 Midea America Corp 5 Sylvan Way, Parsippany, NJ 07054 Midea America Corp.

This manual is also suitable for:

[MI-em34pssAc25cew-bs](#)