



# Disabling Or Enabling The Touchpad

- Toshiba S300 EZ1514 - Satellite Pro
- Core 2 Duo 2.1 GHz User Manual

Toshiba user's guide for satellite s300/s300m (windows vista)



1  
2  
3  
4  
5  
6  
7  
8  
9  
10  
11  
12  
13  
14  
15  
16  
17  
18

19  
20  
21  
22  
23  
24  
25  
26  
27

Table Of Contents

28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167

168  
169  
170  
171  
172  
173  
174  
175  
176  
177  
178  
179  
180  
181  
182  
183  
184  
185  
186  
187  
188  
189  
190  
191  
192  
193  
194  
195  
196  
197  
198  
199  
200  
201  
202  
203  
204  
205  
206  
207  
208  
209  
210  
211  
212  
213  
214  
215  
216  
217



218  
219  
220  
221  
222  
223  
224  
225  
226  
227  
228  
229  
230  
231  
232  
233  
234  
235  
236  
237  
238  
239  
240  
241  
242



•

[Table of Contents](#)

•

## Bookmarks





# 218

## Hot Keys/TOSHIBA Cards

---

*Hot key functions*

### Disabling or enabling the TouchPad™

or  
Fn  
+



This TOSHIBA Card or hot key enables/disables the

TouchPad.

For more information on using the TouchPad, see

["Disabling or enabling the TouchPad™" on page](#)


Selecting this Card or pressing the hot key displays the following options:

*(Sample Image) Disable or Enable TouchPad options*

To enable the TouchPad, select

To disable the TouchPad, select

72.



[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)



1

...

217

218

219

220

## Related Manuals for Toshiba S300 EZ1514 - Satellite Pro - Core 2 Duo 2.1 GHz

[Laptop Toshiba Satellite Pro S300 Maintenance Manual](#)

(464 pages)

[Laptop Toshiba S300-EZ1511 User Manual](#)

S300-ez1511 user's guide (251 pages)

[Laptop Toshiba TECRA A10 Series User Manual](#)

(246 pages)

[Laptop Toshiba PTMB3U-00X00X User Manual](#)

User manual (242 pages)

[Laptop Toshiba TECRA A10 Satellite Pro S300 Series User Manual](#)

(242 pages)

[Laptop Toshiba TECRA A10/S10/M10/SATELLITEPRO S300 TECRA S10 User Manual](#)

Vizio mouse user manual (240 pages)

[Laptop Toshiba SATELLITEPRO S300 User Manual](#)

Toshiba laptop user manual (56 pages)

[Laptop Toshiba Satellite Pro S300-EZ1511 Specifications](#)

Toshiba satellite pro s300-ez1511: specifications (5 pages)

[Laptop Toshiba Satellite Pro S300-S2503 Specifications](#)

Toshiba satellite pro s300-s2503: specifications (5 pages)

[Laptop Toshiba Satellite Pro S300-EZ1512 Specifications](#)

Toshiba satellite pro s300-ez1512: specifications (5 pages)

[Laptop Toshiba Satellite Pro S300-EZ1513 Specifications](#)

Toshiba satellite pro s300-ez1513: specifications (5 pages)

[Laptop Toshiba Satellite Pro S300-EZ1514 Specifications](#)

Toshiba satellite pro s300-ez1514: specifications (5 pages)

[Laptop Toshiba Satellite Pro S300-EZ2501 Specifications](#)

Toshiba satellite pro s300-ez2501: specifications (5 pages)

[Laptop Toshiba Satellite Pro S300-EZ2502 Specifications](#)

Toshiba satellite pro s300-ez2502: specifications (5 pages)

[Laptop Toshiba Satellite Pro S300-EZ2521 Specifications](#)

Toshiba satellite pro s300-ez2521: specifications (5 pages)

[Laptop Toshiba S300L User Manual](#)

Notebook pc toshiba (202 pages)

## Related Content for Toshiba S300 EZ1514 - Satellite Pro - Core 2 Duo 2.1 GHz

[Satellite A35 Series Disabling Or Enabling The Touchpad](#)

Toshiba Satellite A35 Series

[C50 Series Disabling Or Enabling The Touchpad](#)

Toshiba C50 Series

[Satellite L40 series Disabling Or Enabling The Touchpad](#)

Toshiba Satellite L40 series

[Satellite L550 Series Disabling Or Enabling The Touchpad](#)

Toshiba Satellite L550 Series

[Satellite T210 Series Disabling Or Enabling The Touchpad](#)

Toshiba Satellite T210 Series

[Satellite P200 Series Disabling Or Enabling The Touchpad](#)

Toshiba Satellite P200 Series

[Qosmio X300 Series Disabling Or Enabling The Touchpad](#)

Toshiba Qosmio X300 Series

[Tecra A9 Series Disabling Or Enabling The Touchpad](#)

Toshiba Tecra A9 Series

This manual is also suitable for:

[S300 s1001 - satellite pro - core 2 duo 2.4 ghz](#)[S300 ez2501 - satellite pro - core 2 duo 2.2 ghz](#)[S300 ez2502 - satellite pro - core 2 duo 2.26 ghz](#)[S300 s2504 - satellite pro - core 2 duo 2.4 ghz](#)[S300-ez1511 - satellite pro - pentium dual core 2.16 ghz](#)[S300-s2503 - satellite pro - core 2 duo 2.26 ghz](#) ... [Show all](#)