

Intel® Chipset Device Software Installation - Asus Z9PE-D16-10G Series Manual

Z9pe-d16-10g series manual

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16


17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202



•

[Table of Contents](#)

•

Bookmarks



6.2

Intel

®

This section provides the instructions on how to install the Intel the system.

You need to manually install the Intel system.

To install the Intel chipset device software:

®

Restart the computer, and then log on with Administrator privileges.

1.

2.

Insert the motherboard/system support DVD to the optical drive. The support DVD automatically displays the Drivers menu if Autorun is enabled in your computer.

If Autorun is NOT enabled in your computer, browse the contents of the support DVD to locate the file ASSETUP.EXE from the BIN folder. Double-click the ASSETUP.EXE to run the support DVD.

Click the item Intel Chipset Device Software from the menu.

3.

The Intel(R) Chipset Device Software window appears. Click Next to start

4.

installation.

Z9PE-D16-10G Series

chipset device software installation

chipset device software on a Windows operating

®

chipset device software on

®

6-15

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
170
171
172
173

Related Manuals for Asus Z9PE-D16-10G Series

[Software Asus Z9PE-D16-10G DUAL User Manual](#)

System web-based management (94 pages)

[Motherboard Asus Z9PH-D16 FDR User Manual](#)

Z9ph-d16 series (192 pages)

[Motherboard Asus Z9PE-D16 User Manual](#)

Z9pe-d16 series (194 pages)

[Motherboard Asus Z9PA-U8 User Manual](#)

Atx motherboard (188 pages)

[Motherboard Asus Z9PE-D8 WS Manual](#)

Dual intel socket 2011 (226 pages)

[Motherboard ASUS XC Cube box User Manual](#)

(226 pages)

[Motherboard Asus z9pe-d8 WS Quick Start Manual](#)

(14 pages)

[Motherboard Asus Z9PA-D8 User Manual](#)

Z9pa-d8 series 2 x lga 2011 socket (194 pages)

[Motherboard Asus Z9PR-D12 SERIES User Manual](#)

User guide (190 pages)

[Motherboard ASUS Z9PR-D16 Manual](#)

(194 pages)

[Motherboard ASUS Z97M-PLUS User Manual](#)

Uatx motherboard (144 pages)

[Motherboard Asus Z97-C Manual](#)

(48 pages)

[Motherboard Asus Z97-P Manual](#)

(22 pages)

[Motherboard Asus Z87-A User Manual](#)

Asus z87-a motherboard user guide (114 pages)

[Motherboard Asus Z97-PRO GAMER User Manual](#)

(102 pages)

[Motherboard Asus z97 Series Manual](#)

(28 pages)

Related Content for Asus Z9PE-D16-10G Series

[Z10PE-D16 series Intel ® Chipset Device Software Installation](#)

ASUS Z10PE-D16 series

[Z10PR-D16 Intel ® Chipset Device Software Installation](#)

ASUS Z10PR-D16

[Z10PH-D16 Intel ® Chipset Device Software Installation](#)

ASUS Z10PH-D16

[Z10PA-D8 Series Intel ® Chipset Device Software Installation](#)

Asus Z10PA-D8 Series

[XC Cube box Intel ® Chipset Device Software Installation](#)

ASUS XC Cube box

[Z9PR-D16 Intel® Chipset Device Software Installation](#)

ASUS Z9PR-D16

[Z9PR-D12 SERIES Intel® Chipset Device Software Installation](#)

Asus Z9PR-D12 SERIES

[Z9PA-D8 Intel® Chipset Device Software Installation](#)

Asus Z9PA-D8

This manual is also suitable for:

[Z9pe-d16-10g/dualZ9pe-d16-10g/single](#)