



# [Dss] Button; Features; Calling A Station; Transfer To An Idle Station - Toshiba 2000 series User Manual

2000-series digital telephones for strata dk systems




1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18  
19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67

68  
69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117

118  
119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134



•

[Table of Contents](#)



•

## Bookmarks





[DSS] Button

---

## [DSS] Button

The Direct Station Select [DSS] button can appear on both the DADM and DSS Console. Each DSS button is associated with a particular station in your telephone system. It can be used to transfer an outside call to the associated station or to make a direct call to the associated station. The [DSS] LED lights steady red when the station associated with the [DSS] is ringing, busy on a call, or in the DND mode; or when the associated station is idle, but all appearances of the station's [PDN] are busy or in-use by other stations. [DSS] buttons cannot call station [PhDNs], Distributed Hunt Group [DNs], or ACD Groups.

# Features

The LED color indications described in these feature descriptions apply specifically to the DADM and DSS Console models DDSS2060 and DDSS1060. Flash conditions described here apply to all DSS console models and the DADM.

## Calling a Station

To call a station's [PDN] from either a DSS console or a DADM, press the [DSS] associated with the station. A station call with a [DSS] can be made on-hook or off-hook, and with Voice First or Tone signaling. After pressing the button, treat the call like any other station call made from a digital telephone.

[DSS] LEDs indicate whether the associated station is idle or busy. The LED is steady red if the station is busy or ringing, and is not lit if idle. If all the station's PDN buttons are being used by other stations, the DSS LED of the station is lit steady red, but the station may be idle. If the station is in the DND mode, its DSS LED lights steady red.

## Transfer to an Idle Station

You can transfer internal or outside calls to an idle station from either a DSS console or a DADM.

To transfer a call to an idle station

1. Press [DSS] corresponding to the station to be called.

102

The call is placed automatically on hold. The Line or [DN] LED flashes green at double the on-hold rate, and the [DSS] LED flashes green.

You hear a single-ring tone. (If using the Tone signaling mode, you hear successive ring tones.)

Strata DK Digital Telephone

ManualsLib.com

[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)

1

...

113

114

115

116

Quick Links:

[Table of Contents](#)

[Voice Mail Integration](#)

## Related Manuals for Toshiba 2000 series

[IP Phone Toshiba Strata DK 2000-series User Manual](#)

Toshiba digital telephone user guide (164 pages)

[IP Phone Toshiba Strata DK User Manual](#)

Digital business telephone systems includes lcd, add-on module, and direct station selection console (136 pages)

[Control Unit Toshiba V Series Operation Manual](#)

Integrated controller, ethernet module (122 pages)



### [Telephone Toshiba 3000 series Quick Reference Manual](#)

Strata ctx dkt/ipt telephone (13 pages)

### [IP Phone Toshiba Strata DK DKT 2000-Series Quick Reference Manual](#)

(8 pages)

### [Telephone System Toshiba Strata DK DKT 2000-series Quick Reference Manual](#)

Digital business telephone system (2 pages)

### [Toshiba 3000 Series, 2000 Series - DKT / IPT Business Telephone Quick Reference Guide with Button Codes](#)

(article)

### [IP Phone Toshiba DK User Manual](#)

Includes lcd, add-on module, and direct station selection console (163 pages)

### [Telephone Toshiba DKT User Manual](#)

Strata ctx dkt/ipt telephone (116 pages)

### [Telephone Toshiba DKT3010-SD - Digital Phone User Manual](#)

Strata ctx digital business telephone systems dkt/ipt telephone (114 pages)

### [Telephone Toshiba DKT3000 Series User Manual](#)

Strata ctx digital business telephone systems (106 pages)

### [IP Phone Toshiba STRATA CTX DKT3000 User Manual](#)

Dkt3000/2000-series digital business telephone systems (104 pages)

### [IP Phone Toshiba DKT3000/2000 User Manual](#)

Dkt3000/2000-series digital business telephone systems (104 pages)

### [IP Phone Toshiba IPT 2010F-SD User Manual](#)

(3 pages)

### [IP Phone Toshiba DKT3200 Specifications](#)

Toshiba ip telephone specifications (2 pages)

### [IP Phone Toshiba IP EDGE User Manual](#)

Ip5000-series ip telephone, messaging and call manager (242 pages)

## Related Content for Toshiba 2000 series

### [IP5000 Series Spkr Button](#)

Toshiba IP5000 Series

### [IP edge Direct Station Selection \(Dss\)](#)

Toshiba IP edge

### [IPEDGE Direct Station Selection \(Dss\)](#)

Toshiba IPEDGE

### [IP EDGE Direct Station Selection \(Dss\)](#)

Toshiba IP EDGE

### [ID EDGE Direct Station Selection \(Dss\)](#)

Toshiba ID EDGE

### [VIPedge IP5131-SDL Create Actions To Set And Clear The Dss Message](#)

Toshiba VIPedge IP5131-SDL

### [DK14 Direct Station Selection \(Dss\) Consoles And Door Phones \(Mdfbs\)](#)

Toshiba DK14

### [Perception e&ex 20-Button Digital Telephone](#)

This manual is also suitable for:

[Dkt2010-hDkt2010-sdDkt2020-sDkt2020sd](#)