

Caution For Pump Down - Sanyo SPW-C256VH Technical Data & Service Manual

4-way air discharge semi-concealed wall-mounted ceiling-mounted concealed-duct

1

2

3

4

5

Table Of Contents

6

7

8

9

10

11

12

13

14

15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217

218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267

268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317

318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367

368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417

418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467

468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517



-


[Table of Contents](#)


•

Bookmarks



2-32-3. Checking indoor unit addresses

Use the remote controller to check the addresses of the indoor units. Press and hold the  button for 4 seconds or longer (simple settings mode, "ALL" appears on the remote controller).

Then press the  address.

(For the system addresses of the No. 1 outdoor unit,

2



When the button is pressed, the address changes (For the system addresses of the No. 1 outdoor unit, the displayed addresses are 1-1, 1-2, ...)

The indoor unit fan operates only at the selected indoor unit. Confirm the indoor unit address. (For the system addresses of the No. 2 outdoor unit, the displayed addresses are 2-1, 2-2, ...)

Press the button again to return to the normal remote controller mode.

2-32-4. Indicating (marking) the indoor and outdoor unit combination number

Indicate (mark) the number after automatic address setting is completed.

Confirm that the combination of each indoor unit can be checked when multiple units are installed, and confirm that the indoor and outdoor unit numbers correspond to the system address number on the indoor unit control PCB, and use a magic marker to mark the numbers which cannot be easily removed to indicate the numbers in an easily visible location on the indoor units (near the indoor unit nameplates).

Example:

(Outdoor) 1 - (Indoor) 1, 2...

(Outdoor) 2 - (Indoor) 1, 2...

(2) These numbers will be needed for maintenance.

Be sure to indicate them.

Installing the Remote Controller

If the remote controller is to be installed onto a wall or other surface for use, first place the remote controller in the location where it will be installed and press (ON / OFF).

Confirm that the "signal-received" sound occurs at the indoor unit and that the A/C begins operating.

Fasten the remote control mount with screws.

Remote control mount

button and

button and select the indoor

Fig. 2-31

Fitting the remote control in the mount.

2

Press

1

Put in

Fig. 2-32

Installing the batteries

(1) Press on both sides of the remote controller cover and slide it downward to remove it.

(2) Insert 2 AAA alkaline batteries. (Pay attention to the + and - directions.)

(3) Gently insert one end of an unfolded paper clip (or a similar object that can fit) into the Reset hole and press the reset button inside the hole and then put the cover back on.



To remove the remote controller, pull it toward you.

Precautions for remote controller installation

Before mounting the remote controller on the wall, place the unit at the mounting position, then turn on any fluorescent lamps, press the ON/OFF button, and check that the air conditioner operates correctly.

When using the remote controller to detect room temperature, observe the following conditions during installation:

• Avoid locations where the remote controller will be exposed to the direct path of air blown from the air conditioner.

• Avoid locations where the remote controller will be exposed to direct sunlight.

• Avoid locations where the remote controller will be exposed to direct heat sources.

Caution for Pump Down

Pump down means refrigerant gas in the system is returned to the outdoor unit. Pump down is used when the unit is to be moved, or before servicing the refrigerant circuit.

CAUTION

This outdoor unit cannot collect more than the rated refrigerant amount as shown by the nameplate on the back.

If the amount of refrigerant is more than that recommended, do not conduct a pump down.



In this case use another refrigerant collecting system

Pay a special attention to the rotating of the fan while operating.

2-32

Reset hole
Cover

Fig. 2-33



[Previous Page](#)
[Next Page](#)

1

...

395

396

397

398

Quick Links:

[Indoor Unit](#)

[Technical Data](#)

[Outdoor Unit](#)

[Unit Specifications](#)

Related Manuals for Sanyo SPW-C256VH

[Air Conditioner Sanyo Big PACi 18 Series Technical Data & Service Manual](#)

Big pack i dc inverter (275 pages)

[Air Conditioner Sanyo ECOi C0705DXHN8 Brochure & Specs](#)

2 and 3 pipe electric vrf systems (10 pages)

[Air Conditioner Sanyo MINI ECO-i SPW-CR365GXH56B Service Manual](#)

(252 pages)

[Air Conditioner Sanyo SPW-T253G56 Service Manual](#)

Split system air conditioner (71 pages)

[Air Conditioner Sanyo SPW-D253G56 Service Manual](#)

Split system air conditioner (66 pages)

[Air Conditioner Sanyo SPW-CR365GXH56 Technical Data Manual](#)

Mini eco-i system (346 pages)

[Air Conditioner Sanyo Mini ECO-i SPW-ASR74GXH56\(A/B\) Installation Instructions Manual](#)

System air conditioner (49 pages)

[Air Conditioner Sanyo SPW-C1155DXHN8 Technical Data & Service Manual](#)

2-way eco-i multi system (242 pages)

[Air Conditioner Sanyo SPW-U253GH56 Service Manual](#)

Split system air conditioner (108 pages)

[Air Conditioner Sanyo SPW-T253GH56 Service Manual](#)

Split system (106 pages)

[Air Conditioner Sanyo SPW-D253GH56 Service Manual](#)

Split system (108 pages)

[Air Conditioner Sanyo SPW-C0705DZH8 Technical Data Manual](#)

3-way eco-i multi system 5 series (703 pages)

[Air Conditioner Sanyo SPW-C483GYH8 Service Manual](#)

Eco multi system (235 pages)

[Air Conditioner Sanyo SPW-CR1503GDYH8 Technical Data & Service Manual](#)

W-eco multi system series (377 pages)

[Air Conditioner Sanyo SPW-FTR124EH56 Installation And Operation Manual](#)

Dc inverter air conditioner for refrigerant r410a (32 pages)

[Air Conditioner Sanyo SPW-CR363GVH8 Service Manual](#)

(262 pages)

Related Content for Sanyo SPW-C256VH

[SPW-CR365GXH56 Caution For Pump Down](#)

Sanyo SPW-CR365GXH56

[R410A Caution For Pump Down](#)

Sanyo R410A

[W-3WAY ECO-i 85464369098000 Caution For Pump Down](#)

Sanyo W-3WAY ECO-i 85464369098000

[Mini ECO-i 85464359981002 Caution For Pump Down](#)

Sanyo Mini ECO-i 85464359981002

[AHX0752 Caution For Pump Down](#)

Sanyo AHX0752

[85464359982001 Caution For Pump Down](#)

Sanyo 85464359982001

[C2432A I Pump Down](#)

Sanyo C2432A

[SPW-CR365GXH56 Caution For Pump Down](#)

Sanyo SPW-CR365GXH56

This manual is also suitable for:

[Spw-c486vh8Spw-c606vh8Spw-xdr124gh56\(a/b\)Spw-x125hSpw-xm125hSpw-c366vh...](#) [Show all](#)

[Save PDF](#)