



Asus Chromebit CS10 Quick Start Manual

1
2

--

•

Bookmarks

Quick Links

[Download this manual](#) See also: [Quick Start Manual](#)



Enlarged version

Getting started

CA11043

Mise en route

Quick Start Guide

Guide de démarrage rapide

IN SEARCH OF
INCREDIBLE

Connecting Chromebit

For best performance, operate at 1°C - 35°C.

Connecter Chromebit

A maximum of 500 mA current draw should be connected via a powered USB hub, and not directly to the USB port.

Ensure that your Chromebit does not block any of the air vents on your monitor display.

Place your Chromebit or powered USB hub near the side of your monitor to ensure that wireless signals are not obstructed.

Illustrations for reference only.

USB hub, keyboard and mouse are not included.

Visit our multi-language web site at <http://support.asus.com>.

2.

Remove the cap.

Retirez l'embout.

For our best performance, utilize a une température comprise entre 1°C et 35°C.

Tous les périphériques nécessitant une tension électrique de plus de 500 mA doivent être connectés via un hub USB alimenté, et ne pas être directement connectés au port USB.

Assurez-vous que Chromebit ne bloque pas les fentes d'aération sur votre écran.

Placez votre Chromebit ou votre hub USB alimenté près du côté de votre moniteur afin d'éviter d'obstruer les signaux sans fil.

Illustrations à titre de référence uniquement.

Le hub USB, le clavier et la souris ne sont pas inclus.

Visitez notre site multilingue d'assistance en ligne sur <http://support.asus.com>.

2.

Retirez le capot.

Retirez Chromebit à un port HDMI.

Connecter le hub USB

3.

Connect the power into your Chromebit.

Reinsérez Chromebit à un port HDMI.

Connecter le hub USB

3.

Stick your USB hub to your monitor and keep it close set, then connect your Chromebit.

Collez le hub USB à votre moniteur à l'écart, puis connectez le hub USB

3.

Connect your Chromebit into an HDMI port.

Reinsérez Chromebit à un port HDMI.

Connecter le hub USB

3.

Connect the power into your Chromebit.

Reinsérez Chromebit à un port HDMI.

Connecter le hub USB

3.

Stick your USB hub to your monitor and keep it close set, then connect your Chromebit.

Collez le hub USB à votre moniteur à l'écart, puis connectez le hub USB

3.

Connect your Chromebit into an HDMI port.

Reinsérez Chromebit à un port HDMI.

Connecter le hub USB

3.

Connect the power into your Chromebit.

Reinsérez Chromebit à un port HDMI.

Connecter le hub USB

3.

Stick your USB hub to your monitor and keep it close set, then connect your Chromebit.

Collez le hub USB à votre moniteur à l'écart, puis connectez le hub USB

3.

15060-6853R000

Getting started

Mise en route



Getting started

Mise en route



NOTE

- For best performance, operate at 1°C - 35°C.
- Any peripheral over 500 mA current draw should be connected via a powered USB hub, and not directly to the USB port.
- Ensure that your Chromebit does not block any of the air vents on your monitor display.
- Place your Chromebit or powered USB hub near the side of your monitor to ensure that wireless signals are not obstructed.
- Illustrations for reference only.
- USB hub, keyboard and mouse are not included.
- Visit our multi-language web site at <http://support.asus.com>.

REMARQUE

- Pour une meilleure performance, utilisez une température comprise entre 1°C et 35°C.
- Tous les périphériques nécessitant une tension électrique de plus de 500 mA doivent être connectés via un hub USB alimenté, et ne pas être directement connectés au port USB.
- Assurez-vous que Chromebit ne bloque pas les fentes d'aération sur votre écran.
- Placez Chromebit ou le hub USB alimenté auprès du côté de votre moniteur afin d'éviter d'obstruer les signaux sans fil.
- Les illustrations ne sont fournies qu'à titre d'illustration.
- Le hub USB, le clavier et la souris ne sont pas inclus.
- Visitez notre site multilingue d'assistance en ligne sur <http://support.asus.com>.

NOTE

- For best performance, operate at 1°C - 35°C.
- Any peripheral over 500 mA current draw should be connected via a powered USB hub, and not directly to the USB port.
- Ensure that your Chromebit does not block any of the air vents on your monitor display.
- Place your Chromebit or powered USB hub near the side of your monitor to ensure that wireless signals are not obstructed.
- Illustrations for reference only.
- USB hub, keyboard and mouse are not included.
- Visit our multi-language web site at <http://support.asus.com>.

Connecting Chromebit

Connecter Chromebit



Connecting Chromebit

Connecter Chromebit



Connecting USB Hub

Connecter le hub USB



Connecting USB Hub

Connecter le hub USB



[Next Page](#)

1

2

Related Manuals for Asus Chromebit CS10

[TV Accessories Asus Chromebit CS10 Quick Start Manual](#)

(64 pages)

[Desktop Asus CS10 Quick Start Manual](#)

(55 pages)

[Stick PC's Asus Chromebit CS10 Quick Start Manual](#)

(48 pages)

[Stick PC's Asus Chromebit CS10 Quick Start Manual](#)

(40 pages)

[Adapter Asus cs10 Chromebit Quick Start Manual](#)

(37 pages)

[Desktop Asus Chromebit CS10 Safety Information Manual](#)

(17 pages)

[Adapter Asus cs10 Chromebit Quick Start Manual](#)

(16 pages)

[Computer Accessories Asus Chromebit CS10 Quick Start Manual](#)

(2 pages)

[Desktop Asus CS5110 User Manual](#)

User manual (26 pages)

[Desktop Asus CS5120 User Manual](#)

User manual (26 pages)

[Desktop Asus CS Series Installation Manual](#)

(2 pages)

[Desktop Asus CS6110 User Manual](#)

User manual (262 pages)

[Desktop Asus Essentio CM6870 User Manual](#)

Essentio desktop pc (352 pages)

[Desktop Asus CM5425 User Manual](#)

Essentio series desktop pc (22 pages)

[Desktop Asus CP Series User Manual](#)

(137 pages)

[Desktop Asus Chromebox 5 Service Manual](#)

(116 pages)

Summary of Contents for Asus Chromebit CS10

[Page 1](#) • Place your Chromebit or powered USB hub near the side of your monitor to ensure that wireless signals are not obstructed. • Illustrations for reference only. • USB hub, keyboard and mouse are not included. • Visit our multi-language web site at <http://support.asus.com>
Quick Start Guide Remove the cap. REMARQUE : Guide de démarrage rapide • Pour une meilleure performance, utilisez à une température Retirez l'embout.

[Page 2: Connecting Keyboard And Mouse](#)

EN 60065:2002 / A12: 2011 techserv.aspx EN 60950-1: 2006 / A2: 2013 2009/125/EC-ErP Directive Regulation (EC) No. 1275/2008 Regulation (EC) No. 278/2009 ASUS COMPUTER INTERNATIONAL (America) Regulation (EC) No. 642/2009 Regulation (EU) No. 617/2013 2011/65/EU-RoHS Directive Ver. 150326 CE marking...