





Whirlpool 8053365 Installation Instructions Manual



1

2

3

4

5

6

7

8

9

Table Of Contents

10

--

•

[Table of Contents](#)

•

Bookmarks

--

[Download this manual](#)

### Quick Links







# Installation Instructions

A child or adult can tip the range and be killed.

Connect anti-tip bracket to rear range foot.

Reconnect the anti-tip bracket, if the range is moved.

Failure to follow these instructions can result in death or serious burns to children and adults.

## Sealed Burner

Gas

## Range

with standard clean oven

WARNING

Tip Over Hazard

## Quick Reference

### Table of Contents:

#### Pages

2

Before you start

2

Product dimensions

Cabinet dimensions/requirements

2

Electrical requirements

3

Gas supply requirements

3

Installation steps

4 - 7

Gas conversions

7 - 8

Back cover

If range does not operate

Back cover

If you need assistance/service

Back cover


Household — Major — Service and Repair.

Call when you:



Have questions about range installation or operation.

Need to obtain the name and number of an authorized service company.

When you call, you will need:



ManualsLib.com




**IMPORTANT:**

Read and save these instructions.

**IMPORTANT:**

Installers must discuss with the homeowner.  
Homeowner must save these instructions for future reference.  
Save Instructions for local electrical inspector's use.  
Part No. 8



[Table of Contents](#)

[Next Page](#)

1  
2  
3  
4  
5

## Related Manuals for Whirlpool 8053365

[Whirlpool 8535845 Installation Instructions Manual](#)

(25 pages)

[Whirlpool 8577213C Installation Instructions Manual](#)

(16 pages)

[Whirlpool 8316557 Installation Instructions Manual](#)

(13 pages)

[Whirlpool 8535840 Installation Instructions Manual](#)

(25 pages)

[Whirlpool 8535841 Installation Instructions Manual](#)

(24 pages)

## Summary of Contents for Whirlpool 8053365

[Page 1](#) Installer: Leave Installation Instructions with the homeowner. is moved. Homeowner: Keep Installation Instructions for future reference. Failure to follow these instructions can result in death or serious burns to children Save Installation Instructions for local electrical inspector's use. and adults. Part No. 8053365...

### [Page 2: Product Dimensions](#)

Before you start... Product dimensions Grounded electrical Your safety and the safety of others is outlet is required. See very important. "Electrical We have provided many important safety requirements," Page 3. messages in this manual and on your appliance. Proper gas supply Always read and obey all safety messages.

### [Page 3: Tools Needed](#)

Tools needed: Electrical requirements Recommended WARNING level ground method 3/8" drive For your personal safety, this range must be ratchet grounded. This range is manufactured with a power supply cord having a 3-prong ground wood floor: plug. To minimize possible shock hazard, the 1/8"...

### [Page 4: Installation Steps](#)

Check cooktop burners for proper flame Plug power supply cord into grounded outlet Make proper Remove shipping material. connection Remove oven racks and parts package. Install anti- tip bracket Secure range with anti-tip Level range bracket Check burner operation Replace or close broiler drawer.

### [Page 5: Operating Position](#)

Before moving range across floor, check that Operating position range is still on cardboard shipping base to protect floor covering. front leveling leg Making sure the anti-tip bracket is installed: anti-tip • Look for the bracket anti-tip bracket securely attached to range foot Place rack in oven.

### [Page 6: Check Operation](#)

Check operation Electronic ignition system Check operation of oven burner To avoid damaging the hot surface ignitor, Do Not insert any object into the openings of Cooktop and oven burners use electronic the protective shield that surrounds the ignitor ignitors in place of standing pilots. When a Open broiler drawer.

### [Page 7: Gas Conversions](#)

Check operation (cont.) If your oven has this type of electronic Check that the broil burner is

operating. control pads: 888° 88:88 Close the broiler drawer. Press the HEAT BAKE BROIL TIMER "OFF/CANCEL" pad. TIMER START CUSTOM TEMP CLOCK LIGHT BAKE TEMP ENTER...

### [Page 8: Natural Gas Conversion](#)

Natural gas conversion Replace orifice spud Cooktop burners: Pull range out from with the number listed countertop front about 4 orifice spuds in chart. inches. There are two clips, Check that main gas supply line has been one on each side, located shut off and the power supply cord is underneath the cooktop disconnected.

### [Page 9: If You Need Assistance](#)

When you call, you will need: The range model number. The range serial number. Both numbers are listed on the model/serial rating plate located on the frame behind the broiler drawer. Part No. 8053365 Benton Harbor, Michigan 49022 Printed in U.S.A. © 1998 Whirlpool Corporation...