



Toshiba 65L7300U User Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94


95

96

97

Table Of Contents

98



•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks

Quick Links

[1 Picture and Sound Controls](#)

[2 Using Your Home Network](#)

[3 Wireless Setup](#)

[Download this manual](#)



Leading innovation

Integrated
TOSHIBA
High Definition LED

Television

TOSHIBA

Leading Innovation >>

32L4300U / 39L4300U / 50L4300U

50L7300U / 58L7300U / 65L7300U

If you need assistance:

Toshiba's Support Web site support.toshiba.com

For more information, see "Troubleshooting" on page 160 in this guide.

Owner's Record

The model number and serial number are on the back and side of your television.

Record these numbers, whenever you communicate with your Toshiba dealer about this television.

32L4300U / 39L4300U / 50L4300U

Model name:

Serial number:

50L7300U / 58L7300U / 65L7300U

Register your Toshiba Television at register.toshiba.com

Note: To display a High Definition

picture, the TV must be receiving a

High Definition signal (such as an over-

the-air High Definition TV broadcast,

a

High Definition digital cable program,

or a High Definition

digital satellite

program). For details, contact your TV

antenna

installer, cable provider, or

satellite provider.

GMA300019011

3/13

If you need assistance:

Toshiba's Support Web site support.toshiba.com

For more information, see "Troubleshooting" on page 160 in

Owner's Record

The model number and serial number are on the back and si

Record these numbers, whenever you communicate with yo

this Television.

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba 65L7300U

[LED TV Toshiba 39L4300UM User Manual](#)

Integrated high definition led television (186 pages)

[LED TV TOSHIBA 65L7300U User Manual](#)

(90 pages)

[Keyboard Toshiba 58L7350U User Manual](#)

Wireless keyboard users guide I7300, I7350 series cloud tv (2 pages)

[LED TV Toshiba 50L7300U Resource Manual](#)

Integrated high definition led television (2 pages)

[LED TV Toshiba 32L2300UM Resource Manual](#)

Integrated high definition led television (2 pages)

[LED TV TOSHIBA 65L7350U User Manual](#)

(97 pages)

[LED TV Toshiba 58L7350U Resource Manual](#)

Integrated high definition led television (2 pages)

[LED TV TOSHIBA 58L7350U User Manual](#)

Integrated high definition (103 pages)

[LED TV Toshiba 58L9300U User Manual](#)

Integrated high definition led television (202 pages)

[LED TV Toshiba 32L110U Quick Setup Manual](#)

28" 720p, 60hz, led tv; 32" 720p, 60hz, led tv (2 pages)

[LED TV Toshiba 32L221U User Manual](#)

Led google cast tv (99 pages)

[LED TV Toshiba 43U5865 Series Owner's Manual](#)

(27 pages)

[LED TV Toshiba 43U5069 Owner's Manual](#)

(29 pages)

[LED TV Toshiba 65C350KU Quick Setup Manual](#)

Fire tv (18 pages)

[LED TV Toshiba QA7D63DG Operating Instructions Manual](#)

(47 pages)

[LED TV Toshiba 65QA4C63DB Quick Start Manual](#)

(12 pages)

Related Products for Toshiba 65L7300U

[Toshiba 65L7350U](#)

[Toshiba 65L7300UC](#)

[Toshiba 65L7350UC](#)

[Toshiba 65L9300U](#)

[Toshiba 65L9300UC](#)

[Toshiba 65L9400U Series](#)

[Toshiba 65L9450 Series](#)

[Toshiba 65L350U](#)

[Toshiba 65L5400U](#)

[Toshiba 65L5400UC](#)

[Toshiba 65L621U](#)

[Toshiba 65L9363](#)

[Toshiba 65H84](#)

[Toshiba 65U5069EE](#)

[Toshiba 65 UA2B Series](#)

[Toshiba 65 UL2C Series](#)

This manual is also suitable for:

[50I4300u39I4300u32I4300u50I7300u58I7300u](#)