



Asus P535 User Manual

Asus cell phone user manual

1	
2	
Table Of Contents	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	
17	

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132

--

•

[Table of Contents](#)

•

Bookmarks

--

[Download this manual](#)

Quick Links



ASUS
P535

User Manual

ManualsLib.com



[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Asus P535

[PDA Asus P535 Assembly & Disassembly Instructions](#)

(33 pages)

[Cell Phone Asus P535 Quick Start Manual](#)

(27 pages)

[Cell Phone Asus P535 Quick Start Manual](#)

P535 quick start guide (26 pages)

[Cell Phone Asus P525 Quick Start Manual](#)

(25 pages)

[Cell Phone Asus P526 User Manual](#)

Asus cell phone user manual (122 pages)

[Cell Phone Asus P526 Service Manual](#)

Asus p526 cell phone service manual (12 pages)

[Cell Phone Asus P526 Service Manual](#)

Repair lv3 4 sop (113 pages)

[Cell Phone Asus P527 Quick Start Manual](#)

Asus p527: quick start (39 pages)

[Cell Phone Asus 90A-S5G1007T User Manual](#)

User manual (174 pages)

[Cell Phone Asus P527 Firmware Update](#)

(9 pages)

[Cell Phone Asus P550 User Manual](#)

Asus p550 user manual in traditional chinese (140 pages)

[Cell Phone Asus P550 User Manual](#)

(176 pages)

[Cell Phone Asus P565 Troubleshooting Manual](#)

(97 pages)

[Cell Phone Asus P565 User Manual](#)

User manual (190 pages)

[Cell Phone Asus P552w User Manual](#)

User manual (186 pages)

[Cell Phone Asus P552W Manual](#)

Level 3,4 (117 pages)

Summary of Contents for Asus P535

[Page 1](#) P535 User Manual...

[Page 2](#) Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification or alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

[Page 3: Table Of Contents](#)

Table of Contents P535 specifications... 8 Package contents... 9 Chapter 1: Getting started
Getting to know your P535... 12 Layout ... 12 Device components description ... 14 Getting your

device ready..16 Installing the SIM card and battery... 16 Charging the battery...

[Page 4](#) Chapter 1: Entering data .Using the Input Panel... 28 Using the Block Recognizer ... 28 Using the On-screen keyboard ... 29 Using the Letter Recognizer... 30 Using the Transcriber ... 31 Writing and drawing on the screen..32 Recording voice.

[Page 5](#) Using the Speed Dial ... 49 Using Voice Command... 50 Receiving a call..51 Chapter 2: Wireless features Using the Wireless Manager..54 Using Bluetooth ® ... 55 Overview ... 55 Activating Bluetooth in your device ... 55 Configuring Bluetooth ...

[Page 6](#) My Secrets setting... 76 Disabling My Secrets ... 79 Chapter 3: Multimedia features Using the camera..84 Launching the camera... 84 Navigation button functions in camera mode ... 85 Camera mode screen... 87 Taking photos ... 95 Video mode screen ... 96 Recording videos ...

[Page 7](#) System information...119 Restoring default factory settings... 120 Chapter 8: Device component status ASUS status icon..122 CPU mode setting ... 123 USB setting ... 123 LCD Brightness ... 124 Battery ... 124 Memory ... 125 Storage card memory... 125 Programs running in memory ...

[Page 8: P535 Specifications](#)

P535 specifications Processor Operating System Memory Display Frequency band GPRS Camera Connectivity Battery capacity Expansion slot Audio Weight Dimension Talk time* Standby time* NOTE: Specifications are subject to change without notice. Intel XScale processor, 520MHz ® Microsoft ® Windows Mobile™ 5.0...

[Page 9: Package Contents](#)

Package contents Check your P535 package for the following items: P ASUS P535 device P Battery P AC Adapter P Mini-USB cable P Headset P Stylus P Car cell phone charger* P Car Kit (PDA holder and windshield suction pedestal)*...

[Page 11: Chapter 1: Getting Started](#)

Chapter Getting started • Getting to know your P535 • Getting your device ready • Starting up • The Today screen...

[Page 12: Getting To Know Your P535](#)

Getting to know your P535 Layout Left side features Top features Front features Components: MiniSD slot Power button Stylus Camera button Volume controller Reset button Notification LED Earpiece receiver LCD touch screen Call key Left Soft key Mode/Task switcher button Navigation buttons Action button Right Soft key...

[Page 13](#) Getting to know your P535 Rear features Bottom features Components: Right side features Camera flash light Camera lens GPS antenna connector Speaker Battery compartment Voice recorder button Hold button Earphone slot Mini-USB connector...

[Page 14: Device Components Description](#)

Device components description Item MiniSD slot Power button Stylus Camera/Shutter button Volume controller Reset button Notification LED Earpiece receiver LCD touch screen Call key Left Soft key Mode/Task switcher button Navigation buttons Description Allows you to insert a MiniSD storage card. Press once to set suspend mode or to wake device from sleep mode.

[Page 15](#) Device components description Item Action button Right Soft key Ok or Close button End button Camera flashlight Camera lens GPS antenna connector Speaker Battery compartment Voice recorder button Hold button Earphone port Mini-USB connector Description Press to carry out the task of selected item. Performs the task indicated above the button.

[Page 16: Getting Your Device Ready](#)

Getting your device ready Installing the SIM card and battery Before you can make a phone call using your P535, you need to install a Subscriber Identity Module (SIM) card. A SIM card contains your phone number, subscriber details, phonebook, and additional phone memory.

[Page 17](#) 2. Remove the battery. 3. Insert the SIM card with its gold contacts facing down and the notched corner oriented to the upper left corner of the slot as shown. 4. Replace the battery into the compartment with its copper contacts properly aligned to the copper conductor on the device.

[Page 18: Charging The Battery](#)

Charging the battery The bundled battery pack is shipped partially charged. Charge the battery up to four (4) hours before using for the first time. To charge battery: 1. Connect the AC adapter plug to the mini-USB connector at the bottom of the device. 2.

[Page 19: Starting Up](#)

Starting up Powering your device Make sure that your P535 is fully-charged before starting the device for the first time. To turn on power: 1. Press and hold the power button. 2. Follow onscreen instructions to align screen and set the local time zone.

[Page 20: Calibrating P535](#)

Calibrating P535 Calibrating your device ensures that the item you tap on the screen is activated. This involves tapping in the center of targets that appear in various coordinates on the screen. To calibrate your screen: 1. Tap Start > Settings > System tab then tap Screen icon.

[Page 21: The Today Screen](#)

The Today screen The Today screen displays information useful to you. You can configure the Today screen to have all the important information you need. • To access the Today screen, tap Start > Today. • To personalize the Today screen, tap Start > Settings > Personal tab > Today. The following describes the common information found on the today screen: Tap to open the Start menu Tap to setup date, time, and alarm...

[Page 22: Status Indicators](#)

Status indicators Refer to the table below for the Today screen icon status indicators. Icon General Packet Radio Services (GPRS) available. Connecting via GPRS. Connected via GPRS. Connecting with ActiveSync ActiveSync connection not active. ActiveSync synchronization in progress. Synchronization error. Call forwarded.

[Page 23: Icon Description](#)

Status indicators Icon Description New voice mail. No cellular phone service. No signal. Searching for cellular phone service. Indicates signal strength. Sound OFF. Sound ON. Battery low. Battery extremely low. Battery partially charged. Battery charging. Battery fully charged.

[Page 24](#) Status indicators Icon Description Searching Wi-Fi connection. Wi-Fi active. Roaming service. This icon appears only if you have international roaming feature. Vibrate or silent mode on. Bluetooth headset connected. Bluetooth head connected with sound. Appears when you set the alarm No SIM installed.

[Page 25: Screen Orientation](#)

Screen orientation You can set the screen to three different orientations: 1. Portrait 2. Landscape (right-handed) 3. Landscape (left-handed) Set to Portrait mode to get a better view or better operation of certain applications on your device. Set to Landscape when viewing pictures, video or viewing longer text files. To change the screen orientation, tap Start >...

[Page 26: Start Menu](#)

Start menu The Start menu contains various programs and applications that you commonly use. Tap Start to display the start menu items: Portrait mode You can also customize the items that appear in the Start menu. To do this: 1. Tap Start > Settings > Personal tab > Menus. 2.

[Page 27: Entering Data](#)

Chapter Entering data • Using the Input Panel • Writing and drawing on the screen • Recording voice • Using ActiveSync™ • Synchronizing with Exchange Server • Searching information • Getting Help...

[Page 28: Using The Input Panel](#)

Using the Input Panel When you start an application or select a field that requires text, symbols, or numbers, the Input Panel icon appears on the menu bar. The Input Panel allows you to select various input methods including: Block Recognizer, Keyboard, Letter Recognizer, and Transcriber. Using the Block Recognizer The Block Recognizer allows you to use a single stroke to write letters, numbers, symbols, or punctuations, which are converted into typed text.

[Page 29: Using The On-Screen Keyboard](#)

Using the On-screen keyboard With the on-screen keyboard, you can key in text, symbols, numbers, or other special characters when input is possible. To input text using the on-screen keyboard: 1. In an application, tap the Input Panel arrow, then tap Keyboard. 2.

[Page 30: Using The Letter Recognizer](#)

Using the Letter Recognizer With the Letter Recognizer you can write individual letters, numbers, or special characters, which are converted into typed text. To use the Letter Recognizer: 1. In an application, tap the Input Panel arrow, then tap Letter Recognizer. 2.

[Page 31: Using The Transcriber](#)

Using the Transcriber Transcriber is a handwriting recognition program that allows you to write in cursive, print, or mixed styles. It reliably recognizes not only written text but also numbers and symbols. Make sure to write legibly. See Help for more information on the Transcriber. To use the Transcriber: 1.

[Page 32: Writing And Drawing On The Screen](#)

Writing and drawing on the screen You can write or draw directly on the screen and save notes in your own handwriting. If you prefer to use your own handwriting or use drawings in your notes, set the default input mode to Writing.

[Page 33: Recording Voice](#)

Recording voice At any time, whether you phone is on stand-by or active mode, you can record sound, voice, or add a recording to a note while using your device. To start a voice recording: 1. Press Record button to launch voice recorder application.

[Page 34](#) To add a recording to a saved note: 1. Tap Start > Programs > Notes. 2. From the Notes list, tap to open a saved note. 3. If you do not see the recording toolbar, tap Menu > View Recording Toolbar. 4.

[Page 35: Using Activesync](#)

Using ActiveSync™ ActiveSync™ allows you to synchronize data in your device with data in your computer. ActiveSync can also synchronize over a wireless or cellular network with Microsoft Exchange Server, provided that your cellular phone service or company is running Microsoft Exchange Server with Exchange ActiveSync.

[Page 36](#) If you wish to synchronize your device with Exchange Server through your company or service provider, obtain the name of the Exchange Server, user name, password, and domain name from your network administrator before starting the Sync Setup Wizard. To install and configure ActiveSync in your computer: 1.

[Page 37: Synchronizing Via Mini-Usb](#)

Synchronizing via mini-USB You can connect to your device using the bundled mini-USB cable to synchronize to your computer. To synchronize your device via mini-USB: 1. After installing ActiveSync to your computer, connect the mini-USB plug to the mini-USB connector at the bottom of the device. 2.

[Page 38: Synchronizing With Exchange Server](#)

Synchronizing with Exchange Server To synchronize your device with Exchange Server: 1. From the ActiveSync menu, tap Menu > Add Server Source. 2. In the Server Address field, input the name of the server running Exchange Server then tap Next. If necessary, tap the check box This server requires an encrypted (SSL) connection.

[Page 39](#) 3. Input your name, password, and domain then tap Next. 4. Tap the check boxes to

select the data items that you want to synchronize with Exchange Server. To change the available synchronization settings, select a data item then tap Settings. Tap Finish when done.

[Page 40: Setting The Synchronization Schedule](#)

Setting the synchronization schedule To set the synchronization with Exchange Server: 1. From the ActiveSync screen, tap Menu > Schedule. 2. Refer to the table for input details. Volume Recommended setup High Select a shorter interval in the Peak times list. Select As items arrive option or a longer interval in the Off-peak times list.

[Page 41: Searching Information](#)

Searching information Using the search tool, you can search for files and other items stored in your device or the external MiniSD card. You can search by file name or by words located in various applications including the Calendar, Contacts, Excel Mobile, Word Mobile, Outlook Mobile, Help, Messages, Notes, and Tasks.

[Page 42: Getting Help](#)

Getting Help You can easily find Help for using any program on the device. To get help for a program: • From the Today screen or program, tap Start > Help. A page will open with links to topics that explain how to use the program.

[Page 43: Phone Features](#)

Chapter Phone features • Using the phone • Making a call • Receiving a call...

[Page 44: Using Phone](#)

Using phone Like a standard cellular phone, you can use your P535 to make and receive calls. You can also keep a history of calls made and received, send SMS or MMS messages, take notes while talking, call from Contacts, and copy data from installed SIM card to your device.

[Page 45: Adjusting The Device Volume](#)

Adjusting the device volume To adjust the device volume: 1. Tap the speaker icon. 2. From the volume menu, you can: • Adjust the phone volume or device volume by moving the slider to the desired volume level. • Tap On, Vibrate, or Off to change the system and ringer volume settings.

[Page 46: Making A Call](#)

Making a call You can make a phone call using the phone pad. You can also make calls directly from the Contacts, Call History, Speed Dial, or Voice Commander. Using the phone pad To make a call using the phone pad: 1.

[Page 47](#) Phone pad features Operator name Dialed numbers appear here Press to delete number or symbol to the left Press to set speed dial Numeric keypad Press to launch Call History Press to make call Press to launch menu Press to launch Contacts list Displays the current call status Press to mute Press to launch Contacts list...

[Page 48: Making Calls From Contacts](#)

Making calls from Contacts To make a call directly from Contacts: 1. Tap Start > Phone. 2. From the Phone pad, tap Contacts or press the Left soft key. You can also launch Contacts from the Today screen by tapping Contacts on the menu bar or pressing the Right soft key.

[Page 49: Using The Speed Dial](#)

Using the Speed Dial With Speed Dial you can call frequently dialed numbers in a single tap. For example, if you assign a contact to the number 2 button in Speed Dial, you can simply tap and hold the Phone pad to dial the contact's number. To create a Speed Dial entry: 1.

[Page 50: Using Voice Command](#)

Using Voice Command To make a phone call using voice command: 1. Press the record button found on the right side of your device. 2. From the following screen, your device asks you to "Say command." 3. Audibly say "Call" then the name to call from your Contact list.

[Page 51: Receiving A Call](#)

Receiving a call When you receive a call, a message will appear giving you the option to answer or reject the incoming call. To answer or reject an incoming call: • To answer a call tap Answer, or press Call key. •...

[Page 53: Wireless Features](#)

Chapter Wireless features • Using the Wireless Manager • Using Bluetooth ® • Using WLAN (IEEE 802.11b/g) • Setting a GPRS connection...

[Page 54: Using The Wireless Manager](#)

Using the Wireless Manager The Wireless Manager allows you to turn the power off or on to your wireless connections in a single location. This is a quick way to preserve battery power or to prepare your device for an airplane flight.

[Page 55: Using Bluetooth](#)

Using Bluetooth Overview Bluetooth is a short-range wireless communications technology that allows devices with ® Bluetooth capabilities to exchange data within a radius of about 10 meters (30 feet) without requiring a physical connection. With Bluetooth enabled in your device, you can: •...

[Page 56: Configuring Bluetooth](#)

Configuring Bluetooth To configure Bluetooth in your device: 1. Start > Settings > Connections tab then tap the Bluetooth icon. 2. From the Bluetooth screen, you can access the following tabs: • General - allows you to set the user profile, turn Bluetooth on or off, displays the Bluetooth status, and provides a link to the Bluetooth Manager.

[Page 57](#) Using a Bluetooth-enabled headset Mono headset setup 1. Make sure that Bluetooth is enabled on your device. 2. Tap on the Today screen then on the shortcut menu tap Bluetooth Manager. 3. From the Bluetooth Manager, tap New. 4. From the Bluetooth Connection Wizard, tap Hands-free/Headset setup then tap Next.

[Page 58](#) 5. Make sure that your headset device is in pairing mode and ready to receive incoming connection requests then tap Next. 6. Tap the name of your Bluetooth-enabled headset device then tap Next. 7. In Passkey, input the alphanumeric passkey of your headset device then tap .

[Page 59](#) Stereo headset setup P535 supports A2DP (Advanced Audio Distribution Profile), which is used by Bluetooth-enabled stereo headsets. Make sure that your stereo headset also supports A2DP. 1. Tap on the Today screen then on the shortcut menu tap Bluetooth Manager.

[Page 60](#) 5. Tap Finish to initiate connection. NOTES: • To answer a phone call using your stereo headset, make sure that you have mono and stereo connection at the same time. • To use voice commander while using a headset, press the answer button* on the headset then follow succeeding voice instructions.

[Page 61](#) 6. Tap the name of your Bluetooth-enabled GPS device then tap Next. 7. Select SPP Slave in the Service Selection list then tap Next. 8. Tap Finish. 9. Tap and hold the shortcut icon to display shortcut menu then tap Connect.

[Page 62: Using Wlan \(Ieee 802.11B/G\)](#)

Using WLAN (IEEE 802.11b/g) Introduction WLAN (IEEE 802.11b/g), refers to certain types of wireless local area network (WLAN) that use specifications in the 802.11 family. Created by the Wi-Fi Alliance, a nonprofit international association to certify interoperability of wireless local area network products. Any device tested and approved by the Wi-Fi Alliance are certified as interoperable with each other even if they are from different manufacturers.

[Page 63: Configuring Wlan](#)

Configuring WLAN To configure WLAN in your device: 1. Start > Settings > Connections tab then tap the Wi-Fi Manager icon. 2. From the Wi-Fi Manager screen, you can access the following tabs: • Wi-Fi Status • Setting • IP Info •...

[Page 64](#) IP Info Displays the network information and allows you to renew or ping a network connection. Site Survey Shows the available wireless networks in the area.

[Page 65: Setting A Gprs Connection](#)

Setting a GPRS connection Your P535 allows you to connect via General Packet Radio Service (GPRS). GPRS is a wireless communication standard that runs at speeds of up to 115 kbps, compared to 9.6 kbps of the current Global System for Mobile Communications (GSM). It supports a wide range of bandwidths that allows sending and receiving small bursts of data, such as email and web browsing.

[Page 66](#) 4. From the Connections screen, tap Add a new model connection. 5. Input a unique name for the connection then select Cellular Line (GPRS) from the modem list.

[Page 67](#) 6. Input the Access point name. 7. Input your user name, password, and domain then tap Finish. Contact your network administrator for assistance. NOTE: The GPRS and USB connections can not be used at the same time.

[Page 68: Connecting Gprs](#)

Connecting GPRS To connect GPRS: 1. Tap Start > Settings > Connections tab then tap Connections icon. 2. From the Connections screen, tap Manage existing connections. 3. Tap and hold on an existing connection then from the pop-up menu tap Connect.

[Page 69: Disconnecting Gprs](#)

If you have set a default GPRS connection, it automatically connects when you launch an application that connects to the Internet. 1. Launch any application that connects to the Internet (e.g. Internet Explorer). The device will automatically connect your default GPRS connection. A pop-up callout appears to display the connection status.

[Page 70: Using The Gprs Tool](#)

Using the GPRS Tool The GPRS Tool allows you to conveniently select and connect to your GPRS service provider. To connect via GPRS Tool: 1. Tap Start > Settings > Connections tab then tap the Network Setting icon. You can also tap then tap Settings from the pop-up callout.

[Page 71](#) Chapter My Secrets • Using My Secrets...

[Page 72: Using My Secrets](#)

Using My Secrets My Secrets is a secret archive to keep your classified documents, pictures and video. The items placed in the My Secrets folder are encrypted for protection. A user-defined password is required to unlock the folder or change the settings. Enabling My Secrets To enable My Secrets using Express Mode (recommended): 1.

[Page 73](#) 3. Key in a 4-digit password. 4. When prompted, key in the same password again to confirm. 5. Tap Finish. When finished, the My Documents\My Secrets becomes an encrypted folder. You can now start using this folder. IMPORTANT: • When locked, the My Secrets folder is hidden. Use password to unlock folder and access files.

[Page 74: Unlocking My Secrets](#)

Unlocking My Secrets To unlock My Secrets: 1. Tap the My Secrets Today screen. 2. From the shortcut menu, tap Unlock. 3. Key in correct password. You can now use My Secrets folder. icon on the...

[Page 75: Locking My Secrets](#)

Locking My Secrets To lock My Secrets: 1. Tap the My Secrets icon on the Today screen. 2. From the shortcut menu, tap Lock. The My Secrets icon changes to indicating that the My Secrets folder is locked.

[Page 76: My Secrets Setting](#)

My Secrets setting To modify the My Secrets settings: 1. Tap the My Secrets Today screen. 2. From the shortcut menu, tap My Secrets Setting. 3. Key in correct password. My Secrets Setting

allows you to modify any of the following: •...

[Page 77](#) Security Setting Security setting allows you to enable or disable autolock when the device enters sleep mode, lock the device now, or stop security. Password The Password tab allows you to change the password and password type.

[Page 78](#) Hint Set a hint in case you forget your password. • Tap check box to enable or disable use of hint to unlock the device. • Select one of the predefined questions then key in answer. 4. Tap when finished.

[Page 79: Disabling My Secrets](#)

Disabling My Secrets To disable My Secrets: 1. From Today screen, tap Start > Programs > My Secrets or Tap the My Secrets icon on the Today screen and from the shortcut menu, tap My Secrets Setting. 2. Select Security Setting tab, then tap Stop Security.

[Page 80](#) 3. When prompted, tap Yes to confirm. 4. Tap Next to stop all running programs.

[Page 81](#) 5. Tap Next to start decrypting files in My Secrets folder. 6. Tap Done when finished.

[Page 83](#) Chapter Multimedia features • Using the camera • Viewing pictures and video...

[Page 84: Using The Camera](#)

Using the camera The built-in two-megapixel camera allows you to take photos and record audio/video clips. Launching the camera To start using the camera: • Tap Start > Programs > Pictures and Videos > Camera icon or • Press the Camera button on the left side of your device. To exit the Camera: •...

[Page 85: Navigation Button Functions In Camera Mode](#)

Navigation button functions in camera mode The following describes the navigation button functions in Camera mode: In camera preview mode, press for video mode. In the camera or video option menu, press to select menu items. In video preview mode, press for camera mode. Down In the video or camera options menu, press to select menu items.

[Page 86: Supported Formats](#)

Available capture modes Your device camera can be set to two capture modes: • Camera mode - Camera mode allows you to take photos, and save them to your device or MiniSD. You can also configure the camera to match an environment, set picture size, select magnification, adjust the picture quality, apply effects, and modify other advanced settings.

[Page 87: Camera Mode Screen](#)

Camera mode screen The following describes the screen icons in Camera mode: Tap to launch Pictures and Videos Number of available shots Capture modes: Camera mode Video mode Tap to launch camera menu Capture mode icon Picture quality icon Flash light status Macro mode status Default storage icon Scene mode icon...

[Page 88](#) Camera mode icons • Capture mode icon [• Picture quality icon [• Flash light status icon [• Macro mode icon [• Default storage icon [videos clips. • Scene mode icon [• Timer icon [corresponding timer icon appears.

[Page 89: Camera Options Menu](#)

Camera options menu The camera options menu allows you to change various camera and picture settings. To launch options menu: 1. Tap Menu from the camera screen. 2. From the shortcut menu, tap an icon to display contents. Camera options shortcut menu...

[Page 90](#) Change Mode The Change Mode option allows you to set capture mode into Camera or Video mode. Scene The Scene option allows you to select presets appropriate for a night scene or sports event. Select Auto to use best setting for any scene.

[Page 91](#) Picture Quality This option provides three picture quality presets: Normal, Fine, and Super Fine. The picture quality is set to Super Fine by default. Flash Mode This option allows you to change the flash mode to suit a variety of lighting situations. Macro Mode Enables or disables

the macro photography feature.

[Page 92](#) Zoom Allows you to change the maximum magnification allowed. Self-Timer Sets the delay of shutter release to 5 or 10 seconds after you have pressed the camera/shutter button. Burst Allows you to take 4 or 9 pictures in succession with one press of the camera/ shutter button.

[Page 93](#) Frame Allows you to set a frame. Effect The Effect option allows you to apply some effects to the subject. Select from the following configuration options: Black-White, Negative, and Sepia. Set to Normal for no effect. Save to Allows you to select the default storage for captured pictures.

[Page 94](#) Advanced This option allows you to set the following: - Filename prefix format - Filename prefix - File number - Date and time stamp - Shutter sound - Burst interval...

[Page 95: Taking Photos](#)

Taking photos After launching the camera, your device is set to Camera mode by default. If set otherwise, tap Menu > Change Mode > Camera Mode then tap Done. You can also set to camera mode by tapping the camera mode icon on the screen. To take a photo: 1.

[Page 96: Video Mode Screen](#)

Video mode screen The following describes the screen icons in Video mode: Tap to launch Pictures and Videos Recording indicator Green: Ready Red: Recording Capture mode icons: Camera mode Video mode Tap to launch video menu Capture mode icon Remaining video recording time Default storage icon Video resolution...

[Page 97](#) Video mode icons • Capture mode icon [• Flash light status icon [• Macro mode icon [] - this icon appears when the video is in macro mode. • Default storage icon [• Effects icon [•...

[Page 98: Video Options Menu](#)

Video options menu The video options menu allows you to change various video and playback settings. To launch video options menu: 1. Tap Menu from the video screen. 2. From the shortcut menu, tap an icon to display contents. Video options shortcut menu...

[Page 99](#) Change Mode The Change Mode option allows you to set your device into Camera or Video capture mode. Zoom Allows you to change the maximum magnification allowed. Video Size Allows you to set the frame size of video.

[Page 100](#) Flash Mode This option allows you to change the flash mode to suit a variety of lighting situations. Macro Mode Enables or disables the macro photography feature. Save to Allows you to select the default storage location for captured pictures. NOTE: Prepare a MiniSD card before setting default storage to Storage Card.

[Page 101](#) Effect The Effect option allows you to apply some effects to the subject. Select from the following configuration options: Black-White, Negative, and Sepia. Set to Normal for no effect. Advanced This option allows you to set the following: - Video filetype - Filename prefix format - Filename prefix - File number...

[Page 102: Recording Videos](#)

Recording videos Set the device to video capture mode to record videos. To set video mode: • Tap Menu > Change Mode > Video Mode then tap Done. • You can also set the video mode by tapping the video mode icon on the screen as shown.

[Page 103](#) 2. Full-press the camera/shutter button or press the navigation button action button to begin recording. The record indicator turns from green to red while video is recording. 3. Full-press the camera/shutter button or press the navigation button action button again to stop recording. 4.

[Page 104: Viewing Pictures And Video](#)

Viewing pictures and video Use the Pictures and Video Application to preview stored images and playback video clips. Viewing pictures and video To view pictures and video: 1. Tap Start >

Programs > Pictures and Videos. 2. Tap the picture or video clip you want to see. •...

[Page 105: Chapter 7: Other Features](#)

Chapter Other features • WorldCard Mobile • Remote Presenter • Setting ring tone • Wake-up setting • Mode switcher • System information • Restoring factory default settings...

[Page 106: Worldcard Mobile](#)

WorldCard Mobile WorldCard Mobile is a character recognition utility that scans and identifies the printed text or character on a business card then automatically categorizes the information and sends it to your Contact list. From a picture file of a business card, WorldCard Mobile analyzes the appearance of the details in the business card and converts them to editable text for your Contact list.

[Page 107](#) IMPORTANT: • Make sure to clean the camera lens and provide enough lighting before taking picture of business card. • Keep a “1600x1200” resolution when taking a picture of business card. 3. Take a clear picture of the business card. 4.

[Page 108](#) 7. Tap Export to save the information in Contacts. Refer to the labels for other screen options and features. 6. Tap to exit WorldCard Mobile. include or exclude data field Tap the arrows to change data field Tap to save information to Contacts Tap the check box to Tap to add a data field Tap to pan through the image...

[Page 109: Remote Presenter](#)

Remote Presenter Remote Presenter allows you to remotely control PowerPoint™ presentations running on your desktop or notebook from your P535 device. Operating over a Bluetooth wireless connection, it promotes convenience and freedom of movement during your presentation. It also enables you to review slide notes without affecting the audience’s view of the slide show.

[Page 110](#) Tap to start or stop Tap to exit 4. When requested, key in the authentication passkey on your computer and your P535. NOTE: The Bluetooth authentication passkey is only required if a paired relationship is not yet established with the other device.

[Page 111](#) 5. From the Remote Controller menu on your computer, click to establish a connection. to exit reminder. 6. When the connection is established, tap Connect.

[Page 112](#) 7. Your device prompts if the connection is successful or not. Repeat from step 1, if the connection failed. 8. Tap the name of PowerPoint (.ppt) file to show then tap Select.

[Page 113](#) Upon selection, Microsoft ® PowerPoint is automatically launched on your computer with the selected file open.

[Page 114](#) 9. You can now remotely control the PowerPoint presentation on your computer using your device. The following describes the control menu on your device. Slide number Tap to exit Tap to select slide Indicates Bluetooth signal Timer ® Tap to toggle between Normal and Slide Show view Previous slide Next slide...

[Page 115: Setting Ring Tone](#)

Setting ring tone With P535 you can add and configure your favorite music as your phone ring tone. You can easily configure your favorite song or sound as your ring tone with the following compatible audio formats: aac/acc+, amr, .mp3, .wav, .wma, and .mid.

[Page 116: Changing The Ring Tone](#)

Changing the ring tone To change the ring tone: 1. Tap Start > Settings > Personal > Phone icon. 2. Select a ring tone from the Ring tone list box. The songs or sounds that you added as ring tone appears on this list along with the default ring tones that came with the device. to try ring tone sound and tap 3.

[Page 117: Wake-Up Setting](#)

Wake-up setting You can set the wake-up actions whenever your device is in sleep mode. To set the wake-up action: 1. Tap Start > Settings > Personal > Wakeup source icon. 2. Select from

the available wake-up actions. Tap Select All to select all actions or tap Select None to deselect all available actions. 3.

[Page 118: Mode Switcher](#)

Mode switcher Mode switcher allows you to easily switch between applications and tasks. To use the mode switcher, press the mode switcher button on your device keypad. Press again to shift between applications. You can also use the mode switcher button to turn the flash light on or off. Press and hold the mode switcher button to use this feature.

[Page 119: System Information](#)

System information The System Information contains important device information including the current device settings and version. To launch the System Information: 1. Tap Start > Settings > System > System Information icon. 2. Tap the Device Info tab for device hardware information. 3.

[Page 120: Restoring Default Factory Settings](#)

Restoring default factory settings This option allows you to restore the default factory settings. To restore default settings: 1. Tap Start > Settings > Default Settings. 2. Input '1234' in the Password field to confirm that you want to restore to default settings. 3.

[Page 121](#) Chapter Device components status • ASUS Status icon...

[Page 122: Asus Status Icon](#)

ASUS status icon The ASUS status icon allows you to easily check and see the current status of the following device components: CPU, USB, LCD Brightness, Battery power, Memory, MiniSD card, and storage. To check the status of these components, tap the ASUS Status icon on the Today screen.

[Page 123: Cpu Mode Setting](#)

CPU mode setting Allows you to select the CPU mode (Turbo, Standard, Power Saving). Tap to check Automatic Mode to automatically change the CPU speed according to the CPU loading. USB setting Allows you to set the USB connection mode.

[Page 124: Lcd Brightness](#)

LCD Brightness Adjusts the LCD brightness on battery power and external power. Battery Displays the battery power status. The Advanced settings allows you to set a time when to turn-off the device if not used.

[Page 125: Memory](#)

Memory Displays the total, in use and free memory. Storage card memory Displays the total, in use, and available storage card memory.

[Page 126: Programs Running In Memory](#)

When you exit a running program, you are actually only minimizing it and the program remains in the memory. You can stop these programs from running in the background using this option. Settings Allows you to select the items to display in the ASUS Settings pop-up menu.

[Page 127: Appendix](#)

Appendix • Notices • Contact information...

[Page 128: Notices](#)

Notices Replaceable batteries If an equipment is provided with a replaceable battery and if replacement by an incorrect type could result in an explosion (e.g. with some lithium batteries), the following applies: – if the battery is placed in an OPERATOR ACCESS AREA, there shall be a marking close to the battery or a statement in both the operating and the servicing instructions;...

[Page 129](#) Operator access with a tool If a TOOL is necessary to gain access to an OPERATOR ACCESS AREA, either all other compartments within that area containing a hazard shall be inaccessible to the OPERATOR by the use of the same TOOL, or such compartments shall be

marked to discourage OPERATOR access.

[Page 130](#) WARNING The user needs to switch off the device when exposed to areas with potentially explosive atmospheres such as petrol stations, chemical storage depots and blasting operations.

[Page 131](#) IMEI integrity related requirements expressed in the GSM standards. Should you have any questions or comments regarding this matter, please have our best attention. Sincerely yours, ASUSTeK COMPUTER INC. Tel: 886-2-2894-3447 Fax: 886-2-2890-7698 E-mail: <http://vip.asus.com/eservice/techserv.aspx>...

[Page 132: Contact Information](#)

0800-093-456 (Toll-Free call from Taiwan only) Fax: 886-2-2895-9254 E-mail: <http://vip.asus.com/eservice/techserv.aspx> WWW: <http://tw.asus.com> ASUSTeK COMPUTER INC. (Asia-Pacific) Hotline: 886-2-2894-3447 Fax: 886-2-2890-7698 E-mail: <http://vip.asus.com/eservice/techserv.aspx> WWW: <http://www.asus.com> ASUS COMPUTER GmbH (Germany/Austria) Hotline: +49-2102-9599-10 Fax: +49-2102-9599-11 E-mail: <http://www.asus.de/support/support.htm> WWW: <http://www.asus.de> ASUS COMPUTER (China) Tel: +86-10-82667575 E-Mail: <http://vip.asus.com.cn/eservice/techserv.aspx>.

[Save PDF](#)