

Setting The Synchronization Schedule - Asus P535 User Manual

Asus cell phone user manual

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15


16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117

118
119
120
121
122
123
124
125
126
127
128
129
130
131
132



•

[Table of Contents](#)

•

Bookmarks



Setting the synchronization schedule

To set the synchronization with Exchange Server:

1. From the ActiveSync screen, tap Menu > Schedule.
2. Refer to the table for input details.

□0

Volume

High

Select a shorter interval in the Peak times list.

Select As items arrive option or a longer interval

Low

in the Off-peak times list.


While roaming

Check Use above settings while roaming.

Sending messages

Check Send outgoing items immediately.

Recommended setup



[Previous Page](#)
[Next Page](#)

1
...
37
38
39
40
41
42
43
44

Related Manuals for Asus P535

[PDA Asus P535 Assembly & Disassembly Instructions](#)

(33 pages)

[Cell Phone Asus P535 Quick Start Manual](#)

(27 pages)

[Cell Phone Asus P535 Quick Start Manual](#)

P535 quick start guide (26 pages)

[Cell Phone Asus P525 Quick Start Manual](#)

(25 pages)

[Cell Phone Asus P526 User Manual](#)

Asus cell phone user manual (122 pages)

[Cell Phone Asus P526 Service Manual](#)

Asus p526 cell phone service manual (12 pages)

[Cell Phone Asus P526 Service Manual](#)

Repair lv3 4 sop (113 pages)

[Cell Phone Asus P527 Quick Start Manual](#)

Asus p527: quick start (39 pages)

[Cell Phone Asus 90A-S5G1007T User Manual](#)

User manual (174 pages)

[Cell Phone Asus P527 Firmware Update](#)

(9 pages)

[Cell Phone Asus P550 User Manual](#)

Asus p550 user manual in traditional chinese (140 pages)

[Cell Phone Asus P550 User Manual](#)

(176 pages)

[Cell Phone Asus P565 Troubleshooting Manual](#)

(97 pages)

[Cell Phone Asus P565 User Manual](#)

User manual (190 pages)

[Cell Phone Asus P552w User Manual](#)

User manual (186 pages)

[Cell Phone Asus P552W Manual](#)

Level 3,4 (117 pages)

Related Content for Asus P535

[P525 Setting The Synchronization Schedule](#)

Asus P525

[02 Xda Graphite Creating A Synchronization Schedule](#)

Asus 02 Xda Graphite

[M930 Creating A Synchronization Schedule](#)

Asus M930

[ZE550ML Setting Up The Date And Time](#)

Asus ZE550ML

[Zenfone Go ZB500KG Setting Up The Date And Time](#)

Asus Zenfone Go ZB500KG

[Zenfone 11 Ultra Setting Up The Date And Time](#)

Asus Zenfone 11 Ultra

[ROG PHONE 8 Setting Up The Date And Time](#)

Asus ROG PHONE 8

[ZB552KL Setting Up The Date And Time](#)

Asus ZB552KL

Save PDF