

TOSHIBA

Toshiba Perception 4000 Quick Reference Manual

1
2
3
4
5
6
7
8

Table Of Contents

9

--

-

[Table of Contents](#)


•

Bookmarks

--

Quick Links

[Download this manual](#) See also: [User Manual](#), [Quick Reference Manual](#)



Enlarged version

TOSHIBA **PERCEPTION**

BUSINESS
TELEPHONE
SOLUTIONS

4 0 0 0

STANDARD TELEPHONE
QUICK
REFERENCE
GUIDE



[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba Perception 4000

[IP Phone TOSHIBA PERCEPTION 4000 User Manual](#)

Proprietary digital telephone (100 pages)

[Telephone Toshiba PERCEPTION 4000 User Manual](#)

Electronic telephone (92 pages)

[Telephone Toshiba PERCEPTION 4000 User Manual](#)

Standard telephone (56 pages)

[Telephone Accessories Toshiba Perception 4000 Quick Reference Manual](#)

Attendant console (17 pages)

[Telephone Accessories Toshiba Perception 4000 Quick Reference Manual](#)

Attendant console (9 pages)

[Telephone Toshiba Perception 4000 Quick Reference Manual](#)

Acid agent (8 pages)

[Telephone Toshiba PERCEPTIONe&ex User Manual](#)

Standard telephone (28 pages)

[Telephone Toshiba Electronic Key Telephone User Manual](#)

Electronic key telephone (28 pages)

[Telephone Toshiba DP5000-Series User Manual](#)

Strata cix telephone (142 pages)

[Telephone Toshiba IP5000 Series User Manual](#)

Ip telephone, messaging and call manager user guide (322 pages)

[Telephone Toshiba STRATA CTX100 Installation And Maintenance Manual](#)

Digital business telephone systems (348 pages)

[Telephone Toshiba Strata DK/CTX 2020-SD Quick Reference Manual](#)

Toshiba strata dk/ctx 2020-sd station set (1 page)

[Telephone Toshiba 2020-SD Quick Reference Manual](#)

Toshiba strata dk/ctx 2020-sd station set (1 page)

[Telephone Toshiba DP5022F-SD User Manual](#)

Digital business telephone with 4-line lcd display. hearing aid compatible (12 pages)

[Telephone Toshiba DKT3220-SD - Digital Phone - Charcoal User Manual](#)

Ipt/dkt telephone (151 pages)

[Telephone Toshiba DKT User Manual](#)

Strata ctx dkt/ipt telephone (116 pages)

Summary of Contents for Toshiba Perception 4000

[Page 2: Account Code Entry](#)

ACCOUNT CODE ENTRY To Enter a Forced Account Code: Dial the desired destination number. Listen for recall dial tone. Enter the necessary account code. Listen for success tone and wait for the call to be established. To Enter an Optional Account Code: Establish an outgoing or incoming call and ask the party to wait.

[Page 3: Call Pickup](#)

CALL HOLD To Place a Call on Hard Hold: Ask the connected party to wait. Press the hookswitch. Listen for recall dial tone. Enter the Call Hold access code _____. Listen for success tone and, if desired, hang up your telephone. To Retrieve a Call on Hard Hold: Press the hookswitch.

[Page 4: Call Transfer](#)

Listen for recall dial tone. Dial the number of any station that is a member of the group in which the call is ringing. Wait to be connected to the calling party. To Answer a Call Ringing at Another Station: Enter the Call Pickup—Directed access code _____.

[Page 5: Camp-On Transfer](#)

CAMP-ON TRANSFER To Perform a Camp-on Transfer Establish a two-way connection. Press the hookswitch, listen for recall dial tone, and dial the number of the destination that is to receive the call. After receiving busy tone, wait on the line for busy tone to change to success tone.

[Page 6: Last Number Redial](#)

Press the hookswitch to join all parties. (8) Repeat steps 6 ~ 8 until all desired parties are joined. To Release the Last-added Party from a Conference: Press the hookswitch and listen for recall dial tone. (1) Enter the Eight Party Conference Release access code _____.

[Page 7: Speed Calling](#)

SPEED CALLING To Place a Call via Speed Calling: Enter the Speed Calling—System or Speed Calling—Group access code. Speed Calling—System: _____ Speed Calling—Group: _____ Listen for recall dial tone. Enter the desired Speed Calling index number. (Speed Calling—System: 000 ~ 999; Speed Calling—Group: 0 ~ 9.) Dial any remaining digits needed to place the call.

[Page 8](#) Enter the number of the zone in which a call is being held for you. Wait to be connected to the held party. TOSHIBA Toshiba America Information Systems, Inc.
Telecommunication Systems Division 9740 Irvine Boulevard, Irvine, CA 92718 (714) 583-3700...