



Asus MyPal A632 Quick Start Manual

Asus gps receiver user manual

1
2
3
4
5
6

--

•

[Table of Contents](#)

•

Bookmarks

--

Quick Links

[Download this manual](#) See also: [Handbook](#), [User Manual](#)



QE2191

MYPAL  Pock
A636 / A6

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Asus MyPal A632

[PDA Asus MyPal A636 Handbook](#)

(142 pages)

[Handhelds Asus MyPal A632 User Manual](#)

Asus mypal a632: user guide (104 pages)

[Handhelds Asus MyPal A620BT User Manual](#)

(18 pages)

[Handhelds Asus MyPal A620BT User Manual](#)

Asus mypal a620bt user's manual (156 pages)

[Handhelds Asus MyPal A716 Quick Start Manual](#)

Asus mypal a716: quick start (6 pages)

[Handhelds Asus MyPal A716 User Manual](#)

Asus mypal a716: user guide (166 pages)

[Handhelds Asus MyPal A716 Manual De L'utilisateur](#)

Asus mypal a716 french user guide (166 pages)

[Handhelds Asus MyPal A730 Handbook](#)

Asus mypal a730: user guide (204 pages)

[Handhelds Asus MyPal A730W Handbook](#)

Asus mypal a730w: user guide (218 pages)

[Handhelds Asus MyPal A730 User Manual](#)

(80 pages)

[Handhelds Asus MyPal A730W Quick Start Manual](#)

Asus mypal a730w: quick start (6 pages)

[Handhelds Asus A626 - MyPal - Win Mobile 6.0 312 MHz User Manual](#)

Mypal pocket pc (109 pages)

[Handhelds Asus MyPal A632N User Manual](#)

Asustek computer user manual pocket pc (104 pages)

[Handhelds Asus MYPAL A639 User Manual](#)

User manual (106 pages)

[Handhelds Asus MyPal A620 User Manual](#)

Asustek computer user's manual mypal a620 (136 pages)

[Handhelds Asus MyPal A620 User Manual](#)

User manual (136 pages)

Summary of Contents for Asus MyPal A632

[Page 1](#) QE2191...

[Page 2: Front Features](#)

GPS antenna Hold key Battery cover Top features External antenna cover Stylus Power button
MyPal A636: Bluetooth/Wi-Fi/ GPS LED MyPal A632: Bluetooth/GPS LED Bluetooth Wi-Fi LCD
touch screen Notes (voice recording) button Calendar button Mode/ Task switcher button
Contacts button...

[Page 3: Setting Up Mypal](#)

Setting up MyPal NOTE Install the battery before connecting the AC adapter to a power source. See “Installing and removing the battery” of the User Manual for proper battery installation. Connecting power adapter and charging the battery NOTE The charging status LED shows a steady red light as battery is being charged and steady green when battery is fully charged.

[Page 4](#) Do not connect your device to your computer until you have installed ActiveSync. Connecting to the computer When MyPal A636/A632 is connected to the computer’s USB port, it allows data synchronization and battery charging at the same time. Synchronizing with the computer Upon connection, your device is automatically synchronized with your computer.

[Page 5: Today Screen](#)

Tap to display the Wi-Fi Tap to shift display to landscape or portrait orientation Tap to open the ASUS Status menu where you can see common device status and settings (such as backlight setting, battery level, memory usage, and more)

[Page 6: Entering Information](#)

- Recording Tap Menu > View Recording Toolbar. Then, tap the on the toolbar. Typing Writing Reference information Refer to the following sources for additional information on the ASUS MyPal A636/ A632 Pocket PC. Operation MyPal A636/A632 User Manual Online Help...

This manual is also suitable for:

[Mypal a636](#)