

Checking Battery Power; Battery Care - Asus E1916 Hardware User Manual

Asustek computer notebook pc user's manual

1
Table Of Contents
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72

--

•

Table of Contents

•

Bookmarks



Checking Battery Power

The battery system implements the Smart Battery standard under the Windows environment, which allows the battery to accurately report the amount of charge percentage left in the battery. A fully-charged battery pack provides the Notebook PC a few hours of working power. But the actual figure varies depending on how you use the power saving features, your general work habits, the CPU, system memory size, and the size of the display panel.

To check the remaining battery power, move your cursor over the power icon. The power icon is a "battery" when not using AC power and a "plug" when using AC power. Double click on the icon for more information and settings.



NOTE: If you ignore the low battery warning, eventually the Notebook PC enters suspend mode (Windows default uses STR).

WARNING! Suspend-to-RAM (STR) does not last long when the battery power is de-

pleted. Suspend-to-Disk (STD) is not the same as power OFF. STD requires a small

amount of power and will fail if no power is available due to complete battery deple-

tion or no power supply (e.g. removing both the power adapter and battery pack).



Battery Care

The Notebook PC's battery pack, like all rechargeable batteries, has a limit on the number of times it can

be recharged. Fully draining and charging the battery once a day every day will last over a year but how

long beyond that will depend on your environment temperature, humidity, and how your Notebook PC

is used. It is ideal that the battery be used in a temperature range between 10°C and 29°C (50°F and

85°F). You must also take into account that the Notebook PC's internal temperature is higher than the

outside temperature. Any temperatures above or below this range will shorten the life of the battery.

But in any case, the battery pack's usage time will eventually decrease and a new battery pack must be

purchased from an authorized dealer for this Notebook PC. Because batteries also have a shelf life, it is

not recommended to buy extras for storing.

NOTE: The battery stops charging if the temperature is too high or the battery voltage

is too high. BIOS provides a smart battery refreshing function.


Right-click the battery icon for sub-menus.

Getting Started

Move your mouse over the battery icon for remaining power information.

When the AC power is connected, charging status will be shown.

Left-click the battery icon for power management settings.



ManualsLib.com

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
24
25
26
27
28
29
30
31

Related Manuals for Asus E1916

[Laptop Asus Z70A Hardware User Manual](#)

Notebook pc (74 pages)

[Software Asus A3Ac User Manual](#)

(8 pages)

[Laptop Asus E10229 User Manual](#)

Z stylus (28 pages)

[Laptop Asus E15906 User Manual](#)

(13 pages)

[Laptop Asus E14573 E-Manual](#)

(102 pages)

[Laptop Asus VivoBook E12 E-Manual](#)

(94 pages)

[Laptop Asus E18307 E-Manual](#)

(94 pages)

[Laptop Asus E10584 E-Manual](#)

Notebook pc (118 pages)

[Laptop Asus E14902 E-Manual](#)

(96 pages)

[Laptop Asus E10750 E-Manual](#)

Notebook pc (128 pages)

[Laptop Asus E15630 Manual](#)

(110 pages)

[Laptop Asus E15025 Manual](#)

(86 pages)

[Laptop Asus E17919 Manual](#)

(102 pages)

[Laptop Asus E11966 E-Manual](#)

(110 pages)

[Laptop Asus E17305 Manual](#)

(100 pages)

[Laptop Asus Eee PC 1015 Series User Manual](#)

(58 pages)

Related Content for Asus E1916

[Lamborghini VX7 Checking Battery Power](#)

Asus Lamborghini VX7

[G60Jx Checking Battery Power](#)

Asus G60Jx

[F83T Checking Battery Power](#)

Asus F83T

[E5946 Checking Battery Power](#)

ASUS E5946

[E3108 Checking Battery Power](#)

Asus E3108

[Notebook PC Checking Battery Power](#)

ASUS Notebook PC

[E4168 Checking Battery Power](#)

ASUS E4168

[G56JR Checking Battery Power](#)

Asus G56JR

This manual is also suitable for:

[M6aM6vM6vaZ70vZ70vaZ70a](#) ... [Show all](#)

[Save PDF](#)