

Special Keyboard Functions; Colored Hot Keys - Asus E1916 Hardware User Manual

Asustek computer notebook pc user's manual

1
Table Of Contents
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72

--

•

Table of Contents

•

Bookmarks



Special Keyboard Functions

Colored Hot Keys

The following defines the colored hot keys on the Notebook PC's keyboard. The colored commands can only

be accessed by first pressing and holding the function key while pressing a key with a colored command.

NOTE: The Hot Key locations on the function keys may vary depending on model but

the functions should remain the same. Follow the icons instead of the function keys.

"Z" Icon (F1): Places the Notebook PC in suspend mode (either Save-to-RAM or

Save-

to-Disk depending on sleep button setting in power management setup).

Radio Tower (F2): Wireless Models Only: Toggles the internal wireless LAN ON and OFF. When enabled, the wireless LAN LED will light. Windows software settings are necessary to use the wireless LAN.

Filled Sun Icon (F5):

Decreases the display brightness

Open Sun Icon (F6):

Increases the display brightness

LCD Icon (F7): Toggles the display panel ON and OFF. This also stretches your screen area (on certain models) to fill the entire display when using low resolution modes.

LCD/Monitor Icons (F8): Toggles between the Notebook PC's LCD display and an ex-

ternal monitor in this series: Notebook PC LCD -> External Monitor -> Both. (This function does not work in 256 Colors, select High Color in Display Property Settings.)

IMPORTANT: Connect an external monitor before booting up the Notebook PC.

Speaker Icons (F10):

Toggles the speakers ON and OFF (only in Windows OS)

Speaker Minus Icon (F11):

Decreases the speaker volume (only in Windows OS)

Speaker Plus Icon (F12):

Increases the speaker volume (only in Windows OS)

Num Lk (Ins): Toggles the numeric keypad (number lock) ON and OFF. Allows you to

use a larger portion of the keyboard for number entering.

Scr Lk (Del): Toggles the "Scroll Lock" ON and OFF. Allows you to use a larger portion of the keyboard for cell navigation.

Getting Started

3

29



ManualsLib.com

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
26
27
28
29
30
31
32
33

Related Manuals for Asus E1916

[Laptop Asus Z70A Hardware User Manual](#)

Notebook pc (74 pages)

[Software Asus A3Ac User Manual](#)

(8 pages)

[Laptop Asus E10229 User Manual](#)

Z stylus (28 pages)

[Laptop Asus E15906 User Manual](#)

(13 pages)

[Laptop Asus E14573 E-Manual](#)

(102 pages)

[Laptop Asus VivoBook E12 E-Manual](#)

(94 pages)

[Laptop Asus E18307 E-Manual](#)

(94 pages)

[Laptop Asus E10584 E-Manual](#)

Notebook pc (118 pages)

[Laptop Asus E14902 E-Manual](#)

(96 pages)

[Laptop Asus E10750 E-Manual](#)

Notebook pc (128 pages)

[Laptop Asus E15630 Manual](#)

(110 pages)

[Laptop Asus E15025 Manual](#)

(86 pages)

[Laptop Asus E17919 Manual](#)

(102 pages)

[Laptop Asus E11966 E-Manual](#)

(110 pages)

[Laptop Asus E17305 Manual](#)

(100 pages)

[Laptop Asus Eee PC 1015 Series User Manual](#)

(58 pages)

Related Content for Asus E1916

[Lamborghini VX7 Special Keyboard Functions](#)

Asus Lamborghini VX7

[G60Jx Special Keyboard Functions](#)

Asus G60Jx

[F83T Special Keyboard Functions](#)

Asus F83T

[E5946 Special Keyboard Functions](#)

ASUS E5946

[E3108 Special Keyboard Functions](#)

Asus E3108

[Notebook PC Special Keyboard Functions](#)

ASUS Notebook PC

[E4168 Special Keyboard Functions](#)

ASUS E4168

[G56JR Special Keyboard Functions](#)

Asus G56JR

This manual is also suitable for:

[M6aM6vM6vaZ70vZ70vaZ70a](#) ... [Show all](#)

[Save PDF](#)