

Safety Precautions - Asus E1916 Hardware User Manual

Asustek computer notebook pc user's manual

1
Table Of Contents
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72

--

•

Table of Contents

•

Bookmarks



Safety Precautions

The following safety precautions will increase the life of the Notebook PC. Follow all precautions and

instructions. Except as described in this manual, refer all servicing to qualified personnel. Do not use

damaged power cords, accessories, or other peripherals. Do not use strong solvents such as thinners,

benzene, or other chemicals on or near the surface.

Disconnect the AC power and remove the battery pack(s) before cleaning. Wipe the

Notebook PC using a clean cellulose sponge or chamois cloth dampened

with a solution of nonabrasive detergent and a few drops of warm water and remove any extra moisture with a dry cloth.

DO NOT place on uneven or unstable work surfaces. Seek servicing if the casing has been damaged.

DO NOT place or drop objects on top and do not shove any foreign objects into the Notebook PC.

DO NOT press or touch the display panel. Do not place together with small items that may scratch or enter the Notebook PC.

DO NOT expose to strong magnetic or electrical fields.

DO NOT leave the Notebook PC on your lap or any part of the body while the Notebook PC is turned ON or is charging in order to prevent discomfort or injury from heat exposure.

Safe Operating Temperatures: This notebook PC should be used in environments with ambient temperatures **0°C/32°F** between 0°C/32°F and 30°C/86°F.

Introducing the Notebook PC


DO NOT expose to or use near liquids, rain, or moisture. DO NOT use the modem during an electrical storm.

DO NOT expose to dirty or dusty environments. DO NOT operate during a gas leak.

DO NOT expose to extreme temperatures above 50°C (122°F) or to direct sunlight. Do not block the fan vents!

DO NOT expose to extreme temperatures (below 0°C (32°F), otherwise the Notebook PC may not boot.

DO NOT throw batteries in fires as they may explode. Check local codes for special battery disposal instruc-



tions.

30°C/86°F

1

7

[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

1
...
4
5
6
7
8
9
10
11

Related Manuals for Asus E1916

[Laptop Asus Z70A Hardware User Manual](#)

Notebook pc (74 pages)

[Software Asus A3Ac User Manual](#)

(8 pages)

[Laptop Asus E10229 User Manual](#)

Z stylus (28 pages)

[Laptop Asus E15906 User Manual](#)

(13 pages)

[Laptop Asus E14573 E-Manual](#)

(102 pages)

[Laptop Asus VivoBook E12 E-Manual](#)

(94 pages)

[Laptop Asus E18307 E-Manual](#)

(94 pages)

[Laptop Asus E10584 E-Manual](#)

Notebook pc (118 pages)

[Laptop Asus E14902 E-Manual](#)

(96 pages)

[Laptop Asus E10750 E-Manual](#)

Notebook pc (128 pages)

[Laptop Asus E15630 Manual](#)

(110 pages)

[Laptop Asus E15025 Manual](#)

(86 pages)

[Laptop Asus E17919 Manual](#)

(102 pages)

[Laptop Asus E11966 E-Manual](#)

(110 pages)

[Laptop Asus E17305 Manual](#)

(100 pages)

[Laptop Asus Eee PC 1015 Series User Manual](#)

(58 pages)

Related Content for Asus E1916

[E203MA FD018TS Safety Precautions](#)

Asus E203MA FD018TS

[ZenBook 14X Safety Precautions](#)

Asus ZenBook 14X

[X515JA Safety Precautions](#)

Asus X515JA

[ROG GX701GX EV021T Safety Precautions](#)

Asus ROG GX701GX EV021T

[TUF Gaming FX505DV AL072T Safety Precautions](#)

Asus TUF Gaming FX505DV AL072T

[N580VD-FI523T Safety Precautions](#)

Asus N580VD-FI523T

[VivoBook Pro N580GD Safety Precautions](#)

Asus VivoBook Pro N580GD

[ROG G703GXR EV002T Safety Precautions](#)

Asus ROG G703GXR EV002T

This manual is also suitable for:

[M6aM6vM6vaZ70vZ70vaZ70a](#) ... [Show all](#)

[Save PDF](#)