



Toshiba Perception 4000 Quick Reference Manual

Attendant console

1
2
3
4
5
6
7
8
9

--


•

Bookmarks

--

Quick Links

[Download this manual](#) See also: [User Manual](#), [Quick Reference Manual](#)



TOSHIBA

BUSINESS
TELEPHONE
SOLUTIONS





[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba Perception 4000

[IP Phone TOSHIBA PERCEPTION 4000 User Manual](#)

Proprietary digital telephone (100 pages)

[Telephone Toshiba PERCEPTION 4000 User Manual](#)

Electronic telephone (92 pages)

[Telephone Toshiba PERCEPTION 4000 User Manual](#)

Standard telephone (56 pages)

[Telephone Accessories Toshiba Perception 4000 Quick Reference Manual](#)

Attendant console (17 pages)

[Telephone Toshiba Perception 4000 Quick Reference Manual](#)

(9 pages)

[Telephone Toshiba Perception 4000 Quick Reference Manual](#)

Acad agent (8 pages)

[Telephone Accessories Toshiba Strata DK 280 Installation Manual](#)

Digital business telephone system (878 pages)

[Telephone Accessories Toshiba DKT3014-SDL Quick Reference Manual](#)

Dkt / ipt telephone (2 pages)

[Telephone Accessories Toshiba STRATA CTX Installation Manual](#)

Attendant console (24 pages)

[Telephone Accessories Toshiba Strata AirLink User Manual](#)

External wireless handset (47 pages)

[Telephone Accessories Toshiba Strata CT Manual](#)

Acad agent guide (37 pages)

[Telephone Accessories Toshiba Strata DK User Manual](#)

Standard telephone digital business telephone systems (24 pages)

Summary of Contents for Toshiba Perception 4000

[Page 1](#) TOSHIBA REFERENCE PERCEPTION BUSINESS TELEPHONE SOLUTIONS 4000...

[Page 2](#) Menu Options Menu Options Menu Options Menu Options Menu Options Select: Menu Options: CONFIG • Maintain System Tables REPORTS • Print hard copy reports for System Rules, Part Rules, and Configuration Questions PROCESS • Select and update a sales quote INSTALL •...

[Page 3: Configuration Maintenance](#)

Enter Executes a screen selection/transaction. Configuration Configuration Configuration Configuration Configuration To Maintain System Maintenance Maintenance Maintenance Maintenance Maintenance Tables: ¶ Pull down the CONFIG Menu. ¶ Select the table to update: • System Rules • Part Rules • Questions • Authorization ¶...

[Page 4](#) Save Changes to System Rules: After updating files in the System Rules Menu: ¶ Press Esc. ¶ The Save Changes window displays. ¶ Press Enter on the Yes option in the window. The changes are saved. Part Rules Table ¶ Select the table to update.

[Page 5](#) component to be deleted. ¶ Press Delete. ¶ A confirmation window appears. ¶ Press

Enter on the Yes option. ¶ The component is deleted. Insert a Component: When the appropriate Component Table displays: ¶ Press Enter. ¶ A blank Component Information window appears.

[Page 6](#) Add a Question: ¶ With the Questions Table displayed, press Enter. ¶ A blank Question Data window displays. ¶ Enter question information, including part numbers affected by this question. ¶ When finished entering data, press Esc when the Edit/Effects window appears. ¶...

[Page 7](#) ¶ Select the option to print to a printer or to a file. ¶ If printing to a file, enter the file name. ¶ Press Enter. Processing To Update a Sales Quotes Quote: ¶ Pull down the PROCESS menu to display the Select Quote option.

[Page 8](#) ¶ Press Enter to save the quote. ¶ Press Enter to print the quote, or select No to display the Process pop-up window. ¶ Press Enter to create an AS400 file. Delete a Quote: Use the procedures listed under Delete a Component when the Authorization Number pop-up window is displayed.

[Page 9](#) Press Enter to create an AS400 file. Delete a Quote: Use the procedures listed under Delete a Component when the Authorization Number pop-up window is displayed. TOSHIBA Toshiba America Information Systems, Inc. Telecommunication Systems Division 9740 Irvine Boulevard, Irvine, CA 92718 (949) 583-3700...