

Ic Radiation Exposure Statement For Canada - Asus E502M E-Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114


-

[Table of Contents](#)

•

Bookmarks

--



IC Radiation Exposure Statement for Canada

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. To maintain compliance with IC RF exposure requirements, please avoid direct contact to the transmitting antenna during transmitting. End users must follow the specific operating instructions for

satisfying RF exposure compliance.

Operation is subject to the following two conditions:

.

This device may not cause interference and

.

This device must accept any interference, including interference that may cause undesired operation of the device.

To prevent radio interference to the licensed service (i.e. co-channel Mobile

Satellite systems) this device is intended to be operated indoors and away from

windows to provide maximum shielding. Equipment (or its transmit antenna) that

is installed outdoors is subject to licensing.

This device complies with Industry Canada licence-exempt RSS standard(s).

100

Notebook PC E-Manual

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

[1](#)

...

[97](#)

[98](#)

[99](#)

100

[101](#)

[102](#)

[103](#)

[104](#)

Quick Links:

[Table of Contents](#)

[Getting to Know Your Notebook Pc](#)

[Chapter 5: Upgrading Your Notebook Pc](#)

[Installing the Hard Disk Drive](#)

[Hardware Faqs](#)

Related Manuals for Asus E502M

[Laptop Asus E5165 User Manual](#)

Asus laptop user manual (108 pages)

[Laptop Asus ASUSPRO ESSENTIAL PU500CA User Manual](#)

(100 pages)

[Laptop Asus ASUSPRO ESSENTIAL P55VA User Manual](#)

(108 pages)

[Laptop Asus A550CA E-Manual](#)

User's manual for english edition (128 pages)

[Laptop Asus K42JY User Manual](#)

Notebook pc (110 pages)

[Laptop Asus NX90JN User Manual](#)

Asus nx90jn: user guide (108 pages)

[Laptop ASUS PU550C E-Manual](#)

Notebook pc (140 pages)

[Laptop Asus N73JF User Manual](#)

Notebook pc (112 pages)

[Laptop ASUS E5946 User Manual](#)

Notebook pc with internal modem (118 pages)

[Laptop Asus X552W E-Manual](#)

(118 pages)

[Laptop Asus G73JH User Manual](#)

Notebook pc (30 pages)

[Laptop Asus PU500C User Manual](#)

(102 pages)

[Laptop Asus E502MA E-Manual](#)

Notebook pc (120 pages)

[Laptop Asus E5462 User Manual](#)

(114 pages)

[Laptop Asus E510MA Series Disassembly Procedure](#)

(47 pages)

[Laptop Asus E410KA Repair Manual](#)

(29 pages)

Related Content for Asus E502M

[ZenBook Pro UX550VD-BN067T Ic Radiation Exposure Statement For Canada](#)

Asus ZenBook Pro UX550VD-BN067T

[B9440FA Ic Radiation Exposure Statement For Canada](#)

Asus B9440FA

[Transformer Book Ic Radiation Exposure Statement For Canada](#)

Asus Transformer Book

[TP401MA Ic Radiation Exposure Statement For Canada](#)

Asus TP401MA

[X555QG XO108T Ic Radiation Exposure Statement For Canada](#)

Asus X555QG XO108T

[ROG Strix GL503VM-GZ128T Ic Radiation Exposure Statement For Canada](#)

Asus ROG Strix GL503VM-GZ128T

[ROG G501VW FW106T Ic Radiation Exposure Statement For Canada](#)

Asus ROG G501VW FW106T

[PRO ESSENTIAL Ic Radiation Exposure Statement For Canada](#)

Asus PRO ESSENTIAL

This manual is also suitable for:

E502sL502mL502sR517sR517mX502s ... [Show all](#)