

Front Side - Asus E502M E-Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114


-

[Table of Contents](#)

•

Bookmarks

--



Front Side


Status indicators

The status indicators help identify the current hardware status of your Notebook PC.

22

Power indicator

The power indicator lights up when the Notebook PC is turned on and blinks slowly when the Notebook PC



is in sleep mode.

Two-color battery charge indicator

The two-color LED provides a visual indication of the battery's charge status. Refer to the following table for details:

Notebook PC E-Manual

[Table of Contents](#)

1
...
19
20
21
22
23
24
25
26

Quick Links:

[Table of Contents](#)

[Getting to Know Your Notebook Pc](#)

[Chapter 5: Upgrading Your Notebook Pc](#)

[Installing the Hard Disk Drive](#)

[Hardware Faqs](#)

Related Manuals for Asus E502M

[Laptop Asus E5165 User Manual](#)

Asus laptop user manual (108 pages)

[Laptop Asus ASUSPRO ESSENTIAL PU500CA User Manual](#)

(100 pages)

[Laptop Asus ASUSPRO ESSENTIAL P55VA User Manual](#)

(108 pages)

[Laptop Asus A550CA E-Manual](#)

User's manual for english edition (128 pages)

[Laptop Asus K42JY User Manual](#)

Notebook pc (110 pages)

[Laptop Asus NX90JN User Manual](#)

Asus nx90jn: user guide (108 pages)

[Laptop ASUS PU550C E-Manual](#)

Notebook pc (140 pages)

[Laptop Asus N73JF User Manual](#)

Notebook pc (112 pages)

[Laptop ASUS E5946 User Manual](#)

Notebook pc with internal modem (118 pages)

[Laptop Asus X552W E-Manual](#)

(118 pages)

[Laptop Asus G73JH User Manual](#)

Notebook pc (30 pages)

[Laptop Asus PU500C User Manual](#)

(102 pages)

[Laptop Asus E502MA E-Manual](#)

Notebook pc (120 pages)

[Laptop Asus E5462 User Manual](#)

(114 pages)

[Laptop Asus E510MA Series Disassembly Procedure](#)

(47 pages)

[Laptop Asus E410KA Repair Manual](#)

(29 pages)

Related Content for Asus E502M

[E3480 Front Side](#)

Asus E3480

[Eee PC 1015 Series Front Side](#)

Asus Eee PC 1015 Series

[ProArt StudioBook H700GV-AV023R Front Side](#)

Asus ProArt StudioBook H700GV-AV023R

[ROG G501VW FW106T Front Side](#)

Asus ROG G501VW FW106T

[PRO ESSENTIAL Front Side](#)

Asus PRO ESSENTIAL

[ROG G752VS GC018T Front Side](#)

Asus ROG G752VS GC018T

[VivoBook Max X541UV XX040T Front Side](#)

Asus VivoBook Max X541UV XX040T

[E14715 Front Side](#)

Asus E14715

This manual is also suitable for:

E502sL502mL502sR517sR517mX502s ... [Show all](#)