

Getting Started; Charge Your Notebook Pc - Asus E502M E-Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114


-

[Table of Contents](#)

•

Bookmarks

--



Getting started

Charge your Notebook PC

A.

Connect the AC power cord to the AC/DC adapter.

B.

Plug the AC power adapter into a 100V~240V power source.

C.

Connect the DC power connector into your Notebook PC's power (DC) input.

Charge the Notebook PC for 3 hours before using it in battery mode for the first time.

NOTE: The power adapter may vary in appearance, depending on models and your region.

IMPORTANT!

Power adapter information:

- Input voltage: 100-240Vac
- Input frequency: 50-60Hz
- Rating output current: 1.75A (33W)
- Rating output voltage: 19V

26

Notebook PC E-Manual



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
23
24
25
26
27
28
29
30

Quick Links:

[Table of Contents](#)

[Getting to Know Your Notebook Pc](#)

[Chapter 5: Upgrading Your Notebook Pc](#)

[Installing the Hard Disk Drive](#)

[Hardware Faqs](#)

Related Manuals for Asus E502M

[Laptop Asus E5165 User Manual](#)

Asus laptop user manual (108 pages)

[Laptop Asus ASUSPRO ESSENTIAL PU500CA User Manual](#)

(100 pages)

[Laptop Asus ASUSPRO ESSENTIAL P55VA User Manual](#)

(108 pages)

[Laptop Asus A550CA E-Manual](#)

User's manual for english edition (128 pages)

[Laptop Asus K42JY User Manual](#)

Notebook pc (110 pages)

[Laptop Asus NX90JN User Manual](#)

Asus nx90jn: user guide (108 pages)

[Laptop ASUS PU550C E-Manual](#)

Notebook pc (140 pages)

[Laptop Asus N73JF User Manual](#)

Notebook pc (112 pages)

[Laptop ASUS E5946 User Manual](#)

Notebook pc with internal modem (118 pages)

[Laptop Asus X552W E-Manual](#)

(118 pages)

[Laptop Asus G73JH User Manual](#)

Notebook pc (30 pages)

[Laptop Asus PU500C User Manual](#)

(102 pages)

[Laptop Asus E502MA E-Manual](#)

Notebook pc (120 pages)

[Laptop Asus E5462 User Manual](#)

(114 pages)

[Laptop Asus E510MA Series Disassembly Procedure](#)

(47 pages)

[Laptop Asus E410KA Repair Manual](#)

(29 pages)

Related Content for Asus E502M

[E203MA FD018TS Getting Started](#)

Asus E203MA FD018TS

[ZenBook 14X Getting Started](#)

Asus ZenBook 14X

[X515JA Getting Started](#)

Asus X515JA

[ROG GX701GX EV021T Getting Started](#)

Asus ROG GX701GX EV021T

[TUF Gaming FX505DV AL072T Getting Started](#)

Asus TUF Gaming FX505DV AL072T

[N580VD-FI523T Getting Started](#)

Asus N580VD-FI523T

[VivoBook Pro N580GD Getting Started](#)

Asus VivoBook Pro N580GD

[ROG G703GXR EV002T Getting Started](#)

Asus ROG G703GXR EV002T

This manual is also suitable for:

E502sL502mL502sR517sR517mX502s ... [Show all](#)