

Using The Touchpad; Moving The Pointer - Asus E502M E-Manual

1	
2	
Table Of Contents	
3	
4	
5	
6	
7	
8	
9	
10	
11	
12	
13	
14	
15	
16	
17	

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114


-

[Table of Contents](#)

•

Bookmarks

--



Using the touchpad

Moving the pointer

You can tap anywhere on the touchpad to activate its pointer, then slide

your finger on the touchpad to move the pointer onscreen.

Slide horizontally

Slide vertically

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
26
27
28
29
30
31
32
33

Quick Links:

[Table of Contents](#)

[Getting to Know Your Notebook Pc](#)

[Chapter 5: Upgrading Your Notebook Pc](#)

[Installing the Hard Disk Drive](#)

[Hardware Faqs](#)

Related Manuals for Asus E502M

[Laptop Asus E5165 User Manual](#)

Asus laptop user manual (108 pages)

[Laptop Asus ASUSPRO ESSENTIAL PU500CA User Manual](#)

(100 pages)

[Laptop Asus ASUSPRO ESSENTIAL P55VA User Manual](#)

(108 pages)

[Laptop Asus A550CA E-Manual](#)

User's manual for english edition (128 pages)

[Laptop Asus K42JY User Manual](#)

Notebook pc (110 pages)

[Laptop Asus NX90JN User Manual](#)

Asus nx90jn: user guide (108 pages)

[Laptop ASUS PU550C E-Manual](#)

Notebook pc (140 pages)

[Laptop Asus N73JF User Manual](#)

Notebook pc (112 pages)

[Laptop ASUS E5946 User Manual](#)

Notebook pc with internal modem (118 pages)

[Laptop Asus X552W E-Manual](#)

(118 pages)

[Laptop Asus G73JH User Manual](#)

Notebook pc (30 pages)

[Laptop Asus PU500C User Manual](#)

(102 pages)

[Laptop Asus E502MA E-Manual](#)

Notebook pc (120 pages)

[Laptop Asus E5462 User Manual](#)

(114 pages)

[Laptop Asus E510MA Series Disassembly Procedure](#)

(47 pages)

[Laptop Asus E410KA Repair Manual](#)

(29 pages)

Related Content for Asus E502M

[ROG Strix GL703GM Using The Touchpad](#)

Asus ROG Strix GL703GM

[StudioBook 15 H500GV Using The Touchpad](#)

Asus StudioBook 15 H500GV

[EJ026T Using The Touchpad](#)

Asus EJ026T

[Chromebook C523NA Gestures For The Touch Screen Panel And Touchpad](#)

Asus Chromebook C523NA

[E203MA FD018TS Using The Touchpad](#)

Asus E203MA FD018TS

[ZenBook 14X Gestures For The Touch Screen Panel And Touchpad](#)

Asus ZenBook 14X

[X515JA Using The Touchpad](#)

Asus X515JA

[ROG GX701GX EV021T Using The Touchpad](#)

Asus ROG GX701GX EV021T

This manual is also suitable for:

E502sL502mL502sR517sR517mX502s ... [Show all](#)