

Launching The Start Menu; Opening Programs From The Start Menu - Asus E502M E-Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114


-

[Table of Contents](#)

•

Bookmarks

--



Launching the Start menu

Position your mouse pointer over the Start button in the lower-left corner of your desktop then click it.

Press the Windows logo key

Opening programs from the Start menu

One of the most common uses of the Start menu is opening programs



installed on your Notebook PC.

Position your mouse pointer over the program then click to launch it.

Use the arrow keys to browse through the programs.

Press

NOTE: Select All apps at the bottom of the left pane to display a full list of programs and folders on your Notebook PC in alphabetical order.

40

to launch it.

on your keyboard.

Notebook PC E-Manual



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
37
38
39
40
41
42
43
44

Quick Links:

[Table of Contents](#)

[Getting to Know Your Notebook Pc](#)

[Chapter 5: Upgrading Your Notebook Pc](#)

[Installing the Hard Disk Drive](#)

[Hardware Faqs](#)

Related Manuals for Asus E502M

[Laptop Asus E5165 User Manual](#)

Asus laptop user manual (108 pages)

[Laptop Asus ASUSPRO ESSENTIAL PU500CA User Manual](#)

(100 pages)

[Laptop Asus ASUSPRO ESSENTIAL P55VA User Manual](#)

(108 pages)

[Laptop Asus A550CA E-Manual](#)

User's manual for english edition (128 pages)

[Laptop Asus K42JY User Manual](#)

Notebook pc (110 pages)

[Laptop Asus NX90JN User Manual](#)

Asus nx90jn: user guide (108 pages)

[Laptop ASUS PU550C E-Manual](#)

Notebook pc (140 pages)

[Laptop Asus N73JF User Manual](#)

Notebook pc (112 pages)

[Laptop ASUS E5946 User Manual](#)

Notebook pc with internal modem (118 pages)

[Laptop Asus X552W E-Manual](#)

(118 pages)

[Laptop Asus G73JH User Manual](#)

Notebook pc (30 pages)

[Laptop Asus PU500C User Manual](#)

(102 pages)

[Laptop Asus E502MA E-Manual](#)

Notebook pc (120 pages)

[Laptop Asus E5462 User Manual](#)

(114 pages)

[Laptop Asus E510MA Series Disassembly Procedure](#)

(47 pages)

[Laptop Asus E410KA Repair Manual](#)

(29 pages)

Related Content for Asus E502M

[E10750 Launching The Start Menu](#)

Asus E10750

[E10295 Launching The Start Menu](#)

Asus E10295

[E10584 Launching The Start Menu](#)

Asus E10584

[E12001 Launching The Start Menu](#)

Asus E12001

[VivoBook Flip TP201SA Launching The Start Menu](#)

Asus VivoBook Flip TP201SA

[G701VO Launching The Start Menu](#)

Asus G701VO

[G series Launching The Start Menu](#)

Asus G series

[GX700V Launching The Start Menu](#)

Asus GX700V

This manual is also suitable for:

E502sL502mL502sR517sR517mX502s ... [Show all](#)