

Configuring A Static Ip Network Connection - Asus E502M E-Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67

68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114


-

[Table of Contents](#)

•

Bookmarks

--



7.

8.

9.

10.

11.

12.

13.

Configuring a static IP network connection

- 1.
- 2.
- 3.
- 4.

Notebook PC E-Manual

Return to the Network and Sharing Center window then select Set up a new connection or network.

Select Connect to the Internet then select Next. Select Broadband (PPPoE).

Type your User name, Password, and Connection name then select Connect.

Select Close to finish the configuration.



Select

on the taskbar then select the connection you just created.

Type your user name and password then select Connect to start connecting to the Internet.

Repeat steps 1 to 5 under Configuring a dynamic *IP/PPPoE network connection*.

Select Use the following IP address.

Type the IP address, Subnet mask and Default gateway from your service provider.

If needed, you can also type the preferred DNS server address and alternate DNS server address then select OK.

55

[Previous Page](#)
[Next Page](#)

1
...
52
53
54
55
56
57
58
59

Quick Links:

[Table of Contents](#)

[Getting to Know Your Notebook Pc](#)

[Chapter 5: Upgrading Your Notebook Pc](#)

[Installing the Hard Disk Drive](#)

[Hardware Faqs](#)

Related Manuals for Asus E502M

[Laptop Asus E5165 User Manual](#)

Asus laptop user manual (108 pages)

[Laptop Asus ASUSPRO ESSENTIAL PU500CA User Manual](#)

(100 pages)

[Laptop Asus ASUSPRO ESSENTIAL P55VA User Manual](#)

(108 pages)

[Laptop Asus A550CA E-Manual](#)

User's manual for english edition (128 pages)

[Laptop Asus K42JY User Manual](#)

Notebook pc (110 pages)

[Laptop Asus NX90JN User Manual](#)

Asus nx90jn: user guide (108 pages)

[Laptop ASUS PU550C E-Manual](#)

Notebook pc (140 pages)

[Laptop Asus N73JF User Manual](#)

Notebook pc (112 pages)

[Laptop ASUS E5946 User Manual](#)

Notebook pc with internal modem (118 pages)

[Laptop Asus X552W E-Manual](#)

(118 pages)

[Laptop Asus G73JH User Manual](#)

Notebook pc (30 pages)

[Laptop Asus PU500C User Manual](#)

(102 pages)

[Laptop Asus E502MA E-Manual](#)

Notebook pc (120 pages)

[Laptop Asus E5462 User Manual](#)

(114 pages)

[Laptop Asus E510MA Series Disassembly Procedure](#)

(47 pages)

[Laptop Asus E410KA Repair Manual](#)

(29 pages)

Related Content for Asus E502M

[ROG G752VS GC018T Configuring A Static Ip Network Connection](#)

Asus ROG G752VS GC018T

[TUF Gaming A15 Configuring A Static Ip Network Connection](#)

Asus TUF Gaming A15

[TUF Gaming FX504 Configuring A Static Ip Network Connection](#)

Asus TUF Gaming FX504

[P452L Configuring A Static Ip Network Connection](#)

Asus P452L

[REPUBLIC OF GAMERS G Series Configuring A Static Ip Network Connection](#)

Asus REPUBLIC OF GAMERS G Series

[G57JX Configuring A Static Ip Network Connection](#)

Asus G57JX

[E502MA Configuring A Static Ip Network Connection](#)

Asus E502MA

[N591LN Configuring A Static Ip Network Connection](#)

Asus N591LN

This manual is also suitable for:

E502sL502mL502sR517sR517mX502s ... [Show all](#)