



Sanyo RM-6090 Instruction Manual

Am/fm digital alarm clock radio

1

2

3

4

5

6


7

8

9

Table Of Contents

10



•

[Table of Contents](#)

•

Bookmarks

Quick Links


[1 Back-Up Battery Installation](#)

[2 Adjusting the Clock](#)

[3 Wake-Up Time Setting](#)

[4 Listening to the Radio](#)

[Download this manual](#)



RM-6090

INSTRUCTION MANUAL

AM/FM Digital Alarm Clock Radio

SA

Table of Contents

[Next Page](#)

1
2
3
4
5

Related Manuals for Sanyo RM-6090

[Clock Radio SANYO RM-630 User Manual](#)

Am/fm clock radio with night light (11 pages)

[Clock Radio SANYO RM-5750 Instruction Manual](#)

Am/fm digital alarm clock radio (8 pages)

[Clock Radio SANYO RM-6860 Instruction Manual](#)

Am/fm digital alarm clock radio (8 pages)

[Clock Radio SANYO RM-7970 Instruction Manual](#)

Am/fm clock radio (2 pages)

[Clock Radio SANYO RM-DB5 Instruction Manual](#)

Dab+/fm clock radio (12 pages)

[Clock Radio SANYO RM-X106W Instruction Manual](#)

Am/fm clock radio (8 pages)

[Clock Radio Sanyo RM-X105 Instruction Manual](#)

(4 pages)

[Clock Radio Sanyo RM-X100 Instruction Manual](#)

(6 pages)

[Clock Radio Sanyo RM-5090 Instruction Manual](#)

(10 pages)

[Clock Radio Sanyo RM-D500 Service Manual](#)

Compact disc dual alarm clock radio (14 pages)

[Clock Radio Sanyo RM-D500 Instruction Manual](#)

Compact disc dual alarm clock radio (13 pages)

[Clock Radio Sanyo RM-D500 Service Manual](#)

Compact disc dual alarm clock radio (14 pages)

[Clock Radio Sanyo RM-X500 Instruction Manual](#)

Am/fm (15 pages)

[Clock Radio Sanyo RM 5900 Service Manual](#)

Digital clock radio (9 pages)

[Clock Radio Sanyo RM-X100 AU Instruction Manual](#)

(6 pages)

[Clock Radio Sanyo RM5008 Service Manual](#)

Digital clock radio (10 pages)

Summary of Contents for Sanyo RM-6090

[Page 1](#) RM-6090 INSTRUCTION MANUAL AM/FM Digital Alarm Clock Radio...

[Page 2](#) PRECAUTIONS CAUTION: THE APPARATUS SHALL NOT BE EXPOSED TO DRIPPING OR SPLASHING. NO OBJECTS FILLED WITH LIQUIDS, SUCH AS VASES, SHALL BE PLACED ON THE APPARATUS. The rating label is located on the bottom of the unit. Keep the radio away from heating appliances and electric sources that could cause static on the radio such as fluorescent lamps and motors.

[Page 3](#) CONTROLS 1. Earphone socket (EAR) 2. PM indicator (PM) 3. Time button (TIME) 4. Volume control (VOLUME) 5. Alarm select switch (ALARM 1/ALARM 1+2/ALARM 2) 6. Alarm

button (ALARM) 7. Sleep button (SLEEP) 8. Snooze button (SNOOZE) 9. Display 10. Fast up button (FAST UP) 11.

[Page 4: Back-Up Battery Installation](#)

BACK-UP BATTERY INSTALLATION Connect a standard 9V (006P/6F22) battery (not included) to the snap-on terminal matching the polarity. **NOTE:** If the time display is blinking when the mains returns after a failure, the back-up battery is exhausted and must be replaced. **BATTERY BACK-UP SYSTEM** This unit incorporates a battery back-up system which protects the clock, sleep timer and wake-up alarm functions from the mains failure with the battery installed.

[Page 5: Power Supply](#)

POWER SUPPLY Connect the mains lead to an AC 230-240V, 50Hz wall outlet. The function switch is mounted on the secondary side. The unit is not disconnected from mains, even switched off. **Earphone** Connect an earphone (not supplied) to the EAR socket for monitoring or for private listening. The speakers are automatically disconnected when the earphone is connected.

[Page 6: Listening To The Radio](#)

LISTENING TO THE RADIO 1. Set the FUNCTION switch to ON. 2. Set the BAND switch to AM or FM. 3. Turn the TUNING control to tune in a station. 4. Adjust the VOLUME control as desired. 5. To turn the radio off, set the function switch to OFF. **Aerials** For AM reception, rotate or relocate the unit to a different position to improve the reception of a distant or weak station.

[Page 7: Using The Wake-Up Timer](#)

NOTE: Do not set the ALARM switch to ALARM 1+2 when wake up time setting. If you want to check the time setting, simply push the ALARM button. **USING THE WAKE-UP TIMER** 1. If you want to wake up with the radio, tune in the station and adjust the volume level first.

[Page 8: Using The Sleep Timer](#)

USING THE SLEEP TIMER 1. Set the FUNCTION switch to OFF, ALARM-RADIO or ALARM-BUZZER. 2. Push the SLEEP button. "0:59" (59 minutes) appears. The radio turns on and will turn off automatically after 59 minutes. To select the desired time, while holding the SLEEP button down, push the FAST UP or SLOW UP button to select the sleep time.

[Page 9: Specifications](#)

FM: 87.5 - 108 MHz Antennas: Specifications subject to change without Built-in ferrite bar and antenna lead notice. wire Power source: AC: 230-240V, 50 Hz DC: 9 V (Clock black-up, 006P type, not supplied) SANYO Electric Co., Ltd. (AU) 1AD6P1P1923-- Printed in China...