




Sanyo FW55D25F Owner's Manual

55" class 1080p led lcd hdtv, (led backlight) hdtv

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37



•

[Table of Contents](#)

•

Troubleshooting

•

Bookmarks

Quick Links

[1 Features](#)

[2 Downloading Software](#)

[3 Troubleshooting](#)

[Download this manual](#)



LCD TV

(LED BACKLIGHT)

HDTV

Owner's Manual

Manual del Propietario

ES

FR

Manuel du Propriétaire

FW55D25F

**To obtain a more detailed Electronic Copy of this
Manual or much further contents, go to**

SA

ES

Para obtener una Copia Electronica detallada de este Manual o mucho mayor contenido, visite

FR

Pour obtenir une Copie Electronique plus detaillee de ce Manuel ou pour aller encore plus loin, visitez

Need help?

¿ Necesita ayuda?

ES

Sitio Web en:

Besoin d'aide?

FR

Site Web à l'adresse:

sanyoav.com

Please Call Toll Free 1 866 212 0436 or visit our Web Site above:

Llame por favor sin costo al 1 866 212 0436 ó visite nuestro

Appelez notre numéro gratuit à 1 866 212 0436 ou visitez notre

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Chapters

Table of Contents 2

5 Making More Use With Your TV 2 19

Related Manuals for Sanyo FW55D25F

[HDTV Sanyo FW55D25F Quick Start](#)

55" class 1080p led lcd hdtv (2 pages)

[LCD TV Sanyo FW50D36F Owner's Manual](#)

(39 pages)

[LED TV Sanyo FW32D06F Quick Start Manual](#)

32 class led lcd hdtv (2 pages)

[HDTV Sanyo FW32D25T Quick Start Manual](#)

32" class 1080p led lcd hdtv (2 pages)

[HDTV Sanyo FW65D25T Owner's Manual](#)

32" class 1080p led lcd hdtv (30 pages)

[HDTV Sanyo DP19649 Owner's Manual](#)

18.5"/26" lcd hdtv (48 pages)

[HDTV Sanyo DP47840 Owner's Manual](#)

47" 1080p hdtv lcd (56 pages)

[HDTV Sanyo DP19649 Setup Manual](#)

Sanyo dp19649: quick start (2 pages)

[HDTV Sanyo DP26647A - 26 Wide-Screen LCD HDTV Owner's Manual](#)

Lcd hdtv (52 pages)

[HDTV Sanyo DP42647 Owner's Manual](#)

High-definition digital television (48 pages)

[HDTV Sanyo DP19647 Owner's Manual](#)

Sanyo owner's manual television dp19647 (46 pages)

[HDTV Sanyo DP37647 Owner's Manual](#)

High-definition digital television (48 pages)

[HDTV Sanyo DP19241 Setup Manual](#)

19"class (18.5" diag.) led lcd 720p 60hz hdtv (2 pages)

[HDTV Sanyo DP55360 Owner's Manual](#)

55" 1080p hdtv lcd 120hz (40 pages)

[HDTV Sanyo HT27744 Owner's Manual](#)

High-definition digital true flat-screen television (72 pages)

[HDTV Sanyo DP42851 User Manual](#)

Internet ready hdtv (24 pages)

Summary of Contents for Sanyo FW55D25F

[Page 1](#) HDTV Owner's Manual Manual del Propietario Manuel du Propriétaire FW55D25F To obtain a more detailed Electronic Copy of this Manual or much further contents, go to Para obtener una Copia Electronica detallada de este Manual o mucho mayor contenido, visite...

[Page 2: Table Of Contents](#)

English Contents 1 Notice 5 Making more use with your TV Displaying the Main Menu 2 Important PictureSound Positioning the TV Setup Regulatory Notices Autoprogram Environmental Care Channel list Preparing to Move / Ship the Unit Add channels Antenna Confirmation 3 Getting Started...

[Page 3](#) English Register Online at sanyo-av.com today to get the very most from your purchase. Registering your model with SANYO makes you eligible for all of the valuable benefits listed below, so don't miss out. Register Online at sanyo-av.com to ensure:...

[Page 4: Important Safety Instructions](#)

Wall Mount Bracket Kit Funai is not liable for these types of accidents or Brand Model # Screw dimension injuries noted below. FW55D25F SANUS PLA50B M6 x 0.472" (12mm) • Install the Wall Mount Bracket on a sturdy vertical wall. •...

[Page 5: Notice](#)

Any Modifications to the apparatus must be Approved by Funai. SANYO is a registered trademark of SANYO Electric Co., Ltd. The user could lose the authority to operate this apparatus if an and is used by Funai Electric Co., Ltd. and Funai Corporation, Inc.

[Page 6: Important](#)

• Depending on the environment, the End of Life Directives temperature of this Unit may increase slightly. SANYO pays a lot of attention to produce This is not a malfunction. environmental-friendly products in green focal areas. Your new • Avoid a place with drastic temperature changes.

[Page 7: Getting Started](#)

Quantity Size Closed Caption decoder ● Built-in Closed Caption decoder displays text for Closed Caption supported Programs. M4 x 0.472" (12mm) FW55D25F MTS / SAP tuner ● M5 x 0.472" (12mm) Audio can be selected from the Remote Control. Auto Standby ●...

[Page 8: Stand Assembly](#)

English Stand Assembly Managing cables Route your Antenna cable and all other cables through the cable management tie at the back of the TV. The holder helps keep your cables tidy and easily manageable. Attach the cable management tie as illustrated below. x...

[Page 9: Remote Control](#)

English Remote Control a B (POWER / STANDBY) Turns the TV On from Standby or Off to Standby mode. b SOURCE Selects Connected Devices. c SLEEP Sets Sleep Timer. d BACK Returns to the previous Menu operation. e MENU Opens the Main On-screen Menu. f SAP Selects Audio mode (MONO / STEREO / SAP) / Audio language.

[Page 10: Control Panel](#)

English a B (POWER / STANDBY) Control Panel Turns the TV On from Standby or Off to Standby mode. b SOURCE Selects Connected Devices. c MENU Opens the Main On-screen Menu. d CH H / I Selects a Channel in the Memorized Channel Ring (Low to High or High to Low).

[Page 11: Connecting The Antenna, Cable Or Satellite](#)

English Connecting the Antenna, Cable or Satellite Connecting a Set-top Box, Blu-ray Disc / DVD Recorder via Composite Connectors and Analog Audio Be sure your Antenna or another Device is connected properly before Do Not place your Recorder too close to the Screen because some plugging in the AC Power Cord.

[Page 12: Selecting Your Connection Quality](#)

HDMI-DVI Connection Note(s) This Unit can be connected to your Device that has a DVI Terminal. SANYO HDMI supports HDCP (High-bandwidth Digital Contents Protection). HDCP is a form ● of Digital Rights Management that protects High-Definition content in Blu-ray Discs or Use an HDMI-DVI Conversion Cable for this Connection and it requires DVDs.

[Page 13: Component Analog Video Connection](#)

English Component Analog Video Connection Digital Audio Output Connection Component Analog Video Connection offers Better Picture quality for If you connect this Unit to an External Digital Audio Device, you can enjoy Video Devices connected to the Unit. multi-channel Audio like 5.1ch Digital Broadcasting sound. If you connect to the Unit's Component Video (Y/Pb/Pr) Input jacks, Use a Digital Audio Optical Cable to connect the Unit to External Digital connect Analog Audio Cables to the Analog Audio (L/R) Input jacks.

[Page 14: Pc Connection](#)

English PC Connection Note(s) Please purchase the HDMI-DVI Conversion Cable that has a ferrite core. HDMI Connection ● The following operations may reduce noise. ● This Unit can be connected to your PC that has an HDMI terminal. Attach a ferrite core to the AC Power Cord of your PC. -...

[Page 15: Initial Setup](#)

English These Operations are accessible by Remote Control. Use H I to select the desired Location setting, then press OK. Some may also be accessible by the Main Unit's Control Home is the ENERGY STAR qualified setting. Panel. Initial setup Initial Setup Retail This section will guide you through the Unit's Initial setting which...

[Page 16: Use Your Tv](#)

English 4 Use your TV Switching Channels Switching on your TV and putting it in Standby mode Remote Control Remote Control To Turn the TV On from Standby or Off to Standby Press B on the Side of the Unit or the Remote Control. ●...

[Page 17: Watching Channels From An External Device](#)

English Watching Channels from an External Sleep Timer Device Sleep Timer can set the Unit to go into Standby mode after an incremental period of time. Switching Each Input Mode can easily switch with the Remote Control between TV (DTV or Analog TV) and External Devices when they are connected to the Unit.

[Page 18: Changing Pix Shape](#)

English For PC Input signal Changing Pix Shape Display Modes can be Selected when your TV receives a 16:9 or 4:3 Video Signal. Three types of Display Modes can be Selected for a PC Input Signal. Normal Full Unscaled Press PIX SHAPE A Repeatedly to Switch the TV Aspect Ratio. This Unit can also be connected to your PC that has a DVI Terminal.

[Page 19: Making More Use With Your Tv](#)

English 5 Making more use with your TV Use H I to select the desired Menu and an item, then press OK or use H I J K to determine the setting. This section describes the overview of the Main Menu displayed when you press MENU.

[Page 20: Picture](#)

English You can set a Particular Picture Quality using Advanced ● Picture settings. Before you begin: Color alignment Normal Picture You must set Home in Location. L p. 29 Sound Noise reduction Otherwise, personalized Picture and Sound settings will not be Ambient light sensor Setup memorized after the Unit goes into Standby Mode.

[Page 21: Sound](#)

English You can select Audio Output through a Digital Audio Output connector. Sound to Output Multichannel Signals (When the Audio of the Content is Multichannel Before you begin: Digital output PCM, it will be Output in PCM even format if Multichannel is selected.) You must set Location to Home.

[Page 22: Setup](#)

English Setup Autoprogram Before you begin: Please wait while the system is scanning for Make sure the Unit is connected to Antenna or Cable. channels. Auto programming may take more than 20 minutes Press MENU and use H I to select Setup, then press OK. to complete.

[Page 23: Add Channels](#)

English Features Add channels Use H I to select Add channels, then press OK. Display Setup using Home Menu and use H I to select Features, then press OK. Use the NUMBER keys to enter the number of the channel you want to add, then press OK.

[Page 24](#) English Cable / NTSC (Analog) TV Operation Note(s) Closed Caption will NOT be displayed when you are using an HDMI Connection. ● The primary Closed Captions and Digital caption service that you can switch differs depending on the broadcast format. ●...

[Page 25: Child And Ratings Lock](#)

English Channel lock Child and Ratings Lock Particular Channels or External Input modes can be invisible in this You can prevent your children from watching certain Programs or certain function. Channels by locking the TV Controls and by using Ratings. Use H I to Select Channel lock, then press OK.

[Page 26](#) English To set the Sub ratings (displayed in the right column) Setting US Movie and TV Ratings As for TV-Y7, TV-PG, TV-14 or TV-MA, you can further set the Sub US Movie Ratings Lock is the Rating System created by MPAA. ratings to Block Specific Elements within programs.

[Page 27: Pc Settings](#)

English Canadian English or Canadian French Ratings PC settings You can select the Rating for Canadian English or Canadian French This function lets you adjust the PC screen position, clock and phase broadcasting. during PC Input. Use H I to Select Canadian English rating or Canadian French Use J K to adjust Clock setting to stabilize the PC screen and Phase rating, then press OK.

[Page 28: Hdmi-Cec](#)

English Device list HDMI-CEC This function lets you see the product model number or name of This function allows you to operate the linked functions between our Connected Devices. brand Devices with an HDMI-CEC feature and this Unit connecting Use H I to select the desired HDMI-CEC devices listed on the TV through an HDMI cable.

[Page 29: Setting Your Location To Home](#)

English Language Setting your Location to Home You can set the Location of your TV to Home or Retail. Choosing Home Press MENU and use H I to select Language, then press OK. gives you full flexibility to change predefined settings for Picture and Sound.

[Page 30: Usb](#)

English Picture (JPEG) Use H I to select the desired file, then press OK. Your TV is fitted with a USB Connection that enables you to view JPEG photos or watch Motion JPEG files stored on a USB Memory Stick. Picture Connect the USB Memory Stick to the USB terminal on the back of Image1.jpg...

[Page 31: Upgrade Your Tv Software](#)

The TV starts up with the New Software. ● For further assistance, please contact the Call Center. Note(s) Only FAT / DOS-formatted portable memory is supported. ● Use only Software Upgrades that can be found on the SANYO website. ●...

[Page 32: Useful Tips](#)

English 7 Useful tips Question Answer Check the Antenna or Cable Connection to the Main Unit. ● Check the Batteries on the Remote Control. ● Re-insert or replace the AAA Batteries with their Polarities (+/-) as indicated on the Remote Control Battery area. ●...

[Page 33: Troubleshooting](#)

Try moving the Unit to another Location to see if this is the Cause of the ● Universal Remote Control does not work properly. Problem. Refer to the User Manual of the Universal Remote Control for the SANYO ● Ghosts, lines or streaks in picture. (Analog TV- NTSC signal) code.

[Page 34: Information](#)

English 8 Information Glossary Maintenance Analog TV (NTSC) Cabinet Cleaning Acronym that stands for National Television Systems Committee and the Wipe the front panel and other

exterior surfaces of the Unit with a soft ● name of Analog broadcasting standards. cloth.

[Page 35: Specifications](#)

English 9 Specifications Model # FW55D25F Picture Type FHD (Full HD) (1920 x 1080 pixels 60Hz) Aspect Ratio 16:9 Viewing Angles 178° (V) by 178° (H) Built-in Digital / Analog Tuner ATSC (Digital) / NTSC (Analog) Sound Mono / Stereo...

[Page 36: 10 Warranty](#)

Contact the Customer Care Center at: Replacement product can only be sent if all warranty requirements are met. Failure to follow all requirements can sanyo-av.com result in delay. 1 866 212 0436 WHAT IS NOT COVERED - EXCLUSIONS AND LIMITATIONS:...

[Page 37](#) A5GREUH / A5GR0UH ★★★★★...

This manual is also suitable for:

[Fw40d36fFw43d25fFw32d06fFw50d36fFw32d06fom](#)

[Save PDF](#)