


Toshiba RAS-B10N3KV2 Series Owner's Manual

Air conditioner (split type) indoor and outdoor units

1
2
3
4
5
6
7
8
9
10
11

Table Of Contents




•

[Table of Contents](#)

•

Bookmarks

Available languages



Quick Links

- [1 Indoor Unit Display](#)
- [2 Remote Control](#)
- [3 Maintenance](#)


[4 Operation and Performance](#)

[5 Fonctionnement Temporaire](#)

[6 Entretien](#)

[Download this manual](#)

[See also: Installation Manual](#)



OWNER'S MANUAL

AIR CONDITIONER (PITTL)

For general purpose

Indoor unit

RAS-B10, 13, 16, 22N3KV2 Series

RAS-M07, 24N3KV2 Series

Outdoor unit

RAS-10, 13, 16, 22N3AV2 Series

TOSHIBA

RAS-M14GAV-E

RAS-M18UAV-E

RAS-3M13S V

RAS-4M13S V

RAS-3M26UAV-E

RAS-4M27UAV-E

RAS-5M34UAV-E1

TOSHIBA

ENGLISH

ESPAÑOL

FRANÇAIS

ITALIANO

DEUTSCH

PORTUGUÊS

POLSKI

NEDERLANDS


ΕΛΛΗΝΙΚΑ

SVENSKA

SUOMI

NORSK

DANSK



ManualsLib.com

1110650175

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Toshiba RAS-B10N3KV2 Series

[Air Conditioner Toshiba RAS-B10N3KV2 Series Installation Manual](#)

(276 pages)

[Air Conditioner Toshiba RAS-16N3AV2 Series Installation Manual](#)

(124 pages)

[Air Conditioner Toshiba RAS-M07N3KV2 Series Installation Manual](#)

(78 pages)

[Air Conditioner Toshiba RAS-18N3KV2-E1 Installation Manual](#)

(276 pages)

[Air Conditioner toshiba RAS-B10GKVP-E Service Manual](#)

Split type heat pump type/cooling onlytype (134 pages)

[Air Conditioner Toshiba RAS-B10GKVP-E Service Manual](#)

Split type heat pump type/cooling onlytype (133 pages)

[Air Conditioner Toshiba 16N3KVP Series Owner's Manual](#)

(105 pages)

[Air Conditioner Toshiba RAS-B10N3KVP Series Installation Manual](#)

Air conditioner (split type) (80 pages)

[Air Conditioner Toshiba RAS-B10SKVP-E Owner's Manual](#)

Split type; for general public use (31 pages)

[Air Conditioner Toshiba 24N3KV2 Series Owner's Manual](#)

(26 pages)

[Air Conditioner Toshiba RAS-B10SKVP-E Installation Manual](#)

(19 pages)

[Air Conditioner Toshiba RAS-B10SKVP-E Installation Manual](#)

Split type air conditioner (19 pages)

[Air Conditioner Toshiba RAS-4M23SAV-E Installation Manual](#)

Outdoor unit. multi-split type (18 pages)

[Air Conditioner Toshiba RAS-M14GAV-E Installation Manual](#)

Outdoor unit multi-split type (16 pages)

[Air Conditioner Toshiba RAS-\(B\)10UFV Series Installation Manual](#)

Split type indoor unit outdoor unit (13 pages)

[Air Conditioner Toshiba RAS-B10N3KVP series Installation Manual](#)

Split type (9 pages)

Summary of Contents for Toshiba RAS-B10N3KV2 Series

[Page 1](#) OWNER'S MANUAL ENGLISH ESPAÑOL FRANÇAIS ITALIANO DEUTSCH PORTUGUÊS
POLSKI NEDERLANDS ΕΛΛΗΝΙΚΑ SVENSKA SUOMI NORSK DANSK AIR CONDITIONER (SPLIT TYPE)
For general public use Indoor unit RAS-B10, 13, 16, 22N3KV2 Series RAS-M07, 24N3KV2 Series
Outdoor unit RAS-10, 13, 16, 22N3AV2 Series RAS-M14GAV-E RAS-M18UAV-E RAS-3M18SAV-E...

[Page 2: Precautions For Safety](#)

PRECAUTIONS FOR SAFETY The manufacturer shall not assume any liability for the damage caused by not observing the description of this manual. Store this owner's manual in a location where it can be easily accessed when needed. Be sure to read this owner's manual carefully before operating. It is recommended that maintenance be performed by a specialist when the

unit has been operated for a long time.

[Page 3](#) When the air-conditioning unit does not cool or warm, there may be a leakage of refrigerant. Please consult the supplying retail dealership. The refrigerant used in the air-conditioning unit is safe. It will not leak under normal operating conditions but if it leaks into the room and contacts a heat source such as a heater, or stove, it may cause a harmful reaction.

[Page 4: Indoor Unit Display](#)

“ONE-TOUCH” of the button. If you prefer PRE.DEF (Preheat/Defrost) other settings you can select from the many other operating functions of your (Orange) Toshiba unit. TIMER (Yellow) ONE-TOUCH Press : Start the operation.

[Page 5: Maintenance](#)

Setting Everyday Timer OPERATION AND PERFORMANCE Press : Set the ON timer. Press 1. Three-minute protection feature: To prevent the unit from being activated for 3 minutes when suddenly restarted or switched to ON. 2. Preheating operation: Warm up the unit for 5 minutes before blowing warm air. Press : button during the Press...

[Page 6: Mesures De Securite](#)

MESURES DE SECURITE Le fabricant ne saurait être tenu pour responsable en cas de dommages provoqués par le non-respect des consignes de sécurité décrites dans ce manuel. Veuillez à conserver ce manuel de l'utilisateur dans un endroit facile d'accès pour pouvoir le consulter en cas de besoin. Prenez le temps de lire attentivement ce manuel de l'utilisateur avant d'utiliser le produit.

[Page 7](#) Lorsque l'unité de climatisation ne refroidit pas ou ne chauffe pas, cela peut provenir d'une fuite de réfrigérant. Consulter le revendeur. Le réfrigérant utilisé dans le climatiseur est sûr. Il ne fuira pas dans des conditions normales de fonctionnement, mais s'il fuit dans la pièce et entre en contact avec une source de chaleur telle qu'un chauffage ou un poêle, une dangereuse réaction peut survenir.

[Page 8: Fonctionnement Temporaire](#)

«ONE-TOUCH» de la touche. Si vous préférez d'autres réglages, vous pouvez faire votre choix parmi Dégivrage) (Orange) les nombreuses fonctions d'exploitation de votre appareil Toshiba. TIMER (Jaune) ONE-TOUCH Appuyez sur : Démarrez le fonctionnement.

[Page 9: Entretien](#)

Réglage de la minuterie quotidienne FONCTIONS ET PERFORMANCES Appuyez sur : Programmez 1. Fonction de protection de trois minutes: Cette fonction empêche l'appareil Appuyez sur la minuterie de fonctionner pendant 3 minutes environ en cas de remise en marche immédiate après un arrêt de l'appareil. 2.

[Page 10](#) Information according to EMC Directive 2004/108/EC (Name of the manufacturer) TOSHIBA CARRIER (THAILAND) CO., LTD. (Address, city, country) 144/9 MOO 5, BANGKADI INDUSTRIAL PARK, TIVANON ROAD, TAMBOL BANGKADI, AMPHUR MUANG, PATHUMTHANI 12000, THAILAND. (Name of the Importer / Distributor in EU) TOSHIBA CARRIER UK LTD.

This manual is also suitable for:

[Ras-b16n3kv2](#) [seriesRas-b13n3kv2](#) [seriesRas-m07,n3kv2](#) [seriesRas-m24n3kv2](#) [seriesRas-10n3av2](#) [seriesRas-13n3av2](#)
series [...](#) [Show all](#)