

Connectors - Asus Trooper H110 D3 Manual

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67



•

Table of Contents

•

Bookmarks




1.7

Connectors

1.7.1

Rear panel connectors

1. PS/2 mouse port (green)
2. USB 2.0 ports 5~8
3. VGA port



4.

LAN port*

* and **: Refer to the tables on the next page for LAN port LEDs and audio port definitions.

Due to USB 3.0 controller limitations, USB 3.0 devices can only be used under a Windows OS environment and after USB 3.0 driver installation.

The plugged USB 3.0 device may run on xHCI or EHCI mode, depending on the operating system's setting.

USB 3.0 devices can only be used for data storage.

We strongly recommend that you connect USB 3.0 devices to USB 3.0 ports for faster and better performance from your USB 3.0 devices.

1-20

5.

PS/2 keyboard port (purple)

6.

DVI-D port

7.


LAN_USB3_12 (supports USB 3.0 Boost)

8.

Audio I/O ports**

Chapter 1: Product Introduction

®



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
25
26
27
28
29
30
31
32

Related Manuals for Asus Trooper H110 D3

[Motherboard Asus H110M2 D3 Manual](#)

(57 pages)

[Motherboard Asus H110I-PLUS D3 User Manual](#)

(72 pages)

[Motherboard Asus H110M-C D3 User Manual](#)

(79 pages)

[Motherboard Asus H110M-D D3 User Manual](#)

(51 pages)

[Motherboard Asus H110I User Manual](#)

(25 pages)

[Motherboard Asus H110M-K Instruction Manual](#)

(25 pages)

[Motherboard Asus H110M-C User Manual](#)

(77 pages)

[Motherboard Asus H110M-D Instruction Manual](#)

(26 pages)

[Motherboard Asus H110M-A Manual](#)

(55 pages)

[Motherboard Asus H110-PLUS Manual](#)

(26 pages)

[Motherboard Asus PRIME H110M2/FPT Manual](#)

(26 pages)

[Motherboard Asus PRIME H110M-P Manual](#)

(28 pages)

[Motherboard Asus H110M-CS Manual](#)

(27 pages)

[Motherboard Asus H110M-C/HDMI Manual](#)

(27 pages)

[Motherboard Asus H110M-K X Manual](#)

(27 pages)

[Motherboard Asus H110M-P/DVI Manual](#)

(28 pages)

Related Content for Asus Trooper H110 D3

[ROG RAMPAGE V EDITION 10 Internal Connectors](#)

Asus ROG RAMPAGE V EDITION 10

[Q170A-IM-A Connectors](#)

Asus Q170A-IM-A

[Z13PE-D16 Connectors](#)

Asus Z13PE-D16

[WS X299 SAGE Internal Connectors](#)

Asus WS X299 SAGE

[ROG CROSSHAIR VIII EXTREME Connectors With Shared Bandwidth](#)

Asus ROG CROSSHAIR VIII EXTREME

[PCI/I-486SP3G Connectors](#)

Asus PCI/I-486SP3G

[AAEON UP Xtreme 7100 Edge Jumpers And Connectors](#)

Asus AAEON UP Xtreme 7100 Edge

[AAEON UP Xtreme 7100 Jumpers And Connectors](#)

Asus AAEON UP Xtreme 7100