

Chapter 2: Bios Information; Managing And Updating Your Bios; Ez Update - Asus Trooper H110 D3 Manual

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67




-

[Table of Contents](#)

•

Bookmarks



BIOS Information

2.1

Managing and updating your BIOS

Save a copy of the original motherboard BIOS file to a USB flash disk in case you need to restore the BIOS in the future. Copy the original motherboard BIOS using the ASUS Update utility.

2.1.1



EZ Update

EZ Update is a utility that allows you to automatically update your motherboard's softwares, drivers

and the BIOS version easily. With this utility, you can also manually update the saved BIOS and

select a boot logo when the system goes into POST.

To launch EZ Update, click EZ Update on the AI Suite 3 main menu bar.

Click to automatically update

your motherboard's driver,

software and firmware

EZ Update requires an Internet connection either through a network or an ISP (Internet Service Provider).



ASUS TROOPER H110 D3

Click to find

and select the

BIOS from file

Click to select

a boot logo

2

Click to update
the BIOS

2-1



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
36
37
38
39
40
41
42
43

Related Manuals for Asus Trooper H110 D3

[Motherboard Asus H110M2 D3 Manual](#)

(57 pages)

[Motherboard Asus H110I-PLUS D3 User Manual](#)

(72 pages)

[Motherboard Asus H110M-C D3 User Manual](#)

(79 pages)

[Motherboard Asus H110M-D D3 User Manual](#)

(51 pages)

[Motherboard Asus H110I User Manual](#)

(25 pages)

[Motherboard Asus H110M-K Instruction Manual](#)

(25 pages)

[Motherboard Asus H110M-C User Manual](#)

(77 pages)

[Motherboard Asus H110M-D Instruction Manual](#)

(26 pages)

[Motherboard Asus H110M-A Manual](#)

(55 pages)

[Motherboard Asus H110-PLUS Manual](#)

(26 pages)

[Motherboard Asus PRIME H110M2/FPT Manual](#)

(26 pages)

[Motherboard Asus PRIME H110M-P Manual](#)

(28 pages)

[Motherboard Asus H110M-CS Manual](#)

(27 pages)

[Motherboard Asus H110M-C/HDMI Manual](#)

(27 pages)

[Motherboard Asus H110M-K X Manual](#)

(27 pages)

[Motherboard Asus H110M-P/DVI Manual](#)

(28 pages)

Related Content for Asus Trooper H110 D3

[Motherboard A7N8X-VM Chapter 2: Bios Information](#)

Asus Motherboard A7N8X-VM

[PRIME H610T2-CSM D4 Chapter 2: Bios Information](#)

Asus PRIME H610T2-CSM D4

[PRIME H310M-A R1.0 Chapter 2: Bios Information](#)

Asus PRIME H310M-A R1.0

[H110M-P/DVI Chapter 2: Bios Information](#)

Asus H110M-P/DVI

[EX-B660M-V5 D4 Chapter 2 Bios Information](#)

Asus EX-B660M-V5 D4

[PRIME H610M-E Chapter 2: Bios Information](#)

Asus PRIME H610M-E

[PRIME H610I-PLUS Chapter 2: Bios Information](#)

Asus PRIME H610I-PLUS

[PRIME H370M-PLUS Chapter 2: Bios Information](#)

Asus PRIME H370M-PLUS