

Ai Suite 3 - Asus Trooper H110 D3 Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67



•

Table of Contents

•

Bookmarks



3.3

AI Suite 3

AI Suite 3 is an all-in-one interface that integrates several ASUS utilities and allows you to launch and operate these utilities simultaneously.

Installing AI Suite 3

Ensure that you have an Administrator account before installing AI Suite 3 in Windows

Windows



®

To install AI Suite 3 on your computer:

Windows

7 OS

®

1.

Place the Support DVD into the optical drive.

2.

In the AutoPlay dialog box, click Run Instv2.exe then select the Utilities tab.

3.

From the Utilities tab, check AI Suite 3 and select Install, then follow the succeeding onscreen instructions.

Windows

8 / Windows

®

1.

Place the Support DVD into the optical drive then follow onscreen instructions.

2.

From the ASUS motherboard support DVD main menu, select the Utilities tab and check AI

Suite 3 and select Install.

3.

Follow the succeeding onscreen instructions.

If the ASUS motherboard support DVD main menu did not appear, try the following steps:

a.

Go to the Start Screen then click the Desktop app.

b.

On the lower left corner of the Desktop, click File Explorer drive and double-click the Setup application.

Launching AI Suite 3

Windows

7 OS

®

From the Desktop, click Start > All Programs > ASUS > AI Suite 3 > AI Suite 3.

You can also launch AI Suite 3 in Windows

Windows

8 / Windows

®

To launch AI Suite 3 in Windows

the Start Screen (or if you're using a mouse, click the AI Suite 3 app on the Start screen).

ASUS TROOPER H110 D3

8, Windows



8.1, or Windows

®

8.1 / Windows

®

7 by clicking

®

8.1 / Windows

®

8 or Windows

®

10 OS.

®

10 OS

®

on the Notification area.

10 OS

®

10, tap the AI Suite 3 app on

®

7,

®

then select your DVD

3-3



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
54
55
56
57
58
59
60
61

Related Manuals for Asus Trooper H110 D3

[Motherboard Asus H110M2 D3 Manual](#)

(57 pages)

[Motherboard Asus H110I-PLUS D3 User Manual](#)

(72 pages)

[Motherboard Asus H110M-C D3 User Manual](#)

(79 pages)

[Motherboard Asus H110M-D D3 User Manual](#)

(51 pages)

[Motherboard Asus H110I User Manual](#)

(25 pages)

[Motherboard Asus H110M-K Instruction Manual](#)

(25 pages)

[Motherboard Asus H110M-C User Manual](#)

(77 pages)

[Motherboard Asus H110M-D Instruction Manual](#)

(26 pages)

[Motherboard Asus H110M-A Manual](#)

(55 pages)

[Motherboard Asus H110-PLUS Manual](#)

(26 pages)

[Motherboard Asus PRIME H110M2/FPT Manual](#)

(26 pages)

[Motherboard Asus PRIME H110M-P Manual](#)

(28 pages)

[Motherboard Asus H110M-CS Manual](#)

(27 pages)

[Motherboard Asus H110M-C/HDMI Manual](#)

(27 pages)

[Motherboard Asus H110M-K X Manual](#)

(27 pages)

[Motherboard Asus H110M-P/DVI Manual](#)

(28 pages)

Related Content for Asus Trooper H110 D3

[Maximus VII Hero Ai Suite 3](#)

[Asus Maximus VII Hero](#)

[Crosshair IV Extreme Asus Ai Suite Ii](#)

[Asus Crosshair IV Extreme](#)

[Z390 Series Ai Suite 3](#)

Asus Z390 Series

[Maximus VI Extreme Ai Suite 3](#)

ASUS Maximus VI Extreme

[ROG Z200 Series Ai Suite 3](#)

Asus ROG Z200 Series

[Z170-WS Ai Suite 3](#)

Asus Z170-WS

[SABERTOOTH 990FX R3.0 Ai Suite 3](#)

Asus SABERTOOTH 990FX R3.0

[P10S WS Ai Suite 3](#)

Asus P10S WS