



Asus cs10 Chromebit Quick Start Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16

• PAGE

1

-

[Table of Contents](#)

•

Bookmarks

--


Quick Links

[1 Getting Started](#)

[2 Connecting Keyboard and Mouse](#)

[Download this manual](#)

[See also: Quick Start Manual](#)



Quick Start Guide

Кратко упътване за бърз старт

Stručná příručka

Quick Start-vejledning

Snelstartgids

Lühijuhend

Guide de démarrage rapide

Pikakäynnistysopas

Schnellstarthilfe

Οδηγός γρήγορης έναρξης

Beüzemelési útmutató

Guida Rapida

Panduan Ringkas

□□□□□□□□□□

Жылдам іске қосу нұсқаулығы

Are you using this device for Digital Signage? If so, go to google.com/work/chrome/signage/chromebit for more information.

□□ □□ □□□

Greitos darbo pradžios vadovas

Īsa pamācība

Hurtigstartsveiledning

Guia de consulta rápida

Instrukcja szybkiej instalacji

Краткое руководство

Ghid de pornire rapidă

Guía de inicio rápida

دليل التشغيل السريع
Vodič za brzo korišćenje

Stručný návod na spustenie

Кратко утыване за бърз старт

Snabbstartsguide

Stručna priručka

빠른 시작 설명

Greitos darbo p

Īsa pamācība

Hızlı Başlatma Kılavuzu
Höông dẫn khôi ñoäng nhanh
E10980

[Table of Contents](#)

[Next Page](#)

1
2
3
4
5

Related Manuals for Asus cs10 Chromebit

[TV Accessories Asus Chromebit CS10 Quick Start Manual](#)

(64 pages)

[Desktop Asus CS10 Quick Start Manual](#)

(55 pages)

[Stick PC's Asus Chromebit CS10 Quick Start Manual](#)

(48 pages)

[Stick PC's Asus Chromebit CS10 Quick Start Manual](#)

(40 pages)

[Adapter Asus cs10 Chromebit Quick Start Manual](#)

(37 pages)

[Desktop Asus Chromebit CS10 Safety Information Manual](#)

(17 pages)

[Desktop Asus Chromebit CS10 Quick Start Manual](#)

(2 pages)

[Computer Accessories Asus Chromebit CS10 Quick Start Manual](#)

(2 pages)

[Adapter Asus CT-479 Installation Manual](#)

(2 pages)

[Adapter Asus XG-C100C Quick Start Manual](#)

10g pci-e network adapter (2 pages)

[Adapter Asus WL-167g Quick Start Manual](#)

54mbps usb wireless lan adapter (196 pages)

[Adapter Asus USB-N14 User Manual](#)

Dual-band wireless-ac600 usb adapter (26 pages)

[Adapter Asus USB-N14 Quick Start Manual](#)

Wireless n-300 usb adapter (2 pages)

[Adapter Asus USB-BT500 Quick Start Manual](#)

Bluetooth 5.0 usb adapter (48 pages)

[Adapter Asus USB-BT500 Quick Start Manual](#)

Bluetooth 5.0 usb adapter (17 pages)

[Adapter Asus Vivo DualBay User Manual](#)

(12 pages)

Summary of Contents for Asus cs10 Chromebit

[Page 1: Quick Start Guide](#)

E10980 Quick Start Guide 快速启动指南 Кратко упу̀тване за бърз старт Greitos darbo pradžios vadovas Stručná příručka Ľsa pamäciba Quick Start-vejledning Hurtigstartsveiledning Snelstartgids Guia de consulta rápida Lühijuhend Instrukcja szybkiej instalacji Краткое руководство Guide de démarrage rapide Ghid de pornire rapidă Pikakäynnistysopas Guía de inicio rápida Schnellstarthilfe...

[Page 2: Getting Started](#)

USB hub, and not directly to the USB port. • E nsure that your Chromebit does not block any of the air vents on your monitor display. • P lace your Chromebit or powered USB hub near the

side of your monitor to ensure that wireless signals are not obstructed. • Illustrations for reference only. • USB hub, keyboard and mouse are not included. • Visit our multi-language web site at <http://support.asus.com...>

[Page 3](#) Connecting Chromebit 1. Remove the cap.

[Page 4](#) 2. Plug your Chromebit into an HDMI port.

[Page 5](#) 3. Connect the power into your Chromebit.

[Page 6](#) Connecting USB Hub 1. Stick your USB Hub to your monitor with the hook and loop sticker set, then connect your USB Hub into your Chromebit.

[Page 7](#) 2. Connect the power into your USB Hub.

[Page 8](#) Connecting HDMI extension cable 1. Remove the cap, then connect your HDMI extension cable.

[Page 9](#) 2. Stick your Chromebit to your monitor with the hook and loop sticker set, then plug your Chromebit into an HDMI port.

[Page 10](#) 3. Connect the power into your Chromebit.

[Page 11: Connecting Keyboard And Mouse](#)

Connecting keyboard and mouse Bluetooth keyboard and mouse Connect e c t C o n n...

[Page 12](#) USB Hub with wired keyboard and mouse...

[Page 14: Asus Contact Information](#)

Telephone +886-2-2894-3447 +886-2-2890-7798 E-mail info@asus.com.tw Website <http://www.asus.com> Technical Support Telephone +86-21-3429911 +86-21-58668722, ext. 9101# Online support <http://support.asus.com/techserv/techserv.aspx> ASUS COMPUTER INTERNATIONAL (America) Address 800 Corporate Way, Fremont, CA 94539, Telephone +1-510-739-3777 +1-510-608-4555 Website <http://usa.asus.com> Technical Support Support fax +1-812-284-0883 General support +1-812-282-4555 Online support <http://www.service.asus.com> ASUS COMPUTER GmbH...

[Page 15: Ec Declaration Of Conformity](#)

EC Declaration of Conformity We, the undersigned, Manufacturer: ASUSTeK COMPUTER INC. Address: 4F, No. 150, LI-TE Rd., PEITOU, TAIPEI 112, TAIWAN Authorized representative in Europe: ASUS COMPUTER GmbH Address, City: HARKORT STR. 21-23, 40880 RATINGEN Country: GERMANY declare the following apparatus: Chromebit...

[Page 16](#) 15060-68500100...