

Tool Menu; Asus Ez Flash 3 Utility;
Secure Erase - Asus SABERTOOTH
Z170 Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174



•

[Table of Contents](#)

•

Bookmarks



3.9

Tool menu

The Tool menu items allow you to configure options for special functions. Select an item then press <Enter> to display the submenu.

Setup Animator

This item allows you to enable or disable the Setup animator.

Configuration options: [Disabled] [Enabled]

3.9.1

ASUS EZ Fla

This item allows



message appears. Use the left/right arrow key to select between [Yes] or [No], then press <Enter> to confirm your choice.

For more details, refer to section 3.11.2 ASUS EZ Flash 3.

3.9.2

Secure Erase

SSD speeds may lower over time as with any storage medium due to data processing. Secure Erase completely and safely cleans your SSD, restoring it to factory performance levels.

Secure Erase is only available in AHCI mode. Ensure to set the SATA mode to AHCI. Click

Advanced > SATA

To launch Secure

Check the ASUS sup

become unstable if

.

.

3-50


The time to erase the contents of your SSD may take a while.

Do not turn off the system during the process.

Secure Erase is only supported on SATA SSDs.

SATA ports, refer to

Chapter 3: BIOS Setup



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

113

114

115

116

Quick Links:

[Motherboard Layout](#)

[Internal Connectors](#)

[Sata Device Connection](#)

[Front I/O Connector](#)

Related Manuals for Asus SABERTOOTH Z170

[Motherboard Asus Z170 PRO GAMING User Manual](#)

(100 pages)

[Motherboard Asus Z170 PRO GAMING Manual](#)

(96 pages)

[Motherboard Asus Z170-A User Manual](#)

(130 pages)

[Motherboard Asus Z170M-E D3 Manual](#)

(85 pages)

[Motherboard Asus Z170-P D3 User Manual](#)

(85 pages)

[Motherboard Asus Z170-K Quick Start Manual](#)

(11 pages)

[Motherboard ASUS Z170-K User Manual](#)

(85 pages)

[Motherboard Asus Z170-P Manual](#)

(86 pages)

[Motherboard Asus Z170-AR Manual](#)

(130 pages)

[Motherboard Asus Z170M-PLUS User Manual](#)

(89 pages)

[Motherboard Asus SABERTOOTH Z170 MARK 1 Manual](#)

(176 pages)

[Motherboard Asus Z170I PRO GAMING User Manual](#)

(86 pages)

[Motherboard Asus Z170I PRO GAMING Manual](#)

(86 pages)

[Motherboard Asus Z170-E Manual](#)

(128 pages)

[Motherboard Asus Z170-DELUXE Series User Manual](#)

(186 pages)

[Motherboard Asus Z170-PRO Manual](#)

(170 pages)

Related Content for Asus SABERTOOTH Z170

[AM1M-E Tool Menu](#)

Asus AM1M-E

[STRIX Z270H GAMING Tool Menu](#)

Asus STRIX Z270H GAMING

[TUF Z270 MARK 1 Tool Menu](#)

Asus TUF Z270 MARK 1

[TUF X470-PLUS GAMING Tool Menu](#)

Asus TUF X470-PLUS GAMING

[PRIME X570-P Tool Menu](#)

Asus PRIME X570-P

[STRIX Z270H GAMING Tool Menu](#)

Asus STRIX Z270H GAMING

[ROG CROSSHAIR VIII IMPACT Tool Menu](#)

Asus ROG CROSSHAIR VIII IMPACT

[WS C621E SAGE Series Tool Menu](#)

Asus WS C621E SAGE Series