

Chapter 4: Software Support; Installing An Operating System - Asus SABERTOOTH Z170 Manual

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174



•

[Table of Contents](#)

•

Bookmarks



Software Support

4.1

Installing an operating system

-

This motherboard supports 32-bit/64-bit Windows

Windows

-

Motherboard settings and hardware options vary. The setup procedures presented



in this chapter are for reference only. Refer to Windows documentation for detailed information.

4.1.1

Windows

Based on the chipset specification, the 100 series requires USB 3.0 drivers to be preloaded

in order to use USB keyboard/mouse during Windows on preloading USB 3.0 drivers and installing Windows

Method 1: Using SATA ODD & USB devices

Load USB 3.0 drivers using the ASUS support DVD and install Windows device.

Requirement:



- 1 x ASUS support DVD
- 1 x Windows
- 1 x SATA ODD
- 1 x USB device (ODD or storage)

The USB storage device requires 8 GB or more capacity. It is recommended to format the storage device before use.

1. Insert the Windows

Windows

7 installation DVD to a USB storage device on a working system.

®

2.

Connect the USB ODD or USB storage device to your 100 series platform.

3.

Insert the ASUS support DVD into a SATA ODD on your 100 series platform.

4.

Power on your system and press F8 during POST (Power-On Self Test) to enter the boot screen.

SABERTOOTH Z170 S

10 operating systems (OS).

®

7 and USB 3.0 driver for 100 Series

®

7 installation source

®



7 installation DVD into a USB ODD, or copy all files on the

®

7, 64-bit Windows

®

operating system

®

7 installation. This section is a guide

®

7.

®

7 using a USB

®



8.1, and 64-bit

®

4-1

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

122

123

124

125

Quick Links:

[Motherboard Layout](#)

[Internal Connectors](#)

[Sata Device Connection](#)

[Front I/O Connector](#)

Related Manuals for Asus SABERTOOTH Z170

[Motherboard Asus Z170 PRO GAMING User Manual](#)

(100 pages)

[Motherboard Asus Z170 PRO GAMING Manual](#)

(96 pages)

[Motherboard Asus Z170-A User Manual](#)

(130 pages)

[Motherboard Asus Z170M-E D3 Manual](#)

(85 pages)

[Motherboard Asus Z170-P D3 User Manual](#)

(85 pages)

[Motherboard Asus Z170-K Quick Start Manual](#)

(11 pages)

[Motherboard ASUS Z170-K User Manual](#)

(85 pages)

[Motherboard Asus Z170-P Manual](#)

(86 pages)

[Motherboard Asus Z170-AR Manual](#)

(130 pages)

[Motherboard Asus Z170M-PLUS User Manual](#)

(89 pages)

[Motherboard Asus SABERTOOTH Z170 MARK 1 Manual](#)

(176 pages)

[Motherboard Asus Z170I PRO GAMING User Manual](#)

(86 pages)

[Motherboard Asus Z170I PRO GAMING Manual](#)

(86 pages)

[Motherboard Asus Z170-E Manual](#)

(128 pages)

[Motherboard Asus Z170-DELUXE Series User Manual](#)

(186 pages)

[Motherboard Asus Z170-PRO Manual](#)

(170 pages)

Related Content for Asus SABERTOOTH Z170

[P5KPL-E Chapter 3: Software Support](#)

Asus P5KPL-E

[MAXIMUS VII HERO Chapter 4: Software Support](#)

Asus MAXIMUS VII HERO

[AM1M-E Software Support](#)

Asus AM1M-E

[H81M-D R2.0 Software Support](#)

Asus H81M-D R2.0

[P5KPL IN/SI Software Support](#)

Asus P5KPL IN/SI

[P8P67 EVO Chapter 4: Software Support](#)

Asus P8P67 EVO

[Q170M2/CDM/SI Software Support](#)

Asus Q170M2/CDM/SI

[M2N-X Chapter 3: Software Support](#)

Asus M2N-X