

Ai Charger - Asus SABERTOOTH Z170 Manual


1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174




•

[Table of Contents](#)

•

Bookmarks



4.4.1

Ai Charger+

Ai Charger+ allows you to fast-charge your portable BC 1.1* mobile devices on your computer's USB port three times faster than the standard USB devices**.

Launching Ai Charger+

To launch Ai Charger+, click

Charger+.

Ai Charger+ is available only in selected motherboard models.

Ai Charger+ screen

.



* Check the manufacturer if your USB device is a Battery Charging Specification 1.1 (BC 1.1) compliant or compatible device.

.

** Actual charging speeds may vary depending on the charging rate and specifications of your USB device.

To ensure normal charging function, disconnect and reconnect your USB device every time you enable or disable Ai Charger+.

Ai Charger+ does not support USB hubs, USB extension cables, and generic USB cables.

SABERTOOTH Z170 S

on the left of the AI Suite 3 main menu, then select Ai

Tick to enable or disable Ai Charger+

Click or tap to apply the selection

4-19



[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

140

141

142

143

Quick Links:

[Motherboard Layout](#)

[Internal Connectors](#)

[Sata Device Connection](#)

[Front I/O Connector](#)

Related Manuals for Asus SABERTOOTH Z170

[Motherboard Asus Z170 PRO GAMING User Manual](#)

(100 pages)

[Motherboard Asus Z170 PRO GAMING Manual](#)

(96 pages)

[Motherboard Asus Z170-A User Manual](#)

(130 pages)

[Motherboard Asus Z170M-E D3 Manual](#)

(85 pages)

[Motherboard Asus Z170-P D3 User Manual](#)

(85 pages)

[Motherboard ASUS Z170-K User Manual](#)

(85 pages)

[Motherboard Asus Z170-K Quick Start Manual](#)

(11 pages)

[Motherboard Asus Z170-P Manual](#)

(86 pages)

[Motherboard Asus Z170-AR Manual](#)

(130 pages)

[Motherboard Asus Z170M-PLUS User Manual](#)

(89 pages)

[Motherboard Asus SABERTOOTH Z170 MARK 1 Manual](#)

(176 pages)

[Motherboard Asus Z170I PRO GAMING User Manual](#)

(86 pages)

[Motherboard Asus Z170I PRO GAMING Manual](#)

(86 pages)

[Motherboard Asus Z170-E Manual](#)

(128 pages)

[Motherboard Asus Z170-DELUXE Series User Manual](#)

(186 pages)

[Motherboard Asus Z170-PRO Manual](#)

(170 pages)

Related Content for Asus SABERTOOTH Z170

[P10S WS Ai Charger](#)

Asus P10S WS

[SABERTOOTH X99 Ai Charger](#)

Asus SABERTOOTH X99

[Z170-DELUXE Series Ai Charger](#)

Asus Z170-DELUXE Series

[SABERTOOTH Z170 MARK 1 Ai Charger](#)

Asus SABERTOOTH Z170 MARK 1

[Z170-Premium series Ai Charger](#)

Asus Z170-Premium series

[SABERTOOTH Z170 MARK 1 Ai Charger](#)

Asus SABERTOOTH Z170 MARK 1

[F2A85-M PRO Ai Charger](#)

Asus F2A85-M PRO

[X99-M WS Ai Charger](#)

Asus X99-M WS