

Push Notice - Asus SABERTOOTH Z170 Manual

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16


17

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174



•

[Table of Contents](#)

•

Bookmarks



4.4.4

Push Notice

This utility allows you get the detailed status of your system to your smart device. You can also send messages to your smart device using this utility.

Before using this utility, ensure that you pair your computer with your smart device. For pairing information, refer to section Pairing your computer and smart device.

Launching Push Notice on your computer

To launch Push Notice, click
Notice.



Push Notice screen

Click or tap to enable or disable Push Notice

You can also enable the Push Notice via the Push Notice shortcut on the lower-right corner

of your screen. To do this, click or tap << then click or tap

Pairing your computer and smart device

To pair your computer and smart device:

1.

On your smart device, tap

2.

Tap Push Scan then tap the name of your computer that you want to pair with.

To pair your computer and smart device, ensure that both are connected to the same wireless network.

4-24

on the left of the AI Suite 3 main menu, then select Push

Click or tap to
discard the settings



to launch Push Notice.

Push Notice

Tick to select the
smart device

Click or tap to
apply the settings
then select



Chapter 4: Software Support

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

145

146

147

148

Quick Links:

[Motherboard Layout](#)

[Internal Connectors](#)

[Sata Device Connection](#)

[Front I/O Connector](#)

Related Manuals for Asus SABERTOOTH Z170

[Motherboard Asus Z170 PRO GAMING Manual](#)

(96 pages)

[Motherboard Asus Z170 PRO GAMING User Manual](#)

(100 pages)

[Motherboard Asus Z170-A User Manual](#)

(130 pages)

[Motherboard Asus Z170M-E D3 Manual](#)

(85 pages)

[Motherboard Asus Z170-P D3 User Manual](#)

(85 pages)

[Motherboard ASUS Z170-K User Manual](#)

(85 pages)

[Motherboard Asus Z170-K Quick Start Manual](#)

(11 pages)

[Motherboard Asus Z170-P Manual](#)

(86 pages)

[Motherboard Asus Z170-AR Manual](#)

(130 pages)

[Motherboard Asus Z170M-PLUS User Manual](#)

(89 pages)

[Motherboard Asus SABERTOOTH Z170 MARK 1 Manual](#)

(176 pages)

[Motherboard Asus Z170I PRO GAMING User Manual](#)

(86 pages)

[Motherboard Asus Z170I PRO GAMING Manual](#)

(86 pages)

[Motherboard Asus Z170-E Manual](#)

(128 pages)

[Motherboard Asus Z170-DELUXE Series User Manual](#)

(186 pages)

[Motherboard Asus Z170-PRO Manual](#)

(170 pages)

Related Content for Asus SABERTOOTH Z170

[SABERTOOTH X99 Push Notice](#)

Asus SABERTOOTH X99

[Z170-DELUXE Series Push Notice](#)

Asus Z170-DELUXE Series

[SABERTOOTH Z170 MARK 1 Push Notice](#)

Asus SABERTOOTH Z170 MARK 1

[Z170-Premium series Push Notice](#)

Asus Z170-Premium series

[maximus viii formula Push Notice](#)

Asus maximus viii formula

[SABERTOOTH Z170 MARK 1 Push Notice](#)

Asus SABERTOOTH Z170 MARK 1

[X99-M WS Push Notice](#)

Asus X99-M WS

[MAXIMUS VIII EXTREME Push Notice](#)

Asus MAXIMUS VIII EXTREME