



# Tuf Detective 2; Post - Asus SABERTOOTH Z170 Manual



1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16


17

19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68

69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118

119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168

169  
170  
171  
172  
173  
174



•

[Table of Contents](#)



•

## Bookmarks





## 4.6

### TUF Detective 2

TUF Detective 2 allows you to remotely manage and control your computer using your Android mobile device. It also provides relevant system information.

To use TUF Detective 2:

1.

Connect your mobile device to the TUF Detective port located at the rear panel.

2.

On your mobile device, download and install the TUF Detective app.

Download the TUF Detective app



from Play Store or use the QR code to find the app.

3.  
Launch the TUF Detective app to remotely control and manage your computer.

## 4.6.1

# Post

The Post page provides the POST (Power-On Self Test) status..

Post

4-32

Code for the POST status

Details about the POST status.

Select this App

to install TUF

Detective in your


mobile phone.

Scan the QR code

to find the app.

Chapter 4: Software Support

[Table of Contents](#)



[Previous Page](#)  
[Next Page](#)

1

...

153

154

155

156

Quick Links:

[Motherboard Layout](#)

[Internal Connectors](#)

[Sata Device Connection](#)

[Front I/O Connector](#)

## Related Manuals for Asus SABERTOOTH Z170

[Motherboard Asus Z170 PRO GAMING User Manual](#)

(100 pages)

[Motherboard Asus Z170 PRO GAMING Manual](#)

(96 pages)

[Motherboard Asus Z170-A User Manual](#)

(130 pages)

[Motherboard Asus Z170M-E D3 Manual](#)



(85 pages)

[Motherboard Asus Z170-P D3 User Manual](#)

(85 pages)

[Motherboard Asus Z170-K Quick Start Manual](#)

(11 pages)

[Motherboard ASUS Z170-K User Manual](#)

(85 pages)

[Motherboard Asus Z170-P Manual](#)

(86 pages)

[Motherboard Asus Z170-AR Manual](#)

(130 pages)

[Motherboard Asus Z170M-PLUS User Manual](#)

(89 pages)

[Motherboard Asus SABERTOOTH Z170 MARK 1 Manual](#)

(176 pages)

[Motherboard Asus Z170I PRO GAMING User Manual](#)

(86 pages)

[Motherboard Asus Z170I PRO GAMING Manual](#)

(86 pages)

[Motherboard Asus Z170-E Manual](#)

(128 pages)

[Motherboard Asus Z170-DELUXE Series User Manual](#)

(186 pages)

[Motherboard Asus Z170-PRO Manual](#)

(170 pages)

## Related Content for Asus SABERTOOTH Z170

[TUF GAMING B450M-PLUS II Tuf Gaming B450M-Plus II Specifications](#)

[Summary](#)

Asus TUF GAMING B450M-PLUS II

[TUF X470-PLUS GAMING Tuf X470-Plus Gaming Specifications](#)

[Summary](#)

Asus TUF X470-PLUS GAMING

[TUF GAMING Z790-PRO WIFI Tuf Gaming Z790-Pro Wifi Specifications](#)

[Summary](#)

Asus TUF GAMING Z790-PRO WIFI

[TUF GAMING B650M-PLUS Tuf Gaming B650M-Plus Specifications](#)

[Summary](#)

Asus TUF GAMING B650M-PLUS

[TUF GAMING B760M-BTF WIFI D4 Tuf Gaming B760M-Btf Wifi D4](#)

[Specifications Summary](#)

Asus TUF GAMING B760M-BTF WIFI D4

[TUF X299 MARK 2 Tuf X299 Mark 2 Specifications Summary](#)

Asus TUF X299 MARK 2

[TUF GAMING B760M-PLUS WIFI Tuf Gaming B760M-Plus Wifi](#)

[Specifications Summary](#)

Asus TUF GAMING B760M-PLUS WIFI

[90MB0U00-M0EAY0 Tuf X299 Mark 1 Specifications Summary](#)

Asus 90MB0U00-M0EAY0