

Monitor - Asus SABERTOOTH Z170 Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174



•

[Table of Contents](#)

•

Bookmarks



Tap CLEAR CMOS and select Yes to clear the CMOS RTC RAM data.

4.6.3

Monitor

The Monitor page allows you to monitor voltage, temperature, and fan speed.

4-34

Monitor

Tap PATCH ERROR and select Yes to automatically



repair your computer.

Tap the triangle icon to monitor
the voltage.

Chapter 4: Software Support

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1

...

155

156

157

158

Quick Links:

[Motherboard Layout](#)

[Internal Connectors](#)

[Sata Device Connection](#)

[Front I/O Connector](#)

Related Manuals for Asus SABERTOOTH Z170

[Motherboard Asus Z170 PRO GAMING User Manual](#)

(100 pages)

[Motherboard Asus Z170 PRO GAMING Manual](#)

(96 pages)

[Motherboard Asus Z170-A User Manual](#)

(130 pages)

[Motherboard Asus Z170M-E D3 Manual](#)

(85 pages)

[Motherboard Asus Z170-P D3 User Manual](#)

(85 pages)

[Motherboard Asus Z170-K Quick Start Manual](#)

(11 pages)

[Motherboard ASUS Z170-K User Manual](#)

(85 pages)

[Motherboard Asus Z170-P Manual](#)

(86 pages)

[Motherboard Asus Z170-AR Manual](#)

(130 pages)

[Motherboard Asus Z170M-PLUS User Manual](#)

(89 pages)

[Motherboard Asus SABERTOOTH Z170 MARK 1 Manual](#)

(176 pages)

[Motherboard Asus Z170I PRO GAMING User Manual](#)

(86 pages)

[Motherboard Asus Z170I PRO GAMING Manual](#)

(86 pages)

[Motherboard Asus Z170-E Manual](#)

(128 pages)

[Motherboard Asus Z170-DELUXE Series User Manual](#)

(186 pages)

[Motherboard Asus Z170-PRO Manual](#)

(170 pages)

Related Content for Asus SABERTOOTH Z170

[PRIME X570-PRO Monitor Menu](#)

Asus PRIME X570-PRO

[M3N-H/HDMI Hardware Monitor](#)

Asus M3N-H/HDMI

[EX-B660M-V5 D4 Monitor Menu](#)

Asus EX-B660M-V5 D4

[P5KPL-E Hardware Monitor](#)

Asus P5KPL-E

[STRIX Z270F GAMING Monitor Menu](#)

Asus STRIX Z270F GAMING

[MAXIMUS VII HERO Monitor Menu](#)

Asus MAXIMUS VII HERO

[AM1M-E Monitor Menu](#)

Asus AM1M-E

[EX-H310M-X Monitor Menu](#)

Asus EX-H310M-X