

Motherboard Overview; Before You Proceed - Asus SABERTOOTH Z170 Manual


1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174



•

[Table of Contents](#)

•

Bookmarks



1.2

Motherboard overview

1.2.1

Before you proceed

Take note of the following precautions before you install motherboard components or change any motherboard settings.

-
-
-
-
-

Unplug the power cord from the wall socket before touching any component.

Before handling components, use a grounded wrist strap or touch a safely grounded object or a metal object, such as the power supply case, to avoid damaging them due to static electricity.

Hold components by the edges to avoid touching the ICs on them.

Whenever you uninstall any component, place it on a grounded antistatic pad or in the bag that came with the component.

Before you install or remove any component, ensure that the ATX power supply is switched off or the power cord is detached from the power supply. Failure to do so may cause severe damage to the motherboard, peripherals, or components.

Chapter 1: Product Introduction

[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

1
...
19
20
21
22
23
24
25
26

Quick Links:

[Motherboard Layout](#)

[Internal Connectors](#)

[Sata Device Connection](#)

[Front I/O Connector](#)

Related Manuals for Asus SABERTOOTH Z170

[Motherboard Asus Z170 PRO GAMING User Manual](#)

(100 pages)

[Motherboard Asus Z170 PRO GAMING Manual](#)

(96 pages)

[Motherboard Asus Z170-A User Manual](#)

(130 pages)

[Motherboard Asus Z170M-E D3 Manual](#)

(85 pages)

[Motherboard Asus Z170-P D3 User Manual](#)

(85 pages)

[Motherboard Asus Z170-K Quick Start Manual](#)

(11 pages)

[Motherboard ASUS Z170-K User Manual](#)

(85 pages)

[Motherboard Asus Z170-P Manual](#)

(86 pages)

[Motherboard Asus Z170-AR Manual](#)

(130 pages)

[Motherboard Asus Z170M-PLUS User Manual](#)

(89 pages)

[Motherboard Asus SABERTOOTH Z170 MARK 1 Manual](#)

(176 pages)

[Motherboard Asus Z170I PRO GAMING User Manual](#)

(86 pages)

[Motherboard Asus Z170I PRO GAMING Manual](#)

(86 pages)

[Motherboard Asus Z170-E Manual](#)

(128 pages)

[Motherboard Asus Z170-DELUXE Series User Manual](#)

(186 pages)

[Motherboard Asus Z170-PRO Manual](#)

(170 pages)

Related Content for Asus SABERTOOTH Z170

[ROG RAMPAGE V EDITION 10 Motherboard Overview](#)

Asus ROG RAMPAGE V EDITION 10

[Z13PE-D16 Motherboard Overview](#)

Asus Z13PE-D16

[WS X299 SAGE Motherboard Overview](#)

Asus WS X299 SAGE

[Pro A620M-C-CSM Motherboard Overview](#)

Asus Pro A620M-C-CSM

[PRIME H310M-A R1.0 Motherboard Overview](#)

Asus PRIME H310M-A R1.0

[TUF GAMING B650-E WIFI Motherboard Overview](#)

Asus TUF GAMING B650-E WIFI

[H110M-P/DVI Motherboard Overview](#)

Asus H110M-P/DVI

[PRIME X570-PRO Motherboard Overview](#)

Asus PRIME X570-PRO