

Expansion Slots - Asus SABERTOOTH Z170 Manual

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174



•

[Table of Contents](#)

•


Bookmarks



1.2.5

Expansion slots

Unplug the power cord before adding or removing expansion cards. Failure to do so may cause you physical injury and damage motherboard components.

- 1  PCIE 3.0/2.0 x1_1 slot
- 2 PCIE 3.0/2.0 x16_1 slot
- 3 PCIE 3.0/2.0 x1_2 slot



4

PCIe 3.0/2.0 x16_2 slot

5

PCIe 3.0/2.0 x1_3 slot

6

PCIe 3.0/2.0 x16_3 slot

1-12

Chapter 1: Product Introduction

[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

1
...
25
26
27
28
29
30
31
32

Quick Links:

[Motherboard Layout](#)

[Internal Connectors](#)

[Sata Device Connection](#)

[Front I/O Connector](#)

Related Manuals for Asus SABERTOOTH Z170

[Motherboard Asus Z170 PRO GAMING User Manual](#)

(100 pages)

[Motherboard Asus Z170 PRO GAMING Manual](#)

(96 pages)

[Motherboard Asus Z170-A User Manual](#)

(130 pages)

[Motherboard Asus Z170M-E D3 Manual](#)

(85 pages)

[Motherboard Asus Z170-P D3 User Manual](#)

(85 pages)

[Motherboard Asus Z170-K Quick Start Manual](#)

(11 pages)

[Motherboard ASUS Z170-K User Manual](#)

(85 pages)

[Motherboard Asus Z170-P Manual](#)

(86 pages)

[Motherboard Asus Z170-AR Manual](#)

(130 pages)

[Motherboard Asus Z170M-PLUS User Manual](#)

(89 pages)

[Motherboard Asus SABERTOOTH Z170 MARK 1 Manual](#)

(176 pages)

[Motherboard Asus Z170I PRO GAMING User Manual](#)

(86 pages)

[Motherboard Asus Z170I PRO GAMING Manual](#)

(86 pages)

[Motherboard Asus Z170-E Manual](#)

(128 pages)

[Motherboard Asus Z170-DELUXE Series User Manual](#)

(186 pages)

[Motherboard Asus Z170-PRO Manual](#)

(170 pages)

Related Content for Asus SABERTOOTH Z170

[ROG CROSSHAIR VIII EXTREME Expansion Slots](#)

Asus ROG CROSSHAIR VIII EXTREME

[PRIME X570-PRO Expansion Slots](#)

Asus PRIME X570-PRO

[M3N-H/HDMI Expansion Slots](#)

Asus M3N-H/HDMI

[P5KPL-E Expansion Slots](#)

Asus P5KPL-E

[MAXIMUS VII HERO Expansion Slots](#)

Asus MAXIMUS VII HERO

[AM1M-E Expansion Slots](#)

Asus AM1M-E

[STRIX Z270H GAMING Expansion Slots](#)

Asus STRIX Z270H GAMING

[H81M-D R2.0 Expansion Slots](#)

Asus H81M-D R2.0