

Table Of Contents - Asus SABERTOOTH Z170 Manual

1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174

• PAGE

OF 174 GO

•

[Table of Contents](#)

•

Bookmarks



Contents

[Safety information](#)

..... vi

[About this guide](#)

..... vii

[SABERTOOTH Z170 S specifications](#)

[summary](#)..... ix

[Package contents](#)

..... xiv

[Installation tools and components](#)

..... xv

[Chapter 1:](#)

1.1

[Special features](#) 1-1

1.1.1

1.1.2

1.1.3

1.1.4

1.1.5

1.1.6

1.1.7

1.2

[Motherboard overview](#) 1-6

1.2.1

1.2.2

1.2.3

1.2.4

1.2.5

1.2.6

1.2.7

1.2.8

1.2.9

[Chapter 2:](#)

2.1

[Building your PC system](#) 2-1

2.1.1

2.1.2

2.1.3

2.1.4

2.1.5

2.1.6

2.1.7

2.1.8

2.1.9

2.2

[BIOS update utility](#) 2-15

[Product Introduction](#)

Product highlights	1-1
"Ultimate COOL" Thermal Solutions	1-2
"TUF Engine" Power Design	1-3
"Safe & Stable!" Guardian Angel	1-3
ASUS EZ DIY	1-4
ASUS Exclusive Features	1-5
Other special features	1-5
Before you proceed	1-6
Motherboard layout	1-7
Central Processing Unit (CPU)	1-9
System memory	1-10
Expansion slots	1-12
Onboard buttons	1-14
Jumpers	1-15
Onboard LEDs	1-17
Internal connectors	1-18
Basic Installation	
IO Cover installation	2-1
Motherboard installation	2-3
CPU installation	2-6
CPU heatsink and fan assembly installation	2-8
DIMM installation	2-10
ATX Power connection	2-11
SATA device connection	2-12
Front I/O Connector	2-13
Expansion Card installation	2-14

[Previous Page](#)
[Next Page](#)

1
2
3
4
5
6
7

Quick Links:

[Motherboard Layout](#)

[Internal Connectors](#)

[Sata Device Connection](#)

[Front I/O Connector](#)

Related Manuals for Asus SABERTOOTH Z170

[Motherboard Asus Z170 PRO GAMING User Manual](#)

(100 pages)

[Motherboard Asus Z170 PRO GAMING Manual](#)

(96 pages)

[Motherboard Asus Z170-A User Manual](#)

(130 pages)

[Motherboard Asus Z170M-E D3 Manual](#)

(85 pages)

[Motherboard Asus Z170-P D3 User Manual](#)

(85 pages)

[Motherboard Asus Z170-K Quick Start Manual](#)

(11 pages)

[Motherboard ASUS Z170-K User Manual](#)

(85 pages)

[Motherboard Asus Z170-P Manual](#)

(86 pages)

[Motherboard Asus Z170-AR Manual](#)

(130 pages)

[Motherboard Asus Z170M-PLUS User Manual](#)

(89 pages)

[Motherboard Asus SABERTOOTH Z170 MARK 1 Manual](#)

(176 pages)

[Motherboard Asus Z170I PRO GAMING User Manual](#)

(86 pages)

[Motherboard Asus Z170I PRO GAMING Manual](#)

(86 pages)

[Motherboard Asus Z170-E Manual](#)

(128 pages)

[Motherboard Asus Z170-DELUXE Series User Manual](#)

(186 pages)

[Motherboard Asus Z170-PRO Manual](#)

(170 pages)

Related Content for Asus SABERTOOTH Z170

[PRIME Z270-K Table Of Contents](#)

[Asus PRIME Z270-K](#)

[Z170-P Table Of Contents](#)

[Asus Z170-P](#)

[Prime H270-PRO Table Of Contents](#)

[Asus Prime H270-PRO](#)

[PRIME Z270-P Table Of Contents](#)

[Asus PRIME Z270-P](#)

[PRIME Z370-P Table Of Contents](#)

[Asus PRIME Z370-P](#)

[970 PRO GAMING/AURA Table Of Contents](#)

[Asus 970 PRO GAMING/AURA](#)

[Pro WS X570-ACE Table Of Contents](#)

[asus Pro WS X570-ACE](#)

[PRIME Z390-P Table Of Contents](#)

[Asus PRIME Z390-P](#)