



# Chapter 2: Basic Installation; Building Your Pc System; Io Cover Installation - Asus SABERTOOTH Z170 Manual




1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

19  
20  
21  
22  
23  
24  
25  
26  
27  
28  
29  
30  
31  
32  
33  
34  
35  
36  
37  
38  
39  
40  
41  
42  
43  
44  
45  
46  
47  
48  
49  
50  
51  
52  
53  
54  
55  
56  
57  
58  
59  
60  
61  
62  
63  
64  
65  
66  
67  
68

69  
70  
71  
72  
73  
74  
75  
76  
77  
78  
79  
80  
81  
82  
83  
84  
85  
86  
87  
88  
89  
90  
91  
92  
93  
94  
95  
96  
97  
98  
99  
100  
101  
102  
103  
104  
105  
106  
107  
108  
109  
110  
111  
112  
113  
114  
115  
116  
117  
118

119  
120  
121  
122  
123  
124  
125  
126  
127  
128  
129  
130  
131  
132  
133  
134  
135  
136  
137  
138  
139  
140  
141  
142  
143  
144  
145  
146  
147  
148  
149  
150  
151  
152  
153  
154  
155  
156  
157  
158  
159  
160  
161  
162  
163  
164  
165  
166  
167  
168

169  
170  
171  
172  
173  
174



•

[Table of Contents](#)



•

## Bookmarks





# Basic Installation

## 2.1

Building your PC system

### 2.1.1

# IO Cover installation

The SABERTOOTH Z170 S motherboard package can be installed with a 40 mm assistant

fan for additional cooling solution and better airflow.

To install the 40 mm assistant fan:


1. Locate and remove the screw on the back I/O (A) then remove the back I/O fan cover lid (B). Keep the screws for later use.
2. Position and install the 40 mm assistant fan\* in an orientation such that the fan draws air into the chassis for optimal heat dissipation and air ventilation.
3. Match the two (2) screw holes on the 40 mm assistant fan with the two (2) screw holes on the cover lid and secure it with two (2) screws\*\*.

\* The 40mm assistant fan is purchased separately.

\*\* When purchasing your assistant fan, ensure to check with your vendor for the assistant fan screws.

SABERTOOTH Z170 S

2



2-1

[Table of Contents](#)

[Previous Page](#)  
[Next Page](#)

1  
...  
42  
43  
44  
45  
46  
47  
48  
49

Quick Links:

[Motherboard Layout](#)

[Internal Connectors](#)

[Sata Device Connection](#)

[Front I/O Connector](#)

## Related Manuals for Asus SABERTOOTH Z170

[Motherboard Asus Z170 PRO GAMING User Manual](#)

(100 pages)

[Motherboard Asus Z170 PRO GAMING Manual](#)

(96 pages)

[Motherboard Asus Z170-A User Manual](#)

(130 pages)

[Motherboard Asus Z170M-E D3 Manual](#)



(85 pages)

[Motherboard Asus Z170-P D3 User Manual](#)

(85 pages)

[Motherboard Asus Z170-K Quick Start Manual](#)

(11 pages)

[Motherboard ASUS Z170-K User Manual](#)

(85 pages)

[Motherboard Asus Z170-P Manual](#)

(86 pages)

[Motherboard Asus Z170-AR Manual](#)

(130 pages)

[Motherboard Asus Z170M-PLUS User Manual](#)

(89 pages)

[Motherboard Asus SABERTOOTH Z170 MARK 1 Manual](#)

(176 pages)

[Motherboard Asus Z170I PRO GAMING User Manual](#)

(86 pages)

[Motherboard Asus Z170I PRO GAMING Manual](#)

(86 pages)

[Motherboard Asus Z170-E Manual](#)

(128 pages)

[Motherboard Asus Z170-DELUXE Series User Manual](#)

(186 pages)

[Motherboard Asus Z170-PRO Manual](#)

(170 pages)

## Related Content for Asus SABERTOOTH Z170

[MAXIMUS VII HERO Chapter 2: Basic Installation](#)

Asus MAXIMUS VII HERO

[STRIX Z270H GAMING Chapter 2: Basic Installation](#)

Asus STRIX Z270H GAMING

[TUF X470-PLUS GAMING Chapter 2: Basic Installation](#)

Asus TUF X470-PLUS GAMING

[PRIME X570-P Chapter 2: Basic Installation](#)

Asus PRIME X570-P

[WS C621E SAGE Series Chapter 2: Basic Installation](#)

Asus WS C621E SAGE Series

[RAMPAGE V EDITION 10 Chapter 2: Basic Installation](#)

Asus RAMPAGE V EDITION 10

[ROG STRIX X399-E GAMING Chapter 2: Basic Installation](#)

Asus ROG STRIX X399-E GAMING

[PRIME Z370-A II Series Chapter 2: Basic Installation](#)

Asus PRIME Z370-A II Series