

Motherboard Installation - Asus SABERTOOTH Z170 Manual

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16


17

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174




•

[Table of Contents](#)

•

Bookmarks



2.1.2

Motherboard installation

The diagrams in this section are for reference only. The motherboard layout may vary with models, but the installation steps are the same for all models.

1.

Match and align four (4) holes of the back I/O dust grid and four (4) fasteners of the back I/O dust frame then attach the dust grid to the dust frame.

2.

Match and align the four (4) fasteners of the back I/O dust frame and grid assembly to the four (4) circular holes on the back I/O fan vent of the I/O shield then push to fasten the back I/O dust grid into the I/O shield with the back I/O dust frame.

Back I/O dust frame

Back I/O dust grid

I/O shield

Clean your back I/O dust filter from time to time, especially when it is dirty, to ensure optimum airflow.

3.

Install the ASUS Q-Shield to the chassis rear I/O panel.

SABERTOOTH Z170 S

2-3

[Table of Contents](#)

[Previous Page](#)

[Next Page](#)

1
...
44
45
46
47
48
49
50
51

Quick Links:

[Motherboard Layout](#)

[Internal Connectors](#)

[Sata Device Connection](#)

[Front I/O Connector](#)

Related Manuals for Asus SABERTOOTH Z170

[Motherboard Asus Z170 PRO GAMING User Manual](#)

(100 pages)

[Motherboard Asus Z170 PRO GAMING Manual](#)

(96 pages)

[Motherboard Asus Z170-A User Manual](#)

(130 pages)

[Motherboard Asus Z170M-E D3 Manual](#)

(85 pages)

[Motherboard Asus Z170-P D3 User Manual](#)

(85 pages)

[Motherboard Asus Z170-K Quick Start Manual](#)

(11 pages)

[Motherboard ASUS Z170-K User Manual](#)

(85 pages)

[Motherboard Asus Z170-P Manual](#)

(86 pages)

[Motherboard Asus Z170-AR Manual](#)

(130 pages)

[Motherboard Asus Z170M-PLUS User Manual](#)

(89 pages)

[Motherboard Asus SABERTOOTH Z170 MARK 1 Manual](#)

(176 pages)

[Motherboard Asus Z170I PRO GAMING User Manual](#)

(86 pages)

[Motherboard Asus Z170I PRO GAMING Manual](#)

(86 pages)

[Motherboard Asus Z170-E Manual](#)

(128 pages)

[Motherboard Asus Z170-DELUXE Series User Manual](#)

(186 pages)

[Motherboard Asus Z170-PRO Manual](#)

(170 pages)

Related Content for Asus SABERTOOTH Z170

[TUF GAMING Z590-PLUS Motherboard Installation](#)

Asus TUF GAMING Z590-PLUS

[MAXIMUS VII HERO Motherboard Installation](#)

Asus MAXIMUS VII HERO

[STRIX Z270H GAMING Motherboard Installation](#)

Asus STRIX Z270H GAMING

[PRIME Z590-V Motherboard Installation](#)

Asus PRIME Z590-V

[ROG MAXIMUS XII EXTREME Motherboard Installation](#)

Asus ROG MAXIMUS XII EXTREME

[Pro WS W680-ACE Motherboard Installation](#)

Asus Pro WS W680-ACE

[ROG MAXIMUS XII Z490 APEX Motherboard Installation](#)

Asus ROG MAXIMUS XII Z490 APEX

[TUF X470-PLUS GAMING Motherboard Installation](#)

Asus TUF X470-PLUS GAMING