

Bios Update Utility - Asus SABERTOOTH Z170 Manual


1
2
Table Of Contents
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174



•

[Table of Contents](#)

•

Bookmarks



2.2

BIOS update utility

USB BIOS Flashback

USB BIOS Flashback allows you to easily update the BIOS without entering the existing BIOS or operating system. Simply insert a USB storage device to the USB port, press the USB BIOS Flashback button for three seconds, and the BIOS is updated automatically.

To use USB BIOS Flashback:

- 1.

Place the bundled support DVD to the optical drive and install the USB BIOS Flashback Wizard. Follow the onscreen instructions to complete the installation.

- 2.

Insert the USB storage device to the USB Flashback port.

Please ensure to use the BIOS file named Z170STS.CAP. Please refer to Chapter 3: BIOS setup for more information.

3.

Launch the USB BIOS Flashback Wizard to automatically download the latest BIOS version.

4.

Press the BIOS Flashback button for three seconds until a flashing light appears, which indicates that the BIOS Flashback function is enabled.

5.

Wait until the light goes out, indicating that the BIOS updating process is completed.

USB BIOS Flashback button

For more BIOS update utilities in BIOS setup, refer to the section Updating BIOS in Chapter 3.

• DO NOT unplug portable disk, power system, or use the CLR_CMOS jumper while BIOS update is ongoing, otherwise update will be interrupted. In case of interruption, please follow the steps again.

• If the light flashes for five seconds and turns into a solid light, this means that the BIOS Flashback is not operating properly. This may be caused by improper installation of the USB storage device and filename/file format error. If this scenario happens, please restart the system to turn off the light.

• Updating BIOS may have risks. If the BIOS program is damaged during the process and results to the system's failure to boot up, please contact your local ASUS Service Center.

SABERTOOTH Z170 S

USB BIOS Flashback port

2-15

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
56
57
58
59
60
61
62
63

Quick Links:

[Motherboard Layout](#)

[Internal Connectors](#)

[Sata Device Connection](#)

[Front I/O Connector](#)

Related Manuals for Asus SABERTOOTH Z170

[Motherboard Asus Z170 PRO GAMING User Manual](#)

(100 pages)

[Motherboard Asus Z170 PRO GAMING Manual](#)

(96 pages)

[Motherboard Asus Z170-A User Manual](#)

(130 pages)

[Motherboard Asus Z170M-E D3 Manual](#)

(85 pages)

[Motherboard Asus Z170-P D3 User Manual](#)

(85 pages)

[Motherboard Asus Z170-K Quick Start Manual](#)

(11 pages)

[Motherboard ASUS Z170-K User Manual](#)

(85 pages)

[Motherboard Asus Z170-P Manual](#)

(86 pages)

[Motherboard Asus Z170-AR Manual](#)

(130 pages)

[Motherboard Asus Z170M-PLUS User Manual](#)

(89 pages)

[Motherboard Asus SABERTOOTH Z170 MARK 1 Manual](#)

(176 pages)

[Motherboard Asus Z170I PRO GAMING User Manual](#)

(86 pages)

[Motherboard Asus Z170I PRO GAMING Manual](#)

(86 pages)

[Motherboard Asus Z170-E Manual](#)

(128 pages)

[Motherboard Asus Z170-DELUXE Series User Manual](#)

(186 pages)

[Motherboard Asus Z170-PRO Manual](#)

(170 pages)

Related Content for Asus SABERTOOTH Z170

[ROG MAXIMUS XII Z490 APEX Bios Update Utility](#)

Asus ROG MAXIMUS XII Z490 APEX

[ROG STRIX B560-A GAMING Series Bios Update Utility](#)

Asus ROG STRIX B560-A GAMING Series

[ROG CROSSHAIR VIII IMPACT Bios Update Utility](#)

Asus ROG CROSSHAIR VIII IMPACT

[WS C621E SAGE Series Bios Update Utility](#)

Asus WS C621E SAGE Series

[RAMPAGE V EDITION 10 Bios Update Utility](#)

Asus RAMPAGE V EDITION 10

[ROG STRIX X399-E GAMING Bios Update Utility](#)

Asus ROG STRIX X399-E GAMING

[ROG STRIX Z690-E GAMING WIFI Bios Update Utility](#)

Asus ROG STRIX Z690-E GAMING WIFI

[WS C422 SAGE/10G Bios Update Utility](#)

Asus WS C422 SAGE/10G