

Advanced Mode - Asus SABERTOOTH Z170 Manual

1

2

Table Of Contents

3

4

5

6

7

8

9

10

11

12

13

14

15

16


17

19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68

69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118

119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168

169
170
171
172
173
174



•

[Table of Contents](#)

•

Bookmarks



3.2.2

Advanced Mode

The Advanced Mode provides advanced options for experienced end-users to configure the BIOS settings. The figure below shows an example of the Advanced Mode. Refer to the following sections for the detailed configurations.

To switch from EZ Mode to Advanced Mode, click Advanced Mode or press <F7> hotkey.

Configuration fields

Menu bar

Language

Sub-menu item

Menu items

3-4

MyFavorite(F3)



Qfan Control(F6)
General help
Quick Note (F9)
EZ Tuning Wizard(F11)
Go back to EZ Mode
Last modified settings
Displays the CPU temperature,
CPU, and memory voltage output
Scroll bar
Hot Keys
Search on the FAQ
Chapter 3: BIOS Setup

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
...
65
66
67
68
69
70
71
72

Quick Links:

[Motherboard Layout](#)

[Internal Connectors](#)

[Sata Device Connection](#)

[Front I/O Connector](#)

Related Manuals for Asus SABERTOOTH Z170

[Motherboard Asus Z170 PRO GAMING User Manual](#)

(100 pages)

[Motherboard Asus Z170 PRO GAMING Manual](#)

(96 pages)

[Motherboard Asus Z170-A User Manual](#)

(130 pages)

[Motherboard Asus Z170M-E D3 Manual](#)

(85 pages)

[Motherboard Asus Z170-P D3 User Manual](#)

(85 pages)

[Motherboard Asus Z170-K Quick Start Manual](#)

(11 pages)

[Motherboard ASUS Z170-K User Manual](#)

(85 pages)

[Motherboard Asus Z170-P Manual](#)

(86 pages)

[Motherboard Asus Z170-AR Manual](#)

(130 pages)

[Motherboard Asus Z170M-PLUS User Manual](#)

(89 pages)

[Motherboard Asus SABERTOOTH Z170 MARK 1 Manual](#)

(176 pages)

[Motherboard Asus Z170I PRO GAMING User Manual](#)

(86 pages)

[Motherboard Asus Z170I PRO GAMING Manual](#)

(86 pages)

[Motherboard Asus Z170-E Manual](#)

(128 pages)

[Motherboard Asus Z170-DELUXE Series User Manual](#)

(186 pages)

[Motherboard Asus Z170-PRO Manual](#)

(170 pages)

Related Content for Asus SABERTOOTH Z170

[PRIME X570-PRO Advanced Mode](#)

Asus PRIME X570-PRO

[STRIX Z270F GAMING Advanced Mode](#)

Asus STRIX Z270F GAMING

[B450M-A/CSM Advanced Mode](#)

Asus B450M-A/CSM

[MAXIMUS VII HERO Advanced Mode](#)

Asus MAXIMUS VII HERO

[STRIX Z270H GAMING Advanced Mode](#)

Asus STRIX Z270H GAMING

[PRIME B250M-J Advanced Mode](#)

Asus PRIME B250M-J

[H110M-K X Advanced Mode](#)

Asus H110M-K X

[PRIME H310M-C/PS R2.0 Advanced Mode](#)

Asus PRIME H310M-C/PS R2.0