

Save These Instructions - Whirlpool WFAU Installation Instructions Manual

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18

19
20
21
22
23
24



•

[Table of Contents](#)

-

Troubleshooting

•

Bookmarks



IMPORTANT SAFETY INSTRUCTIONS

Use only with type of gas approved for this furnace.

Refer to the furnace rating plate.

Install this furnace only in a location and position as specified in the "Location Requirements" section of these instructions.

Provide adequate combustion and ventilation air to the furnace space as specified in the "Venting Requirements" section of these instructions.

Combustion products must be discharged outdoors.

Connect this furnace to an approved vent system only, as specified in the "Venting Requirements" section of these instructions.

Never test for gas leaks with an open flame. Use a

commercially available soap solution made specifically for the detection of leaks to check all connections, as specified in the "Make Gas Connections" section of these instructions.

Adequate clearance must be provided around the vent air intake terminals.

Always install furnace to operate within the furnace's intended temperature-rise range with a duct system which has an external static pressure within the allowable range, as specified in the "Complete Installation" section of these instructions. See furnace rating plate.

WARNING:

FIRE OR EXPLOSION HAZARD

Failure to follow safety warnings exactly could result in serious injury, death or property damage.

— **Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.**

— **WHAT TO DO IF YOU SMELL GAS**

- **Do not try to light any appliance.**
- **Do not touch any electrical switch; do not use any phone in your building.**
- **Leave the building immediately.**
- **Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.**
- **If you cannot reach your gas supplier, call the fire department.**

— **Installation and service must be performed by a qualified installer, service agency or the gas supplier.**

2

SAVE THESE INSTRUCTIONS

When a furnace is installed so that supply ducts carry air circulated by the furnace to areas outside the space containing the furnace, the return air shall also be handled by duct(s) sealed to the furnace casing and terminating outside the space containing the furnace.

A gas-fired furnace for installation in a residential garage must be installed as specified in the "Location Requirements" section of these instructions.

The furnace is not to be used for temporary heating of buildings or structures under construction.

The furnace shall be installed so the electrical components are protected from water.

Furnaces for indoor installation on combustible flooring shall not be installed directly on carpeting, tile or other combustible material other than wood flooring.

[Table of Contents](#)

[Previous Page](#)
[Next Page](#)

1
2
3
4
5
6

Quick Links:

[Tools and Parts](#)

[Troubleshooting](#)

Related Manuals for Whirlpool WFAU

[Furnace Whirlpool WFAU Installation Instructions Manual](#)

(20 pages)

[Furnace Whirlpool Whirlpool furnace User Instructions](#)

(12 pages)

[Furnace Whirlpool GAS FURNACE User Instructions](#)

(8 pages)

[Furnace Whirlpool WGFD293 Installation Instructions Manual](#)

93% and 95% 2-stage variable speed gas furnace (52 pages)

[Furnace Whirlpool WGFM29 Installation Instructions Manual](#)

93% and 95% 2-stage variable-speed gas furnace (52 pages)

[Furnace Whirlpool W2PG Installation Instructions Manual](#)

Package gas electric furnaces (20 pages)

[Furnace Whirlpool Gold WGFM195 Installation Instructions Manual](#)

Gold gas-fired warm air furnace (52 pages)

[Furnace Whirlpool WGFD28 Installation Instructions Manual](#)

80% 2-stage variable speed gas furnace gold models (40 pages)

[Furnace Whirlpool WFCU Installation Instructions Manual](#)

(28 pages)

[Furnace Whirlpool WFCT Installation Instructions Manual](#)

90+ multipositional gas furnace (32 pages)

[Furnace Whirlpool GAS FURNACE User Instructions](#)

(8 pages)

[Furnace Whirlpool WGFM195 Installation Instructions Manual](#)

(48 pages)

[Furnace Whirlpool Gold WGFD295 Installation Instructions Manual](#)

80% 2-stage variable speed gas furnace (40 pages)

[Furnace Whirlpool WFCU Installation Instructions Manual](#)

90+ gas furnace (24 pages)

Related Content for Whirlpool WFAU

[WGFBLT Installation Instructions](#)

Whirlpool WGFBLT

[Gold WFD193 Installation Instructions](#)

Whirlpool Gold WFD193

[W2PG Furnace Installation Instructions](#)

Whirlpool W2PG

[WPG Installation Instructions](#)

Whirlpool WPG

[WFM18 Installation Instructions](#)

Whirlpool WFM18

[WGFD293 Installation Instructions](#)

Whirlpool WGFD293

[WGFD28 Installation Instructions](#)

Whirlpool WGFD28

[Gold WGFD295 Installation Instructions](#)

Whirlpool Gold WGFD295

This manual is also suitable for:

[WfarWfluWfatWflrWflr](#)